


Series LC™

Oil, Gas & Gas/Oil Boilers – Water



Installation, Operation & Maintenance Manual



PeerlessBoilers.com

TABLE OF CONTENTS

USING THIS MANUAL	1	5. VENTING	26
A. INSTRUCTION MANUALS	1	6. INSTALL THE BURNER	26
B. SPECIAL ATTENTION BOXES	1	A. BURNER APPLICATION	26
1. PREINSTALLATION	2	B. INSTALL BURNER MOUNTING PLATE	26
A. ACCESSIBILITY CLEARANCES	2	C. MOUNT THE BURNER	26
B. CLEARANCE FROM COMBUSTIBLE CONSTRUCTION	3	7. CONNECT FUEL PIPING	28
C. COMBUSTION & VENTILATION AIR	3	A. GENERAL	28
D. CHIMNEY OR VENT	3	B. INSTALL FUEL OIL PIPING	28
E. BOILER WATER TREATMENT	4	C. INSTALL GAS SUPPLY PIPING	28
F. BOILER SETTING	4	D. TEST GAS SUPPLY PIPING	28
G. INSTALLATION SURVEY	5	8. INSTALL CONTROLS & TRIM	30
H. PLANNING THE LAYOUT	5	A. INSTALL SAFETY RELIEF VALVE	30
I. VERIFY COMPONENTS	5	B. INSTALL DRAIN VALVE	30
2. PLACE THE BOILER	9	C. INSTALL LOW WATER CUTOFFS	30
A. PACKAGED BOILER	9	D. INSTALL CONTROLS & TRIM	30
B. ASSEMBLED BLOCK BOILER	9	E. PIPE TANKLESS HEATERS IF USED	31
C. KNOCKDOWN BOILERS	9	F. CONNECT SUPPLY WIRING	31
D. INSTALL COILS OR PLATES	13	G. INSTALL CONTROL WIRING	31
E. HYDROSTATIC TEST THE BOILER	13	9. STARTING THE BOILER	34
F. APPLY CLEANOUT COVER PLATES	15	A. CHECK THE PIPING	34
G. INSTALL FLUE COLLAR	16	B. FILL THE BOILER	34
H. INSTALL FLUE BAFFLES	16	C. RUN BURNER CHECK-OUT	34
3. PIPE THE BOILER	17	D. CHECK BOILER CONTROLS	35
A. PREPARATION	17	10. MAINTENANCE	37
B. SUPPLY & RETURN PIPING	17	A. PLACING BOILER IN OPERATION	37
C. LOW SYSTEM TEMPERATURE	17	B. TO SHUT DOWN THE BOILER	37
D. CHILLED WATER SYSTEMS	20	C. MAINTENANCE – ANNUAL	37
E. HIGH FLOW RATE PIPING	20	D. MONTHLY MAINTENANCE	38
F. MULTIPLE BOILER INSTALLATIONS	20	E. DAILY MAINTENANCE	38
4. ASSEMBLE THE JACKET	24	11. BOILER RATINGS & DIMENSIONS	39
A. PREPARE THE PARTS	24	12. REPAIR PARTS	42
B. APPLY JACKET SIDES & CORNERS	24	13. STARTUP & SERVICE REPORT	44
C. APPLY JACKET FRONT PANELS	24		
D. APPLY JACKET REAR PANEL	24		
E. APPLY JACKET TOP PANELS	24		
F. APPLY PLATES AND LABELS	24		

USING THIS MANUAL

A. INSTRUCTION MANUALS

The Series LC™ Installation, Operation & Maintenance Manual is divided into four basic sections:

1. Preinstallation (Section 1)
2. Installation (Sections 2 through 8)
3. Start-Up (Section 9)
4. Maintenance (Section 10)

B. SPECIAL ATTENTION BOXES

Throughout this manual you will see special attention boxes intended to supplement the instructions and make special notice of potential hazards. These categories mean, in the judgment of PB Heat, LLC:



DANGER

Indicates a hazardous situation, which, if not avoided, will result in death or serious injury and major property damage.



WARNING

Indicates a hazardous situation, which, if not avoided, could result in death or serious injury and major property damage.



CAUTION

Indicates a hazardous situation, which, if not avoided, could result in minor or moderate injury, and minor property damage.

NOTICE

Indicates special attention is needed, not related to personal injury or property damage.

1. PREINSTALLATION

Carefully read these instructions before beginning work. Understand all aspects of the installation. Contact your PB Heat's sales representative or customer service for help in answering questions.

⚠ WARNING

This manual is intended for use by Qualified Heating Professionals only. Installation, service, or adjustment of this heating appliance by anyone other than a Qualified Heating Professional may cause severe personal injury, death, or major property damage.

This boiler must be installed by a qualified contractor. The boiler warranty can be voided if the boiler is not installed, maintained and serviced correctly.

NOTICE

The installer must verify that at least one carbon monoxide alarm has been installed within a residential living space or home following the alarm manufacturer's instructions and applicable local codes before putting the appliance into operation.

L'installateur est tenu de vérifier qu'au moins une alarme de détection de monoxyde de carbone soit installée dans une espace résidentiel ou dans un domicile conformément aux directives du fabricant de l'alarme et aux codes locaux applicables avant de mettre l'appareil en service.

NOTICE

The equipment must be installed in accordance with installation requirements of the authority having jurisdiction or, in the absence of such requirements, to the current edition of the *National Fuel Gas Code*, ANSI Z223.1/NFPA 54.

Where required by the authority having jurisdiction, the installation must conform to *American Society of Mechanical Engineers Safety Code for Controls and Safety Devices for Automatically Fired Boilers*, ASME CSD-1.





Figure 1.1: Clearance Requirements

A. ACCESSIBILITY CLEARANCES

1. The following recommendations allow for *reasonable access to the boiler*. Follow local codes and requirements when setting actual layout. See Figure 1.1.
 - a) For installing, removing and servicing the burner: provide 48" between the front of the boiler and any adjacent wall or other appliance.
 - b) For access to the top of the boiler for cleaning flueways: provide 24" above top of jacket.
 - c) For accessing and servicing of level controls and inspection tappings (if used): provide 24" minimum from the right side of the boiler to any wall or obstruction.
 - d) For installation of jacket: provide at least 12" from the left side of the boiler to any wall or obstruction. More clearance may be needed for longer boilers unless the jacket is pre-assembled before placing the boiler.
 - e) For installation and removal of tankless heaters: provide 45" between the end of the boiler and any adjacent wall or obstruction. [This provides for all available tankless coils. The spacing can be closer for Heater Number X-1020 (allow 30")].

B. CLEARANCE FROM COMBUSTIBLE CONSTRUCTION

Provide the following *minimum clearances to combustible construction*. See Figure 1.1.

1. Sides: 6"
2. Rear of Jacket: 6"
3. Front of Jacket: 24"
4. Top of Jacket: 24"
5. Hot Water Pipes: 6"
6. Vent or Chimney Connector: 18"

C. COMBUSTION & VENTILATION AIR

1. The installation must provide adequate air for combustion and ventilation.
2. Unless the boiler room construction and natural air infiltration are sure to provide all the air needed, provide an opening or duct to the outside with a free cross sectional area of at least 1 square inch per 4000 Btuh input for all installed appliances. At high altitude, increase this requirement 4% for each 1000 feet above sea level.
3. The boiler room must never be under negative pressure. If exhaust fans or other equipment can cause a negative pressure in the boiler room, the air openings and equipment design must be engineered to assure a neutral or slightly positive pressure in the boiler room at all times of operation. If the equipment design and air openings cannot assure this, then the boiler must be located in an isolated room.

4. Using combustion air dampers:

If motorized dampers are used on the combustion and ventilation air openings, wire them such that they must open when the boiler tries to operate. They must include a switch which prevents the boiler from operating if they do not open. See Figure 1.2.




Figure 1.2: Motorized Vent Damper Interlock

D. CHIMNEY OR VENT

1. Inspect the existing chimney or vent system. Make sure it is in good condition. Inspect chimney liner and repair or replace if necessary.
2. The vent system and installation must be in accordance with the current edition of the American National Standard ANSI/NFPA 211, "Chimneys, Fireplaces, Vents, and Solid Fuel Burning Appliances", or applicable provisions of the local building codes.
3. Chimney/Vent Operation: The vent system must be sized and installed to remove all combustion products. If the vent system is not sized properly, the burner may not operate properly. This can cause poor combustion or sooting to occur.
4. If the vent terminates in an area where wind-generated downdrafts are likely, install a suitable vent cap which can control wind effects.
5. This boiler is designed to fire only with a pressurized fire box. The breeching and vent may be sized for negative, neutral or positive pressure (no more than 0.1 inches water column at the boiler outlet) as desired. But negative pressure overfire can cause lifting of the flame and poor combustion or overheating of the boiler crown sheet.
6. Forced draft breechings and vents must be sealed and of heavy gauge steel construction and must comply with all applicable codes of construction.
7. The vent diameter and minimum height for stub vents are listed in the Ratings and Dimensions Section of this manual. Always extend vent terminations at least 3 feet above the roof line. See Figure 1.3.

⚠ WARNING

Failure to provide adequate venting can result in severe property damage, personal injury or death.




Figure 1.3: Vent Termination, Typical

8. Exterior Vents:
Insulate sufficiently to ensure adequate draft and to prevent vent damage due to condensation.
9. Vent Connection to Boiler:
 - a) Support the weight of the vent system independently of the boiler flue connection.
 - b) Provide support of the vent connector (breeching) at maximum 12 foot intervals to prevent sagging and to provide a minimum upward slope of 1/4" per foot.
10. Do not vent natural draft appliances in a combined vent which operates under positive pressure.
11. Draft Regulator: Install a barometric draft regulator where using high chimney or any high draft vent. This is needed to prevent causing negative draft in the boiler. Excess draft will cause flame lifting and possible impingement.

E. BOILER WATER TREATMENT

1. Consult a local qualified water treatment specialist for recommendations regarding the appropriate chemical compounds and concentrations which are compatible with local environmental regulations.
 - a) Boiler water pH should be in the 7.5 to 11 range.
 - b) Boiler water chloride concentration should be less than 30 ppm.
 - c) The water hardness should be less than 9 grains per gallon to prevent scale build-up.




Figure 1.4: Foundation Layout

F. BOILER SETTING

1. If the boiler room floor is not level or if additional structural support is needed, provide a good, level foundation for the boiler with the minimum dimensions given in Table 1.1. The flooring and structural support system must be suitable for the operating weight of the boiler and any connected piping. Place the Steel Channels on the foundation as shown in Figure 1.4.
2. Do not operate the boiler until the foundation, if new concrete, has thoroughly cured. The concrete might be damaged if heated too quickly due to the entrained moisture remaining.

WARNING

Do not install this boiler on carpeting or any combustible flooring. A significant fire hazard could result, with potential for property damage, personal injury or death.

3. If the boiler is installed in a penthouse or if wiring of any sort is run underneath the boiler foundation, construct the foundation with provision for air flow underneath between the main floor and the top of the boiler foundation.
 - a) An acceptable foundation would be concrete blocks laid with the openings lined up.
 - b) If the foundation must be a concrete slab, use an air cell high temperature insulating board, at least 1/2 inch thick, with aluminum backing, aluminum side up. 1/2 inch thick high temperature millboard with aluminum backing is acceptable as well. Place the insulating board on the slab between the steel channels.

Table 1.1: Foundation Lengths

Model	Foundation Length, Inches
LC-04	37-15/16
LC-05	43
LC-06	48-1/16
LC-07	53-1/8
LC-08	58-5/16
LC-09	63-3/8
LC-10	68-7/16
LC-11	73-1/2
LC-12	78-9/16

G. INSTALLATION SURVEY

For new and existing installations, a Water Installation Survey is available from PB Heat, LLC. The survey will provide information on how a hot water boiler works with your specific system and will provide an overview of hot water system operation in general.

You can also use this survey to locate system problems which will have to be corrected. To obtain copies of the Water Installation Survey, contact your PB Heat representative or download it from PeerlessBoilers.com.

H. PLANNING THE LAYOUT

Prepare sketches and notes of the layout to minimize the possibility of interferences with new or existing equipment, piping, venting and wiring.

I. VERIFY COMPONENTS

1. Packaged: All components should be inside crate. In some cases the burner may be shipped separately. Optional equipment, such as barometric draft dampers, may also be shipped separately.
2. Knockdown: All components shipped for field assembly. See Table 1.2 for standard components. See Tables 1.3 through 1.8 for optional components.
 - a) Channel Rails
 - b) Sections
 - c) Assembly Kit Carton(s): Includes flow port gaskets, tie rods with hardware, high temperature rope, and cleanout cover plates.
 - d) Flue Box Carton: Includes flue box, rear observation assembly and port cover plates.
 - e) Baffle Carton: Includes baffles, combustion chamber liner and rating label.
 - f) Jacket Cartons: Includes ASME plate
 - g) Burner Mounting Plate
 - h) Trim Carton: Includes safety relief valve and temperature-pressure gage
 - i) Control Carton: Limit controls
 - j) Tankless Heater(s)
 - k) Additional controls and fittings
3. Assembled Block: Same as knockdown except channel rails, sections and assembly kit cartons are assembled into a block as a single shipping level component.

Table 1.2: Series LC™ Shipping List

Boiler Model Number	Channel Rail Bundle	Standard Sections (See Table 1.3 for Options)				Baffle Carton	Assembly Kit Ctns. Contents See Below Item 1	Flue Ctn. Contents See Below Item 2	Jacket Cartons (Tbl 1.4, 1.5 Options)	
		Front	Back	Plain Interm.	1" LWCO Interm.	3" Tap. Interm.			Front/Rear Panels Hardware	Top Side Panels Hardware Chamber Liner
LC-04	Quantity	1	1	1	1		1	1	1	1
	Part No.	LC-1013	LC-1016	LC-1000	LC-1000-1		LC-1023	LC-1022	LC-6016	LC-6017
	Label						LC-04	A		A
	Stock Code	86010	86018	86004	86005		85004	86050	86030	86031
LC-05R	Quantity	1	1	2	1		1	1	1	1
	Part No.	LC-1013	LC-1016	LC-1000	LC-1000-1		LC-1023	LC-1022-1	LC-6016	LC-6017-1
	Label						LC-05	B		B
	Stock Code	86010	86018	86004	86005		85105	86051	86030	86032
LC-05	Quantity	1	1	2	1		1	1	1	1
	Part No.	LC-1013	LC-1016	LC-1000	LC-1000-1		LC-1023-1	LC-1022-1	LC-6016	LC-6017-1
	Label						LC-05	B		B
	Stock Code	86010	86018	86004	86005		85005	86051	86030	86032
LC-06	Quantity	1	1	3	1		1	1	1	1
	Part No.	LC-1013	LC-1016	LC-1000	LC-1000-1		LC-1023-2	LC-1022-2	LC-6016	LC-6017-2
	Label						LC-06	C		C
	Stock Code	86010	86018	86004	86005		85006	86052	86030	86033
LC-07	Quantity	1	1	4	1		1	1	1	1
	Part No.	LC-1013	LC-1016	LC-1000	LC-1000-1		LC-1023-3	LC-1022-3	LC-6016	LC-6017-3
	Label						LC-07	D		D
	Stock Code	86010	86018	86004	86005		85007	86053	86030	86034
LC-08	Quantity	1	1	4	1	1	1	1	1	1
	Part No.	LC-1013	LC-1016	LC-1000	LC-1000-1	LC-1015	LC-1023-4	LC-1022	LC-6016	LC-6017-1
	Label						LC-08	A		A
	Stock Code	86010	86018	86004	86005	86016	85008	86050	86030	86031
LC-09	Quantity	1	1	5	1	1	1	2	1	2
	Part No.	LC-1013	LC-1016	LC-1000	LC-1000-1	LC-1015	LC-1023-5	LC-1022-1	LC-6016	LC-6017-1
	Label						LC-09	B		B
	Stock Code	86010	86018	86004	86005	86016	85009	86051	86030	86032
LC-10	Quantity	1	1	6	1	1	1	1	1	1
	Part No.	LC-1013	LC-1016	LC-1000	LC-1000-1	LC-1015	LC-1023-6	LC-1022-2	LC-6016	LC-6017-1
	Label						LC-10	B		B
	Stock Code	86010	86018	86004	86005	86016	85010	86052	86030	86033
LC-11	Quantity	1	1	7	1	1	1	2	1	2
	Part No.	LC-1013	LC-1016	LC-1000	LC-1000-1	LC-1015	LC-1023-7	LC-1022-2	LC-6016	LC-6017-2
	Label						LC-11	C		C
	Stock Code	86010	86018	86004	86005	86016	85011	86052	86030	86033
LC-12	Quantity	1	1	8	1	1	1	1	1	1
	Part No.	LC-1013	LC-1016	LC-1000	LC-1000-1	LC-1015	LC-1023-8	LC-1022-3	LC-6016	LC-6017-2
	Label						LC-12	C		C
	Stock Code	86010	86018	86004	86005	86016	85012	86052	86030	86034

1 Assembly Kit Cartons Contents: Flow Port Gaskets, Silicone Sealant, Tie Rods, Washers, Tie Rod Nuts, Section Seal Rope, Spray Adhesive, Cleanout Plates, Mounting Hardware

2 Flue Box Carton Contents: Flue Box, Seal Rope, Observation Assembly, Coil Cover Plates, Cover Plate Gaskets, Mounting Hardware

Table 1.3: Standard and Optional Sections for Knockdown Boilers

Sections		50 psig MAWP				80 psig MAWP			
		Standard No Inspection Tappings		w/Inspection Tappings		No Inspection Tappings		w/Inspection Tappings	
Front	Part #/UPC	LC-1001	86000	LC-1013	86010	LC-1001-2	86002	LC-1013-2	86012
Plain Interm.	Part #/UPC	LC-1000	86004	LC-1014	86014	LC-1000-2	86006	LC-1014-1	86015
LWCO Interm.	Part #/UPC	LC-1000-1	86005	LC-1014-2	86092	LC-1000-3	86007	LC-1014-3	86093
3" Tap. Interm.	Part #/UPC	LC-1003	86008	LC-1015	86016	LC-1003-2	86009	LC-1015-1	86017
Closed Back	Part #/UPC	LC-1007	86022	LC-1016	86018	LC-1007-2	86024	LC-1016-2	86020
Coil Back	Part #/UPC	LC-1002	86036	LC-1017	86026	LC-1002-2	86038	LC-1017-2	86028

Table 1.4: Standard and Optional Jacket Cartons, Front/Back Panels

Standard 50 psig MAWP	86030
30 psig MAWP	86059
80 psig MAWP	86058

Note: 80 psig MAWP not available in Canada.

Table 1.5: Standard and Optional Jacket Cartons, Top/Side Panels

Jacket Label	Standard (No Inspection Tappings)	With Inspection Tappings
A	86031	86101
B	86032	86102
C	86033	86103
D	86034	86104
E	86094	86097

Note: Boilers with inspection tappings in front and back sections only use standard cartons.

Table 1.6: Burner Mounting Plates

Model		Boiler Model									
		LC-04	LC-05R	LC-05	LC-06	LC-07	LC-08	LC-09	LC-10	LC-11	LC-12
Beckett	CF-800	86070*	86070*								
	CF-1400			86069*	86069*	86069*					
	CF-2300						86074*	86074*	86074*	86074*	86074*
Carlin	301CRD	86070*	86070*								
	702CRD			86069*	86069*	86069*	86069*				
	801CRD							86073	86073	86073	86073
Gordon Piatt	S4.2	86070*	86070*								
	R6.2			86078							
	R6.3				86078						
	R8.1					86079	86079				
	R8.2							86079	86079	86079	
	R8.3										86079
Power Flame	C1	86071	86071	86071	86071	86071					
	C2						86076	86076	86076	86076	86076
	J15A	86072	86072								
	J30A			86072	86072	86072					
	J50A						86077	86077	86077	86077	
Webster	JB1	86071	86071	86071	86071	86071	86075	86075	86075	86075	86075

* Standard Burner Mounting Plate

Table 1.7: Trim Cartons

Model	Output ¹		
	30 psig	50 psig	80 psig
LC-04	87030	87050	87080
LC-05R	87030	87050	87080
LC-05	87030	87050	87080
LC-06	87030	87050	87080
LC-07	87031	87050	87080
LC-08	87031	87050	87080
LC-09	87032	87051	87080
LC-10	87032	87051	87081
LC-11	87032	87051	87081
LC-12	87032	87051	87081

¹ Safety Relief Valve selection based on capacity determined by boiler output (Gross I=B=R Output). Applies to most locations in United States and Canada.

Table 1.8: Control Cartons

Model	Stock Code	Label
LC-04 Through LC-12	88511	Water

2. PLACE THE BOILER

A. PACKAGED BOILER

1. Remove crate top and sides. Remove any loose cartons. Remove burner support pedestal and nipple, if supplied.
2. Lift boiler off crate pallet. Move to location determined in Chapter 1: Preinstallation.
3. Remove lifting frame and hardware.
4. Re-install burner support pedestal and nipple if necessary.
5. Proceed to Chapter 3: Piping the Boiler.

B. ASSEMBLED BLOCK BOILER

1. Move block to location determined in Chapter 1: Preinstallation.

2. Remove lifting frame and hardware.
3. Proceed to Section D: Install Coils or Plates

C. KNOCKDOWN BOILER

1. Place channel rails as shown in Figure 1.4.
2. Open the Section Assembly Kit cartons. These cartons contain the parts needed for assembly of the sections.
3. Place the Back Section on the floor as shown in Figure 2.1.
4. The Back Section combustion chamber area is lined with a ceramic fiber blanket liner. Make sure the liner is in good condition. Minor tears are not a problem, but there should be no holes in the insulation.




Figure 2.1: Lay Sections on Floor and Apply Rope Seal and Gaskets




Figure 2.2: Flow Port Machining & Gasket

CAUTION

Gaskets will be damaged by petroleum or its derivatives. Completely remove all solvent residue before placing gaskets.

Do not use petroleum based compounds in the boiler.

5. Clean the area around the flow ports and in the seal recess. Use solvent and a clean cloth to thoroughly clean all of the sealing surfaces. Remove all foreign matter to assure a water tight seal when the sections are drawn together.
6. Place a Flow Port Gasket in each of the three flow port recesses as shown in Figures 2.1 and 2.2.
7. Apply spray adhesive in the rope groove around the perimeter of the section.
8. Place the sealing rope completely around the rope groove, being careful not to stretch the rope. Extend the rope from 1/4" to 1/2" past the end of the groove on both sides of the cleanout opening on top of the section. This will assure a gas tight seal when the cleanout cover plate is applied.
9. Apply a bead of silicone sealant around each flow port as shown in Figure 2.3. Do not get sealant on the flow port gaskets.

WARNING

The sections are heavy and must be supported securely.

10. Lift up the Rear Section and move into position on the steel channels on the boiler foundation.
11. Screw a 3" pipe at least 30 inches long into the lower 3" tapping on the back of the Rear Section as shown in Figure 2.4. Place a block under the pipe as shown in the figure and use as a brace during assembly.
12. Place a Plain Intermediate Section on the floor and prepare as above.
13. Carefully place the Intermediate Section against the Rear Section and visually line up the flow ports as close as possible.
14. Insert a tie rod with one nut and washer applied into each of the four tie rod lugs. See Figure 2.5.
15. Place the nut and washer on the other end of the tie rod and draw finger tight.




Figure 2.3: Apply Silicone Sealant

⚠ WARNING

**SECTIONS ARE TOP HEAVY.
HANDLE WITH CARE TO
AVOID TIPPING OR FALLING.**

LEVEL EACH SECTION:
PLACE THE FIRST INTERMEDIATE
SECTION NEXT TO THE
REAR SECTION AS SHOWN.
USE A SPIRIT LEVEL TO
MAKE SURE THE SECTIONS ARE
PLUMB. CHECK THE LEVEL AS
EACH ADDITIONAL INTERMEDIATE
SECTION IS ADDED.

TEMPORARY PIPE SUPPORT:
SCREW A 3" NPT PIPE
AT LEAST 30" LONG INTO
LOWER RETURN TAPPING
IN THE REAR SECTION.




Figure 2.4: Install Additional Sections. Use level on each section as tie rod bolts are drawn up.




Figure 2.5: Series LC™ Boiler Assembly – Right Side View

16. To properly assemble LC™ sections in the field, the following steps *must* be followed to ensure that no damage occurs to the tie rod lugs. A 0-100 ft-lbs torque wrench is required.
 - a. Use a spirit level as shown in Figure 2.4 to check the alignment of the sections as the nuts are drawn up. Keep the sections plumb.
 - b. Draw the sections together evenly, in three rotations. Torque each port to 20 ft-lbs for the first rotation, then to 40 ft-lbs for the second rotation, then to 60 ft-lbs for the third rotation. Use the following sequence until all three ports touch metal-to-metal at 60 ft-lbs. See Figure 2.6 for port reference.
 - i) First: Lower Top Port
 - ii) Second: Bottom Port
 - iii) Third: Upper Top Port
 - c. Tighten these (3) three locations only to a torque value of 60 ft-lbs. DO NOT EXCEED.
 - d. After the three ports have been tightened to 60 ft-lbs, tighten the draw rod at the bumping pads until metal-to-metal contact is reached. This will assure a proper gas tight seal and prevent the products of combustion from migrating into the boiler room.

WARNING

Do not exceed the manufacturer's torque recommendations.




Figure 2.6: Torque Specification/Procedure

17. Repeat with the remaining sections.
 - a. Save the LWCO Intermediate with two 1" tappings (for level control) for use as the section closest to the front section.
 - b. Place the Intermediate Section with 3" top tapping (Tapped Intermediate) in the position given in Figure 2.7.

Table 2.1: Section Numbering Sequence

Model	Place a Tapped Intermediate Section at Position (Numbered Rear to Front)
LC-04	N/A
LC-05	N/A
LC-06	N/A
LC-07	N/A
LC-08	4
LC-09	5
LC-10	5
LC-11	6
LC-12	6

D. INSTALL COILS OR PLATES

1. Remove the coil cover plates, gaskets and mounting hardware, located in the Flue Box Carton.
2. Install tankless heaters, if used, in openings #1 and #2. See Figure 2.8 and Table 2.2.
3. Place the cover plates and gaskets over any unused heater openings. Place the cover plate with two 3/4" NPT tappings on the upper flow port opening (Position #2) of the Front Section.

E. HYDROSTATIC TEST THE BOILER

1. Install a drain valve in the Rear Section, Tapping 13. See Figure 8.2.
2. Provide a water supply line to the boiler.
3. Plug all open tappings in the boiler.
4. Provide a means to vent air as the boiler fills.
5. Fill the boiler with water, venting air as water level rises.
6. Pressurize boiler to:
 - 75 psig for 50 psig sections.
 - 120 psig for 80 psig sections.
 - **DO NOT EXCEED THESE PRESSURES.**

Maintain pressure while checking all joints and fittings for leaks.

7. After inspection is complete, drain the boiler and remove plugs from tappings that are to be used.

SERIES LC




Figure 2.7: Boiler Section Assembly Sequence

Table 2.2: Tankless Coil Ratings

Model	Heater No. X-1020			Heater No. X-1022			Two Heaters No. X-1020			Two Heaters No. X-1022		
	GPM	Press. Drop PSI	Location	GPM	Press. Drop PSI	Location	GPM	Press. Drop PSI	Location	GPM	Press. Drop PSI	Location
LC-04	5.5	11	2	—	—	—	8.0	6	1 & 2	—	—	—
LC-05R	5.62	11	2	—	—	—	9.0	8	1 & 2	—	—	—
LC-05	5.75	12	2	—	—	—	10.0	10	1 & 2	—	—	—
LC-06	6.25	14	2	—	—	—	12.0	13	1 & 2	—	—	—
LC-07	6.5	15	2	13.0	27	2	13.0	15	1 & 2	15.5	13	1 & 2
LC-08	7.0	16	2	13.75	30	2	14.0	16	1 & 2	18.0	15	1 & 2
LC-09	7.25	17	2	14.5	33	2	14.5	17	1 & 2	20.0	18	1 & 2
LC-10	7.5	18	2	15.5	38	2	15.0	18	1 & 2	22.5	21	1 & 2
LC-11	8.0	20	2	16.5	43	2	16.0	20	1 & 2	24.5	24	1 & 2
LC-12	—	—	—	17.5	48	2	—	—	—	27.0	29	1 & 2

Above heater ratings are based on intermittent demand for water from 40°F to 140°F with 200°F boiler water.

DANGER: Install mixing valve in hot water supply piping. Water temperature over 125°F can cause severe burns instantly or death from scalds.




Figure 2.8: Tankless Coil Openings

F. APPLY CLEANOUT COVER PLATES

1. Apply the Cleanout Cover Plates on the tops of the section joints as shown in Figure 2.9.
2. Pre-assemble a steel flat washer and steel nut on the carriage bolts. Place a carriage bolt into each side of the cleanout opening as shown in the figure.




Figure 2.9: Install Cleanout Cover Plates

3. Tighten the lower nut securely.
4. Press the Cleanout Plate with insulation over the protruding carriage bolts until the insulation lays flush against the cast iron.
5. Apply a flat washer and brass nut to the carriage bolt. Draw the brass nuts down until the insulation presses firmly against the iron.

G. INSTALL FLUE COLLAR

1. Remove the Flue Collar and Rear Observation Door Assembly from the LC™ Rear Flue Box Carton.
2. Attach the Flue Collar to the Back Section with 5/16" x 1-1/2" studs, flat washers and hex nuts supplied. See Figure 2.10.
3. Attach the Rear Observation Door to the Rear Section with four (4) 5/16"-18 x 3/4" hex head bolts provided.




Figure 2.10: Rear Flue Collar Attachment

H. INSTALL FLUE BAFFLES

1. Remove the Front Cleanout Plate from Front Section.
2. Open Baffles carton. Remove Baffles. Save Ceramic Fiber Liner for Section I. Save Rating Label for Chapter 4.
3. Place baffles as shown in Figure 2.11. Three of these are special stainless steel baffles, identified with a 1/4" hole punched in each end. These baffles must be placed in the lowest row of tubes.
4. Install the Front Cleanout Plate.




Figure 2.11: Flue Baffle Locations

3. PIPE THE BOILER

A. PREPARATION

1. Make sure the boiler has been pressure tested as outlined in "Place the Boiler Sections" in this manual.
2. The Supply and Return piping can be installed before installing the jacket. Use nipples long enough to extend through the jacket.
3. Install a pipe plug or nipple and cap in the 3" tapping in the top of the tapped intermediate section when necessary. Use only the lower side connection, required for return piping as shown.

B. SUPPLY & RETURN PIPING

1. Always locate the Supply and Return connections as shown in Figure 3.1 and other illustrations in this manual.
2. The suggested supply and return sizing in Table 3.1 and in the "Boiler Ratings and Dimensions" section in this manual is based on a flow rate through the boiler equivalent to a 20°F temperature rise (1 gpm flow for each 10,000 Btu/Hr of boiler output). Using higher flow rates is not recommended. This could cause poor water flow distribution in the boiler. Lower flow rates (higher temperature rise) are acceptable provided

the return temperature to the boiler is at least 130°F on gas boilers and 150°F on oil boilers to prevent condensation of flue gases.

3. Do not reduce the number or size of supply and return connections given in Table 3.1. These are required to control the flow velocities in the boiler and maintain uniform distribution.
4. When the boiler is connected to heating coils located in air handling units, the boiler piping system must be equipped with flow control valves or other automatic devices to prevent gravity circulation of the boiler water during the cooling cycle.

C. LOW SYSTEM TEMPERATURE

1. Low Return Temperature Piping, General

- a) When the return temperature from the system will be below 130°F on gas boilers or 150°F on oil boilers for extended periods (heat pump systems, outdoor reset, snow melt, etc.), provide piping and controls to protect the boiler from condensation. Condensation will damage the boiler and will lead to shortened boiler life and maintenance problems.

**BOILER HEADER:
PIPE WITH OFFSET
TO ALLOW FOR HEADER
EXPANSION. USE
THREADED FITTINGS
FOR SWING JOINTS.**




Figure 3.1: Piping Detail, Supply and Return Connections




Figure 3.2: Boiler Piping

Table 3.1: Boiler Supply and Return Connections & Recommended Header Sizing

Model	I=B=R Gross Output MBH	20°F Rise		Suggested Supply Connections – Top			Return Connections Rear and Side		
		GPM	Press. Drop (Feet)	Number	Size (Inches)	Header (Inches)	Number	Size (Inches)	Header (Inches)
LC-04	547	55	0.2	1	2-1/2	2-1/2	1	2-1/2	2-1/2
LC-05R	649	65	0.5	1	2-1/2	2-1/2	1	2-1/2	2-1/2
LC-05	707	71	0.5	1	2-1/2	2-1/2	1	2-1/2	2-1/2
LC-06	868	87	0.8	1	3	3	1	3	3
LC-07	1029	103	1.3	1	3	3	1	3	3
LC-08	1189	119	0.3	2	3	3	2	3	3
LC-09	1350	135	0.4	2	3	3	2	3	3
LC-10	1511	151	0.6	2	4	4	2	3	4
LC-11	1672	167	0.7	2	4	4	2	3	4
LC-12	1832	183	0.9	2	4	4	2	3	4

b) Temporary low temperature operation is acceptable within limits. For occasional cold start-ups condensation will occur, but will have limited effects. If the system is frequently allowed to cool to room temperature, such as on night set-back systems or energy management systems, cold start-ups will occur often. These systems require a Variable Low Temperature piping and control arrangement, described below.

2. Constant Low Temperature

For systems with a relatively constant low operating temperature (such as heat pump systems), you can pipe a fixed flow by-pass arrangement as shown in Figure 3.3. This piping will not work for variable low temperature systems such as outdoor reset systems or primary/secondary systems with a large primary circuit temperature drop. See Figure 3.4 for multiple boilers.

3. Variable Low Temperature

When the return water temperature from the system will vary (outdoor reset, snow melt, etc.) a fixed bypass will not work. Fixed bypass piping works by setting a high temperature rise through the boiler. As the system return temperature rises (during primary heating months, for example) the boiler will cycle on the limit control frequently, causing poor performance and excessive cycling. To protect the boiler and provide proper operation, install a temperature control valve and boiler circuit pump piped off of the system as a secondary loop. See Figure 3.6 for a single boiler and Figure 3.7 for multiple boilers.




Figure 3.3: Fixed By-Pass Piping, Single Boiler




Figure 3.4: Fixed By-Pass Piping, Multiple Boilers

D. CHILLED WATER SYSTEMS

If the boiler will be used in conjunction with a refrigeration system, the chilled medium must be placed in parallel with the boiler and proper valves applied to prevent the chilled medium from entering the boiler. See Figure 3.5.

E. HIGH FLOW RATE PIPING

For flow rates higher than given in Table 3.1, provide bypass piping around the boiler to limit the boiler flow to that given in the table or pipe the boiler in a secondary loop with its own pump as shown in Figure 3.3.

F. MULTIPLE BOILER INSTALLATIONS

1. For multiple boiler installations, piping the boilers in a secondary loop is recommended. Each boiler should be provided with its own pump and piped off of the secondary loop header. See Figure 3.7 for systems with return temperature above 130°F on gas boilers or 150°F on oil boilers. For low temperature systems, see Figure 3.4 (constant low temperature systems) or Figure 3.8 (variable low temperature systems).

2. You can use alternative piping if desired, such as parallel piping or series piping in the primary system loop. But these systems are less versatile.
 - a) With parallel piping, for instance, the system flow conditions change if one or more of the boiler shut-off valves are closed. It is difficult to pipe parallel boilers to protect the boiler from low return temperatures.
 - b) With series piping, temperature control to the system is difficult because the temperature rise equals the sum of the rises through each boiler. Series piped boilers cannot be isolated for servicing.






Figure 3.5: Piping to Isolate Boiler from Chilled Medium on Chiller Systems





- ① Boiler Loop Circulator
- ② Check Valve
- ③ System Pump
- ④ Air Separator
- ⑤ Expansion Tank
- ⑥ Mixing Valve, 150°F Set Point
- ⑦ Mixing Valve Temperature Sensor



PIPING FOR VARIABLE SYSTEM RETURN TEMP BELOW: 130°F FOR GAS; 150°F FOR OIL

Figure 3.6: Piping for Variable Low Temperature Systems, Single Boiler

FOR VARIABLE SYSTEM RETURN TEMP BELOW 130°F (150°F FOR OIL)




- ① Boiler Loop Circulator
- ② Check Valve
- ③ System Pump
- ④ Air Separator
- ⑤ Expansion Tank
- ⑥ Mixing Valve, 150°F Set Point
- ⑦ Mixing Valve Temperature Sensor

MULTIPLE BOILER PIPING, TYPICAL (PRIMARY/SECONDARY MEHTOD, LOW TEMP RETURN)

Figure 3.7: Multiple Boiler Piping, System Return Temperature Above 130°F on Gas, 150°F on Oil

**FOR SYSTEM
RETURN TEMP
ABOVE 130°F
(150°F FOR OIL)**



MULTIPLE BOILER PIPING, TYPICAL (PRIMARY/SECONDARY METHOD)




Figure 3.8: Piping for Variable Low Temperature Systems, Multiple Boilers

4. ASSEMBLE THE JACKET

A. PREPARE THE PARTS

1. Collect all the jacket cartons: **Jacket Front & Back Carton plus Jacket Side & Top Cartons**. See the Shipping List in the front of this manual for the jacket cartons required. The cartons contain the jacket parts and screws. The jacket panels are pre-insulated.
2. Remove all needed knockouts from the jacket parts before beginning assembly.

B. APPLY JACKET SIDES & CORNERS

1. See Figure 4.2 for details.
2. The Side Panels can be used on either side of the boiler.
3. Place the Jacket Side Panels on each side leaned against the Boiler Sections.
4. On Models LC-08 through LC-12, each side uses two panels. Place the panels so the seam is centered on the Tapped Intermediate Section.
5. On boilers with two or more Jacket Side Panels per side, join the panels together with #10 x 1/2" sheet metal screws. Also attach the Jacket Side Panel Reinforcing Angle inside the jacket at the bottom of the seam.
6. Attach the Left Front Corner Panel to the Left Side Panel with #10 x 1/2" sheet metal screws.
7. Attach the Right Front Corner Panel to the Right Side Panel with #10 x 1/2" sheet metal screws.

C. APPLY JACKET FRONT PANELS

1. Attach the Upper Front Panel to the Right and Left Front Corner Panels with #10 x 1/2" sheet metal screws.
2. Attach the Middle Front Panel and Lower Front Rail in the same manner.
3. Position the Jacket Assembly with the front panels pushed up against the front section. You will need the jacket in this position to install the Burner Front Plate.

D. APPLY JACKET REAR PANEL

Attach the Rear Jacket Panel to the Jacket Side Panels with #10 x 1/2" sheet metal screws.

E. APPLY JACKET TOP PANELS

1. Attach the Top Front Panel to the Sides and Upper Front Panel with #10 x 1/2" sheet metal screws.
2. Models LC-08 through LC-12 use two Jacket Top Panels. Place them on top with the seam at the same point as the side panels. Join them at their seam with #10 x 1/2" sheet metal screws.
3. Attach the Jacket Top Panel to the Jacket Top Front Panel with #10 x 1/2" sheet metal screws.
4. Attach the Top Rear Panel to the Jacket Top Panel with #10 x 1/2" sheet metal screws.
5. Finish by placing #10 x 1/2" sheet metal screws in the remaining holes along the Jacket Top Panel flanges, into the Jacket Side Panels.

F. APPLY LABELS

1. Attach labels to the Upper Jacket Front Panel as shown in Figure 4.1.




Figure 4.1: Attach Labels to Jacket Front Top Panel




Figure 4.2: Jacket Assembly

5. VENTING

Refer to Chapter 1, Preinstallation, Section D. Chimney or Vent for installation requirements. Refer to Chapter 9, Starting the Boiler, Section C. Run Burner Check Out for damper settings and draft requirements.

6. INSTALL THE BURNER

A. BURNER APPLICATION

1. Refer to Burner Spec and Data Sheets for the Oil and Gas/Oil Burners pre-tested with Series LC™ boilers.
2. Make sure the nozzle sizing and spray pattern match those given in the spec and data sheets.
3. See Figure 6.1 and Table 6.1 for combustion chamber dimensions.

B. INSTALL BURNER MOUNTING PLATE

1. The Burner Mounting Plate is made to fit the burner being used. Burners vary in bolt pattern for the flange, burner tube diameter, insertion length and near-tube configuration. Make sure the front plate is correct for your burner if purchased separately from the boiler.
2. Remove the Burner Mounting Plate and Hardware Bag from the crate.
3. Screw (7) 3/8"-16 x 2 1/4" studs into the holes in the front section around the chamber opening.
4. Secure the Burner Mounting Plate to the front section with the flat washers and hex nuts.

C. MOUNT THE BURNER

1. Remove the Burner from its crate. Read the burner instructions.
2. Insert (4) 3/8"-16 x 1 1/4" studs supplied with Burner Mounting Plate into the front plate holes.
3. Place the high temperature gasket on the burner front plate and secure the burner to the front plate with 3/8" flat washers and hex nuts.
4. If the burner is supplied with a pedestal, install it to the burner per the Burner Manufacturer's Instructions. The pedestal provides additional support and prevents the burner from sagging.




Figure 6.1: Combustion Chamber Layout – See Table 6.1 for Dimensions

Table 6.1: Combustion Chamber Dimensions

Model	Chamber Length "A" (Inches)	Burner Front Plate Extension Past Jacket (Inches)					
		Beckett Gas	Beckett Oil	Carlin	Gordon-Piatt	Power Flame	Webster
LC-04	18-7/8	1-1/8	6-1/8	6-1/8	6-1/8	6-1/8	6-1/8
LC-05R	23-15/16	1-1/8	6-1/8	6-1/8	1-1/8	6-1/8	6-1/8
LC-05	23-15/16	1-1/8	6-1/8	6-1/8	1-1/8	6-1/8	6-1/8
LC-06	29	1-1/8	6-1/8	6-1/8	1-1/8	6-1/8	6-1/8
LC-07	34-1/16	1-1/8	6-1/8	6-1/8	1-1/8	6-1/8	6-1/8
LC-08	39-1/8	1-1/8	1-1/8	6-1/8	1-1/8	1-1/8	1-1/8
LC-09	44-3/16	1-1/8	1-1/8	1-1/8	1-1/8	1-1/8	1-1/8
LC-10	49-1/4	1-1/8	1-1/8	1-1/8	1-1/8	1-1/8	1-1/8
LC-11	54-5/16	1-1/8	1-1/8	1-1/8	1-1/8	1-1/8	1-1/8
LC-12	59-3/8	1-1/8	1-1/8	1-1/8	1-1/8	1-1/8	1-1/8

7. CONNECT FUEL PIPING

A. GENERAL

1. Read the Burner Instruction Manual, supplied with the boiler or with the burner if purchased separately. Review applicable code requirements for burner and fuel piping installations.
2. Install piping to allow removal of burner and access to combustion chamber for cleaning or service.

B. INSTALL FUEL OIL PIPING

1. Place the fuel oil tank and install the piping in accordance with NFPA-31 and all other applicable codes.
2. General Guidelines for Oil Piping
 - a) Follow the guidelines in the Burner Manual for sizing oil lines. Never use smaller than 1/2" OD copper tubing.
 - b) Install manual shut-off valves on the suction line at the burner and at the oil line entrance to the building. If installing a shut-off valve on the return line, you must provide an oil pressure relief valve piped ahead of the shut-off valve and discharged to the tank to prevent over-pressure conditions.
 - c) Install a two-pipe oil distribution system when possible. It will improve the reliability of the oil delivery to the burner.
 - d) Use flare fittings when using copper tubing.
 - e) Provide an oil line filter in the suction line. Size the filter for the suction gear capacity of the burner oil pump if running a two-pipe system.
 - f) If burner is above the top of the fuel oil tank, install a check valve on the oil suction line at the burner to prevent oil from evacuating the line. If burner is below the top of the tank, install an anti-siphon device to prevent oil flow should the oil line break.

C. INSTALL GAS SUPPLY PIPING

1. Size the piping as required by the National Fuel Gas Code, ANSI Z223.1 or as required by local codes.
Use Table 7.1 for sizing of natural gas for a system pressure drop of 0.3 inch water column.
2. The standard gas train is designed for a maximum pressure of 1/2 psig (14 inches water column). Make sure the system regulator will not allow a higher pressure to the Gas Control Train under any conditions.
3. The minimum gas supply pressure is listed on the Burner Rating Plate. Make sure the system regulator and the piping are sized and adjusted properly to provide this pressure under all conditions.




Figure 7.1: Gas Supply Connection to Boiler

4. Install a Service Valve, Sediment Trap and Ground Joint Union at the supply connection to the Gas Control Train as shown in Figure 7.1. These are not supplied with the boiler. Install them in accordance with local codes.
5. Use only pipe joint compounds rated for use with Liquefied Petroleum Gases.

D. TEST GAS SUPPLY PIPING

1. ISOLATE THE BOILER GAS CONTROL TRAIN FROM THE SYSTEM DURING TEST:
 - a) Test pressure 1/2 psig or less – Close the Manual Shut-Off Valve on the Boiler Gas Control Train.
 - b) Test pressure over 1/2 psig – Disconnect the gas supply piping upstream of the Boiler Manual Shut-Off Valve.

WARNING

Do not expose the Gas Control Train to excessive pressure. The gas valves can be damaged. This could result in explosion hazard and severe personal injury or death.

Do not test gas supply piping with open flame. Use a soap suds mixture brushed onto the pipe joints to test for leaks.

Table 7.1: Capacity of Gas Supply Pipe in Cubic Feet Per Hour of Natural Gas for Pressure Drop of 0.3 inch Water Column.

Pipe Length (Feet)	1-1/4" Pipe	1-1/2" Pipe	2" Pipe	2-1/2" Pipe	3" Pipe	4" Pipe	6" Pipe
10	1050	1600	3050	4800	8500	17500	44000
20	730	1100	2100	3300	5900	12000	31000
30	590	890	1650	2700	4700	9700	25000
40	500	760	1450	2300	4100	8300	22000
50	440	670	1270	2000	3600	7400	20000
60	400	610	1150	1850	3250	6800	18000
70	350	560	1050	1700	3000	6200	17000
90	320	490	930	1500	2600	5400	15000
100	305	460	870	1400	2500	5100	14000
150	250	380	710	1130	2000	4100	11500

Above ratings based on natural gas with specific gravity of 0.60 allowing pressure drop of 0.3 inches water column. No allowance is needed for pipe fittings. Use the following multipliers on above capacities for specific gravity other than 0.60:

Specific Gravity	0.50	0.55	0.60	0.65	0.70
Multiply Capacity by:	1.10	1.04	1.00	0.962	0.926

8. INSTALL CONTROLS & TRIM

A. INSTALL SAFETY RELIEF VALVE

Pipe the Safety Relief Valve off of the 2-1/2" tapping at the upper left side of the Rear Section. Make sure the relief valve sizing meets local code requirements. See Figure 8.1.

CAUTION

Pipe the discharge of the Safety Relief Valve(s) away from any traffic area, preferably to a floor drain. This is necessary to prevent injury should the valve discharge.

Pipe the discharge full size of valve outlet.

B. INSTALL DRAIN VALVE

1. Install a 3/4" drain valve in the lower center tapping in the Rear Section. See Figure 8.1 and Figure 8.2.
2. Pipe the valve discharge to a floor drain if available or apply a nipple and cap to close off when not in use.

C. INSTALL LOW WATER CUTOFFS

See Figure 8.2 for the locations of tappings for probe type and float type low water cutoffs. The Front Section has a 3/4" tapping for a probe type control. The Rear Section has two 1" tappings for mounting a float type control.

D. INSTALL CONTROLS & TRIM

1. Install the Temperature-Pressure Gage in the 1/2" tapping at the upper center of the Front Section. See Figure 8.2.
2. Mount the Operating Temperature Limit Control bulb well in the Coil Cover Plate at the upper right of the Front Section. Place the well in the right side 3/4" control tapping of the cover plate if a Tankless Heater is not installed there. If a tankless heater is installed at this location (Position 2), mount the well in the center 3/4" control tapping of the coil. See Figure 8.2.




Figure 8.1: Safety Relief Valve Piping

3. Mount the High Limit Control bulb well in the left side 3/4" tapping of the coil cover plate if a tankless heater is not mounted in the upper right opening (Position 2). If a coil is installed there, mount the well in the 3/4" tapping to the left of the opening. See Figure 8.2.

CAUTION

Make sure that the gas ignition system components, electrical controls, junction boxes and electrical panels are protected from water (dripping, spraying, rain, etc.) during boiler operation and service (circulator or pump servicing, control replacements or other).

E. PIPE TANKLESS HEATERS IF USED

Connect piping to any installed tankless heaters. See Figure 8.3 for suggested piping for single coils and Figure 8.4 for suggested piping for dual coils.

F. CONNECT SUPPLY WIRING

1. Install all wiring in accordance with local codes, the National Electrical Code and other controlling agencies or governing bodies.
2. Use #14 gauge or heavier wire for supply wiring. Protect the circuit with a fused disconnect switch (by others).


CAUTION

The boiler/burner must be electrically grounded in accordance with the requirements of the authority having jurisdiction, or in the absence of such requirements, with the current edition of the National Electrical Code, ANSI/NFPA Number 70.

3. Follow the instructions in the Burner Manual and the Wiring Diagrams supplied with the burner and the boiler.


G. INSTALL CONTROL WIRING

1. Wire the boiler according to the wiring diagrams supplied with the burner and the boiler (in the Boiler Envelope).
2. Low Energy Safety Control wiring, if used, must follow the contour of the boiler. Some local codes may require that all wiring, even low voltage, be routed in conduit.
3. Install line voltage wiring in conduit.
4. Do not install single pole switches, including safety controls, in a grounded line.



1	4" NPT Supply Tapping, Front Section	9	Alternate High Temp Limit Location Tapping, 3/4" NPT
2	4" NPT Supply Tapping, Rear Section	10	Not Used On Water, 3/4" NPT Tapping - Plug
3	3" NPT Return Tapping, Rear Section	11 12	Float LWCO Tapping, 1" NPT
4	Pressure/Temp Gauge Tapping, 1/2" NPT	13	Drain Tapping, 3/4" NPT
5	Not Used On Water, 1/2" NPT Tapping - Plug	14	Not Shown - 1" NPT Tapping in Side and Top of First Intermediate - for Float LWCO
6	Tankless Coil Temp Control Tapping, 3/4" NPT, Not Used On Water - Plug	15	Control Tapping, (2) 3/4" NPT - Both Limits in Special Tapped Plate if no Tankless Coil in opening. Operating Limit Control here if Coil installed.
7	Relief Valve Tapping, 2-1/2" NPT	16	Tankless Coil Temp Control Tapping, 3/4" NPT, Only with Optional Tankless Coil Rear Section
8	Probe LWCO Tapping, 3/4" NPT	17	Inspection Tappings, Optional

Figure 8.2: Control and Pipe Tapping Locations



⚠ DANGER

Provide anti-scald devices in the system where needed.

Failure to control water temperature to showers or other usage areas where a scald risk exists can result in severe personal injury.

Figure 8.3: Suggested Piping – Single Tankless Coil Installation




Figure 8.4: Suggested Piping – Dual Tankless Coil Installation

9. STARTING THE BOILER

A. CHECK THE PIPING

1. Water Piping
 - a) The Boiler must have been hydrostatically tested.
 - b) Check the attached piping for joint tightness.
 - c) Continue monitoring as you proceed through start up.
2. Gas Piping
 - a) Make sure the gas system piping and the connections to the boiler Gas Control Train(s) have been leak tested.
 - b) After the boiler is in operation, check the tightness of all joints in the boiler gas piping with a soap suds solution.
 - c) Purge the gas piping of all air up to the boiler Gas Control Train.
3. Oil Piping
 - a) Check the oil piping visually. Make sure all joints are tight.
 - b) When the burner is firing, check the suction line and return line pressures.
 - c) If the pressure exceeds the allowable pressure in the Burner Manual or if the suction line vacuum is higher than allowable, correct the piping as needed to bring the suction line and return line pressures within acceptable range.
 - d) Excess pressure can cause pump seal failures. Excess vacuum will cause fuel flow problems with the burner oil pump.

B. FILL THE BOILER

1. Fill the boiler and system.
 - a) See Section 1 - Preinstallation, for boiler water treatment requirements.

CAUTION

Check the system for leaks and make sure the automatic fill valve (if used) and the expansion tank are operating correctly. Leakage or weeping of the relief valve will cause make-up water to be added to the system. Excessive make-up water will damage the boiler and system components due to liming and oxygen corrosion.

- b) If the system requires antifreeze, use only antifreeze designed for hydronic systems. These contain inhibitors to prevent corrosion of the boiler and system components. Do not use ethylene glycol or automotive antifreezes.
 - Make sure the antifreeze supplier can provide periodic inhibitor check service.

- If automatic fill is used, the system will have to be checked periodically to make sure the antifreeze concentration has not been diluted below design level.
- Local codes may require the use of a backflow preventer or manual fill only with separation from the city supply.
- Consider the minimum temperature of potential exposure for the system when deciding on the antifreeze concentration. A concentration of 50% generally provides protection from freezing down to -30°F.

CAUTION

The boiler gaskets will be damaged by petroleum or its derivatives.

Do not use petroleum based compounds in the boiler, including petroleum-based stop-leak compounds.

2. Purge the air from the system.

C. RUN BURNER CHECK-OUT

1. Before firing the burner, slide the Slide Gate Damper on the rear flue box all the way down (full open).
2. Follow the instructions in the Burner Manual for starting the burner, adjusting air openings and fuel rates. Perform ignition system and flame supervisory control test and checkout as described in the manual.
3. After burner is set at rate, close the damper until the pressure reading at the test opening in the rear flue box or draft damper is between 0" wc and 0.1" wc positive. See Table 9.1 for typical overfire pressure (measured at the burner front plate) and boiler draft loss.

When a barometric draft regulator is installed in the venting system, adjust the boiler damper for 0" wc pressure reading at the damper. Adjust the draft regulator for -0.05" wc draft between the boiler damper and the draft regulator.

CAUTION

On installations with high draft, do not leave the boiler with a negative draft reading at the rear flue box or draft damper. High negative draft can pull the flame up into the boiler crown sheet and overheat the iron. This can result in cracked sections or shortened boiler life.

4. Adjust the burner as needed for a CO₂ reading of:
 - a) Oil burners: CO₂ approximately 12.5% or 1% less than the level at which the smoke reading goes above a trace on the Bacharach scale.
 - b) Gas burners: 9% to 10% with CO less than 50 ppm.
 - c) Inspect all flue gas joints (sections, attachments, breeching and vent) for gas tightness. Remove the jacket panels in order to thoroughly inspect all rope seal joints between the sections.
- a) Test probe type controls by using the Push-to-Test Button.
- b) Test float type controls. ASME CSD-1 requires the control to be piped with Test-n-Check valves in order to allow isolation for test.
3. Follow additional instructions in the Burner Manual for proving the burner component operation.
4. Check all controls to make sure they function correctly.
5. After all controls have been proven, set the Operating and High Limit Temperature Controls to the temperatures desired.

D. CHECK BOILER CONTROLS

1. Limit and Operating Temperature Controls
Lower the setting of each control until the burner shuts down.
2. Low Water Cutoffs

Table 9.1: Typical Combustion Chamber Pressure and Boiler Draft Loss

Model	Combustion Chamber Pressure with 0.1" w.c. at Rear Flue Box Test Port (Inches w.c.)	Boiler Draft Loss (Inches w.c.)
LC-04	+ 0.22	0.12
LC-05R	+ 0.22	0.12
LC-05	+ 0.24	0.14
LC-06	+ 0.26	0.16
LC-07	+ 0.27	0.17
LC-08	+ 0.28	0.18
LC-09	+ 0.29	0.19
LC-10	+ 0.30	0.20
LC-11	+ 0.31	0.21
LC-12	+ 0.32	0.22

NOTE: Actual chamber pressure and draft loss readings may vary with each boiler and installation due to variation in the heat exchanger, deposits in the flueways, actual burner firing rate and excess air conditions. Use the above numbers as a general guide only. If the measured draft loss is considerably higher than the above, check the flueways for deposits and confirm the burner firing rate.

10. MAINTENANCE

WARNING

Product Safety Information Refractory Ceramic Fiber Product

This appliance contains materials made from refractory ceramic fibers (RCF). Airborne RCF, when inhaled, have been classified by the International Agency for Research on Cancer (IARC), as a possible carcinogen to humans. After the RCF materials have been exposed to temperatures above 1800°F (982°C), they can change into crystalline silica, which has been classified by the IARC as carcinogenic to humans. If particles become airborne during service or repair, inhalation of these particles may be hazardous to your health.

Avoid Breathing Fiber Particulates and Dust

Suppliers of RCF recommend the following precautions be taken when handling these materials:

Precautionary Measures:

Provide adequate ventilation.

Wear a NIOSH/MSHA approved respirator.

Wear long sleeved, loose fitting clothing and gloves to prevent skin contact.

Wear eye goggles.

Minimize airborne dust prior to handling and removal by water misting the material and avoiding unnecessary disturbance of materials.

Wash work clothes separately from others. Rinse washer thoroughly after use.

Discard RCF materials by sealing in an airtight plastic bag.

First Aid Procedures:

Inhalation: If breathing difficulty or irritation occurs, move to a location with fresh clean air. Seek immediate medical attention if symptoms persist.

Skin Contact: Wash affected area gently with a mild soap and warm water. Seek immediate medical attention if irritation persists.

Eye Contact: Flush eyes with water for 15 minutes while holding eyelids apart. Do not rub eyes. Seek immediate medical attention if irritation persists.

Ingestion: Drink 1 to 2 glasses of water. Do not induce vomiting. Seek immediate medical attention.

WARNING

Do not store or allow combustible or flammable materials near the boiler. Substantial fire or explosion hazard could result, causing risk of personal injury, death or property damage.

Do not use this boiler if any part of it has been under water. Immediately call a qualified service technician to inspect the boiler. Any part of the control system, any gas control or any burner or gas component which has been under water must be replaced.

Should overheating occur or the fuel supply fail to shut off: Shut off the fuel supply at a location external to the boiler. Do not turn off or disconnect the electrical supply to the pump. Immediately call a qualified service technician to inspect the boiler for damage and defective components.

A. PLACING BOILER IN OPERATION

1. Start up the Burner/Boiler per the Burner Manual and the instructions in this manual on starting the boiler.
2. Prove the correct operation of all controls on the boiler and burner as outlined below.
3. Check the operation of the ignition and flame proving controls as described in the Burner Manual.
4. Test the limit and operating controls to assure they are operating correctly.
5. Inspect and test all low water cutoffs.
6. Test the safety relief valve(s) using the procedure given by the valve manufacturer on the valve tag.
7. Visually inspect the burner and pilot flames (if applicable).

B. TO SHUT DOWN THE BOILER

1. Turn off Burner.
2. Open main line power disconnect switch to boiler/burner.
3. Close fuel shut-off valves.
4. To take boiler out of service if the boiler and system are not to be used when temperatures are below freezing:
 - a) Drain the boiler and system completely and shut off make-up water supply.
 - b) Open main line power disconnect switch to boiler/burner. Remove the fuses or secure the switch so that the power cannot be turned on accidentally.
 - c) Be certain that the boiler and system are refilled before returning to service. Follow the Instructions in this manual and the Lighting Instructions to operate.

- d) The system may be filled with a 50% inhibited propylene glycol solution for protection down to -35°F. Use only antifreeze solutions specifically designed for hydronic use.

C. GENERAL

If there is considerable foreign matter in the boiler water, the boiler should be shut down and allowed to cool, then drained and thoroughly flushed out. Drain the boiler at the drain cock. Pipe the drain cock to a suitable drain or containment device (if antifreeze is used). Flush the system to remove remaining matter. See Section 1 - Preinstallation, for boiler water treatment requirements. If there is evidence that hard scale has formed on the internal surfaces, the boiler should be cleaned by chemical means as prescribed by a qualified water treatment specialist.

D. MAINTENANCE – ANNUAL

1. **Before the start of each heating season**, inspect and make all necessary adjustments to insure proper boiler and burner operation. Use the maintenance and inspection procedures following.
2. Inspect the Venting System
 - a) Check the chimney or vent to make sure it is clean and free from cracks or potential leaks.
 - b) All joints must be tight and sealed.
 - c) The vent connector must extend into, but not beyond the inside edge of the chimney or vent.

CAUTION

Before servicing the boiler:

- **Turn off all electrical power to the boiler.**
- **Close the Gas Service Valve and Oil Shut-Off Valve.**
- **Allow the boiler to cool if it has been operating.**
- **Label all wires prior to disconnection when servicing controls. Wiring errors can cause improper and dangerous operation. Verify proper operation after servicing.**

3. Inspect the Boiler Area
 - a) The boiler area must be clean and free from combustible materials, gasoline or any other flammable liquids or vapors.
 - b) The combustion air openings and the area around the boiler must be unobstructed.
4. Inspect boiler flueways and burner for cleanliness. If cleaning is required, use the following procedure.
 - a) Turn off all electrical power to the boiler.

- b) Remove Jacket Middle Front Panel and Jacket Top Panels. Remove Front Cleanout Plate and Cleanout Cover Plates on each flueway.
 - c) Brush the boiler tube spaces both horizontally (through cleanout openings on ends) and vertically (from top of boiler through cleanout openings at flueways).
 - d) Remove the Burner and Burner Mounting Plate. Remove any scale or soot from the combustion chamber by means of vacuum cleaning or other available means. Take care not to damage the chamber floor liner or target wall liner.
 - e) Replace the Front Cleanout Plate, Burner Mounting Plate, Burner and all Cleanout Cover Plates on top of the sections. Make sure all sealing rope and seals are in good condition. Replace sealing rope if necessary.
 - f) Replace all Jacket Panels.
5. Inspect the boiler and piping for signs of leaks. Check to see if there are signs of heavy make-up water addition to the system.
 6. When placing boiler into operation, follow Burner Manual, all instructions supplied with the boiler and the instructions in this chapter.
 7. Test the operation of all limit controls, float controls and ignition components as described in Part A, "Placing Boiler in Operation", of this chapter.

E. MONTHLY MAINTENANCE

1. Inspect the burner and pilot flames as for the annual inspection.
2. Inspect the boiler and system for any signs of leakage or excessive make-up water usage.
3. Inspect and check the operation of the venting system.

F. DAILY MAINTENANCE

1. Inspect the boiler area to make sure the area is free from combustible or flammable materials and that there are not obstructions to the flow of air to the boiler or combustion air openings to the room.
2. Make sure there are no signs of abnormal operation, such as overfilling or leakage.


CAUTION

Be very careful when adding water to a hot boiler. Add very slowly or, if possible, allow the boiler to cool naturally before adding water.

If an excessive loss of water occurs, check for a leak in the piping and correct the problem. Excessive make-up water will cause corrosion and damage to the boiler.

11. BOILER RATINGS & DIMENSIONS

Table 11.1: Series LC™ Boiler Ratings

Series LC™												Boiler H.P.
Boiler Model	Oil Input ¹		Gas Input, MBH	Gross Output, MBH	Net Ratings ⁴			Oil		Gas		
	GPH	MBH			Steam, sqft	Water ² , MBH	Steam ³ , MBH	Combustion Efficiency ⁵ , %	Thermal Efficiency ⁵ , %	Combustion Efficiency ⁵ , %	Thermal Efficiency ⁵ , %	
LC-04-S	4.75	665	686	547	1,708	—	410	83.7	82.2	81.2	79.8	16.3
LC-04-W	4.75	665	686	547	—	476	—	84.2	82.9	81.6	80.4	16.3
LC-05R	5.60	784	808	649	2,029	564	487	83.7	82.8	81.2	80.3	19.4
LC-05	6.10	854	881	707	2,208	615	530	83.7	82.8	81.2	80.3	21.1
LC-06	7.50	1,050	1,077	868	2,713	755	651	83.7	83.1	81.1	80.6	25.9
LC-07	8.80	1,232	1,273	1,029	3,217	895	772	83.6	83.3	81.1	80.8	30.7
LC-08	10.20	1,428	1,469	1,189	3,717	1,034	892	83.6	83.5	81.1	81.0	35.5
LC-09	11.60	1,624	1,664	1,350	4,250	1,174	1,020	83.6	83.6	81.1	81.1	40.3
LC-10	12.80	1,792	1,860	1,511	4,804	1,314	1,153	83.6	83.7	81.1	81.2	45.1
LC-11	14.20	1,988	2,056	1,672	5,367	1,454	1,288	83.6	83.8	81.1	81.3	50.0
LC-12	15.60	2,184	2,252	1,832	5,917	1,593	1,420	83.6	83.9	81.1	81.4	54.7

1 Burner input based on No. 2 fuel oil with a heating value of 140,000 Btu per gallon.

2 Net water ratings based on an allowance of 1.15.

3 Net steam ratings based on an allowance for LC-04 to LC-08=1.333, LC-09=1.323, LC-10=1.310, LC-11=1.298, LC-12=1.290.

4 Consult factory before selecting a boiler for installations having unusual piping and pickup requirements, such as intermittent system operation, extensive piping systems, etc.

5 Combustion and thermal efficiencies are determined in accordance with ANSI/AHRI Standard 1500.

BOILER RATINGS & DIMENSIONS




Figure 11.1: Series LC™ Dimensional Diagram

Table 11.2: Series LC™ Boiler Dimensions

SERIES LC™ BOILER DIMENSIONS							
Boiler Model Number	Jacket			Flue Size “D”	Distance Between Tappings		
	Depth “A”	Width “B”	Height “C”		“E”	Water	Steam
						“E1”	“E1”
LC-04	25-15/16”	37”	63”	9”	16-1/2”	N/A	N/A
LC-05R	31”	37”	63”	9”	21-9/16”	N/A	N/A
LC-05	31”	37”	63”	9”	21-9/16”	N/A	N/A
LC-06	36-1/16”	37”	63”	10”	26-5/8”	N/A	N/A
LC-07	41-1/8”	37”	63”	10”	31-11/16”	N/A	N/A
LC-08	46-5/16”	37”	63”	10”	36-13/16”	15-13/16”	N/A
LC-09	51-3/8”	37”	63”	12”	41-7/8”	20-15/16”	N/A
LC-10	56-7/16”	37”	63”	12”	46-15/16”	20-15/16”	N/A
LC-11	61-1/2”	37”	63”	12”	52”	26”	26”
LC-12	66-9/16”	37”	63”	12”	57-1/8”	26”	26”

This page intentionally left blank.

12. REPAIR PARTS

Repair parts are available from your local PB Heat, LLC distributor or from Parts To Your Door at 1 (610) 916-5380 (www.partstoyourdoor.com).

Note: Remember to include boiler model number and serial number when ordering parts.




Figure 12.1: Series LC™ Boiler Assembly

Table 12.1

	Description	Quantity Required	Stock Code
1	Front Section #50	—	86000
2	Intermediate Section w/ 1" Tapping #50	—	86005
3	Intermediate Section Plain #50	—	86004
4	Back Section #50	—	86022
5	3" Tapped Intermediate Section #50	—	86008
—	Intermediate Section w/ (2) 1-1/2" Inspection Tappings #50	—	86014
—	Tankless Back Section	—	86036
—	Top Outlet Intermediate Section	—	86000
—	Upper Flow Port Gasket	2	51671
—	Lower Flow Port Gasket	1	51672
6	Tie Rod	4	51721
—	5/8" Diameter High Temp Rope (13' required per flueway)	—	55723
7	Ceramic Fiber Base Liner – Models LC-04 thru LC-12	—	50862
8	Ceramic Fiber Target Wall	—	50854
9	Front Cleanout Plate (C.I.)	—	51162
—	Observation Glass	—	51681
—	Observation Gasket	—	90091
11	Steel Cover Plate w/ Gasket & Screws	—	91477
12	Steel Cover Plate	—	51777
13	Tankless Heater Location 1 (specify heater model number)	—	—
14	Tankless Heater Location 2	—	—
15	Tankless Heater Location 3 (specify heater model number)	—	—
16	Rubber Gasket (specify qty.)	—	51800
18	Rear Observation Assembly	—	90923
20	Burner Mounting Plate (see charts)	—	—
—	Combustion Cover Plate Insulation	—	50798
—	Hardware Mounting Kit	—	90964
22	Flame Observation Assembly	—	90922
25	Cleanout Cover Plate (Steel)	1	51772
—	Cleanout Cover Plate Insulation	—	50800
26	Rear Flue Box w/ 9" Flue Outlet – Models LC-04, LC-05	—	86040
	Rear Flue Box w/ 10" Flue Outlet – Models LC-06 thru LC-08	—	86041
	Rear Flue Box w/ 12" Flue Outlet – Models LC-09 thru LC-12	—	86042
	Rear Flue Box w/ 14" Flue Outlet	—	86043
	Rear Flue Box w/ 16" Flue Outlet	—	86044
28	Rear Flue Box Hi Temp Rope, 1/4" Diameter x 65" Long	—	51209
29	Side Jacket Panel – LC-6000 – Models LC-04, LC-08	—	—
	Side Jacket Panel – LC-6001 – Models LC-05, LC-08 thru LC-10	—	—
	Side Jacket Panel – LC-6002 – Models LC-06, LC-10 thru LC-12	—	—
	Side Jacket Panel – LC-6003 – Models LC-07, LC-12	—	—
—	Silicone Sealer (3 oz.)	—	7605
30	Left Front Jacket Corner Panel – LC-6011	—	—

	Description	Quantity Required	Stock Code
31	Right Front Jacket Corner Panel – LC-6010	—	—
32	Upper Front Jacket Panel – LC-6007	—	—
33	Middle Front Jacket Panel – LC-6008	—	—
34	Lower Front Jacket Rail – LC-6009	—	—
35	Back Jacket Panel – LC-6012	—	—
36	Side Jacket Panel Support Angle – LC-6014	—	—
37	Front Top Jacket Panel – LC-6005	—	—
38	Top Jacket Panel – LC-6004 – Models LC-04, LC-08	—	—
	Top Jacket Panel – LC-6004-1 – Models LC-05, LC-08 thru LC-10	—	—
	Top Jacket Panel – LC-6004-2 – Models LC-06, LC-10 thru LC-12	—	—
	Top Jacket Panel – LC-6004-3 – Models LC-07, LC-12	—	—
39	Rear Top Jacket Panel – LC-6006	—	—
Assembly Kit			
—	A	—	86050
—	B	—	86051
—	C	—	86052
—	D	—	86053
Flue Baffles			
	LC1023 – LC-04	—	LC1023
	LC1023-1 – LC-05	—	LC1023-1
	LC1023-2 – LC-06	—	LC1023-2
	LC1023-3 – LC-07	—	LC1023-3
	LC1023-4 – LC-08	—	LC1023-4
	LC1023-5 – LC-09	—	LC1023-5
	LC1023-6 – LC-10	—	LC1023-6
	LC1023-7 – LC-11	—	LC1023-7
	LC1023-8 – LC-12	—	LC1023-8
Channel Rails			
—	LC-1030 – LC-04	—	90160
—	LC-1030-1 – LC-05	—	90161
—	LC-1030-2 – LC-06	—	90162
—	LC-1030-3 – LC-07	—	90163
—	LC-1030-4 – LC-08	—	90164
—	LC-1030-5 – LC-09	—	90165
—	LC-1030-6 – LC-10	—	90166
—	LC-1030-7 – LC-11	—	90167
—	LC-1030-8 – LC-12	—	90168
Trim			
—	A – LC-1006	—	87030
—	B – LC-1006-1	—	87031
—	C – LC-1006-2	—	87032
Controls			
—	LC-1075	—	88510

13. STARTUP & SERVICE REPORT

Job _____

Date _____ Serial No. _____

Boiler Model No. _____ Burner Operation _____

Burner Type _____ Mfr. _____ No. _____

Combustion Test Results:

Gas Type	Input (cfh)	Gas Pressure		CO ₂ %	CO %	Stack Press. " w.c.	Temp. °F		Flame Signal		Air Settings	
		Orifice " w.c.	Supply " w.c.				Stack (Gross)	Room	Pilot	Main	Total (In.)	Primary %
High Fire												
Low Fire												

Oil	Input (gph)	Oil Pressure		CO ₂ %	Smoke No.	Stack Press. " w.c.	Temp. °F		Flame Signal		Air Settings	
		Supply psig	Bypass psig				Stack (Gross)	Room	Pilot	Main	Total (In.)	Primary %
High Fire												
Low Fire												

Check of Safety Controls

Low Water Cutoff _____ High Gas Press. _____ Setting _____ " w.c. _____

Pilot Failure _____ Low Gas Press. _____ Setting _____ " w.c. _____

Main Flame Failure _____

Limit Control Settings

High Limit _____ Operating Cont. _____ Mod. Cont. _____ Hi-Lo Cont. _____

Oil Nozzle — _____ gph _____ Angle Spray _____ Type _____ Make _____

Remarks: _____

Startup By: _____ Accepted By: _____

Copies of Report to: _____

Series LC™

Oil, Gas & Gas/Oil Boilers Water

Installation, Operation & Maintenance Manual

TO THE INSTALLER:

This manual is the property of the owner and must be affixed near the boiler for future reference.

TO THE OWNER:

This boiler should be inspected annually by a Qualified Service Agency.



PeerlessBoilers.com

PB HEAT, LLC

131 S. CHURCH STREET • BALLY, PA 19503

Mixed Sources
Product group from well-managed
forests and recycled wood or fibre

Cert no. SCS-COC-001363
www.fsc.org
© 1996 Forest Stewardship Council