PEERLESS[®] PureFire[®] REV2

Gas Boilers

PF-50 PF-80 PF-110 PF-140 PF-200 PF-210 PF-300 PF-399



Installation, Operation & Maintenance Manual



PeerlessBoilers.com

TABLE OF CONTENTS

	USING THIS MANUAL 1	
	A. INSTALLATION SEQUENCE1	
	B. SPECIAL ATTENTION BOXES1	
1.	PREINSTALLATION 2	
	A. GENERAL	
	B. CODES & REGULATIONS2	
	C. ACCESSIBILITY CLEARANCES	
	D. COMBUSTION & VENTILATION AIR4	
	E. PLANNING THE LAYOUT	
2.	BOILER SET-UP 8	
	A. GENERAL	
	B. WALL MOUNTING	
	C. FLOOR STANDING INSTALLATION	
3.	VENTING & AIR INLET PIPING 9	
•.	A. GENERAL	
	B. APPROVED MATERIALS	
	C. EXHAUST VENT/AIR INTAKE	
	PIPE LOCATION	
	D. EXHAUST VENT/AIR INTAKE PIPE SIZING 14	
	E. EXHAUST VENT/AIR INTAKE PIPE	
	INSTALLATION14	
	F. EXHAUST TAPPING FOR VENT SAMPLE15	
	G. BOILER REMOVAL FROM COMMON	
	VENTING SYSTEM15	
_		
4.	WATER PIPING & CONTROLS 17	
4.	A. GENERAL	
4.	A. GENERAL.17B. WATER QUALITY.17C. OPERATING PARAMETERS18D. SYSTEM COMPONENTS18E. SYSTEM PIPING22	
4.	A. GENERAL.17B. WATER QUALITY.17C. OPERATING PARAMETERS18D. SYSTEM COMPONENTS18E. SYSTEM PIPING22F. FREEZE PROTECTION22	
	A. GENERAL.17B. WATER QUALITY.17C. OPERATING PARAMETERS18D. SYSTEM COMPONENTS18E. SYSTEM PIPING22F. FREEZE PROTECTION22G. SPECIAL APPLICATIONS29	
	A. GENERAL.17B. WATER QUALITY.17C. OPERATING PARAMETERS18D. SYSTEM COMPONENTS18E. SYSTEM PIPING22F. FREEZE PROTECTION22G. SPECIAL APPLICATIONS29FUEL PIPING30	
	A. GENERAL. 17 B. WATER QUALITY. 17 C. OPERATING PARAMETERS 18 D. SYSTEM COMPONENTS 18 E. SYSTEM PIPING 22 F. FREEZE PROTECTION 22 G. SPECIAL APPLICATIONS 29 FUEL PIPING 30 A. GENERAL 30	
	A. GENERAL. 17 B. WATER QUALITY. 17 C. OPERATING PARAMETERS 18 D. SYSTEM COMPONENTS 18 E. SYSTEM PIPING 22 F. FREEZE PROTECTION 22 G. SPECIAL APPLICATIONS 29 FUEL PIPING 30 A. GENERAL 30 B. FUEL LINE SIZING 30	
	A. GENERAL. 17 B. WATER QUALITY. 17 C. OPERATING PARAMETERS 18 D. SYSTEM COMPONENTS 18 E. SYSTEM PIPING 22 F. FREEZE PROTECTION 22 G. SPECIAL APPLICATIONS 29 FUEL PIPING 30 A. GENERAL 30 B. FUEL LINE SIZING 30 C. GAS SUPPLY PIPING – INSTALLATION 30	
	A. GENERAL. 17 B. WATER QUALITY. 17 C. OPERATING PARAMETERS 18 D. SYSTEM COMPONENTS 18 E. SYSTEM PIPING 22 F. FREEZE PROTECTION 22 G. SPECIAL APPLICATIONS 29 FUEL PIPING 30 A. GENERAL. 30 B. FUEL LINE SIZING 30 C. GAS SUPPLY PIPING – INSTALLATION 31	
5.	A. GENERAL. 17 B. WATER QUALITY. 17 C. OPERATING PARAMETERS 18 D. SYSTEM COMPONENTS 18 E. SYSTEM PIPING 22 F. FREEZE PROTECTION 22 G. SPECIAL APPLICATIONS 29 FUEL PIPING 30 A. GENERAL 30 B. FUEL LINE SIZING 30 C. GAS SUPPLY PIPING – INSTALLATION 30 D. GAS SUPPLY PIPING – OPERATION 31 E. MAIN GAS VALVE – OPERATION 32	
	A. GENERAL.17B. WATER QUALITY.17C. OPERATING PARAMETERS18D. SYSTEM COMPONENTS18E. SYSTEM PIPING22F. FREEZE PROTECTION22G. SPECIAL APPLICATIONS29FUEL PIPING30A. GENERAL.30B. FUEL LINE SIZING30C. GAS SUPPLY PIPING – INSTALLATION31E. MAIN GAS VALVE – OPERATION32CONDENSATE DRAIN PIPING33	
5.	A. GENERAL. 17 B. WATER QUALITY. 17 C. OPERATING PARAMETERS 18 D. SYSTEM COMPONENTS 18 E. SYSTEM PIPING 22 F. FREEZE PROTECTION 22 G. SPECIAL APPLICATIONS 29 FUEL PIPING 30 A. GENERAL 30 B. FUEL LINE SIZING 30 C. GAS SUPPLY PIPING – INSTALLATION 30 D. GAS SUPPLY PIPING – OPERATION 31 E. MAIN GAS VALVE – OPERATION 32 CONDENSATE DRAIN PIPING 33 A. GENERAL 33	
5.	A. GENERAL. 17 B. WATER QUALITY. 17 C. OPERATING PARAMETERS 18 D. SYSTEM COMPONENTS 18 E. SYSTEM PIPING 22 F. FREEZE PROTECTION 22 G. SPECIAL APPLICATIONS 29 FUEL PIPING 30 A. GENERAL. 30 B. FUEL LINE SIZING 30 C. GAS SUPPLY PIPING – INSTALLATION 30 D. GAS SUPPLY PIPING – OPERATION 31 E. MAIN GAS VALVE – OPERATION 32 CONDENSATE DRAIN PIPING 33 A. GENERAL 33 B. CONDENSATE SYSTEM 33	
5.	A. GENERAL. 17 B. WATER QUALITY. 17 C. OPERATING PARAMETERS 18 D. SYSTEM COMPONENTS 18 E. SYSTEM PIPING 22 F. FREEZE PROTECTION 22 G. SPECIAL APPLICATIONS 29 FUEL PIPING 30 A. GENERAL. 30 B. FUEL LINE SIZING 30 C. GAS SUPPLY PIPING – INSTALLATION 31 E. MAIN GAS VALVE – OPERATION 32 CONDENSATE DRAIN PIPING 33 A. GENERAL. 33 B. CONDENSATE SYSTEM 33 C. CONDENSATE DRAIN PIPE MATERIAL. 34	
5.	A. GENERAL.17B. WATER QUALITY.17C. OPERATING PARAMETERS18D. SYSTEM COMPONENTS18E. SYSTEM PIPING22F. FREEZE PROTECTION22G. SPECIAL APPLICATIONS29FUEL PIPING30A. GENERAL30B. FUEL LINE SIZING30C. GAS SUPPLY PIPING – INSTALLATION30D. GAS SUPPLY PIPING – OPERATION31E. MAIN GAS VALVE – OPERATION32CONDENSATE DRAIN PIPING33A. GENERAL33B. CONDENSATE DRAIN PIPE MATERIAL34D. CONDENSATE DRAIN PIPE SIZING34	
5.	A. GENERAL.17B. WATER QUALITY.17C. OPERATING PARAMETERS18D. SYSTEM COMPONENTS18E. SYSTEM PIPING22F. FREEZE PROTECTION22G. SPECIAL APPLICATIONS29FUEL PIPING30A. GENERAL.30B. FUEL LINE SIZING30C. GAS SUPPLY PIPING – INSTALLATION30D. GAS SUPPLY PIPING – OPERATION31E. MAIN GAS VALVE – OPERATION32CONDENSATE DRAIN PIPING33A. GENERAL.33C. CONDENSATE DRAIN PIPE MATERIAL34D. CONDENSATE DRAIN PIPE SIZING34E. CONDENSATE DRAIN PIPE34	
5.	A. GENERAL.17B. WATER QUALITY.17C. OPERATING PARAMETERS18D. SYSTEM COMPONENTS18E. SYSTEM PIPING22F. FREEZE PROTECTION22G. SPECIAL APPLICATIONS29FUEL PIPING30A. GENERAL.30B. FUEL LINE SIZING30C. GAS SUPPLY PIPING – INSTALLATION31E. MAIN GAS VALVE – OPERATION31E. MAIN GAS VALVE – OPERATION32CONDENSATE DRAIN PIPING33A. GENERAL.33B. CONDENSATE DRAIN PIPE MATERIAL.34D. CONDENSATE DRAIN PIPE SIZING34E. CONDENSATE DRAIN PIPE MATERIAL.34	
5.	A. GENERAL.17B. WATER QUALITY.17C. OPERATING PARAMETERS18D. SYSTEM COMPONENTS18E. SYSTEM PIPING22F. FREEZE PROTECTION22G. SPECIAL APPLICATIONS29FUEL PIPING30A. GENERAL.30B. FUEL LINE SIZING30C. GAS SUPPLY PIPING – INSTALLATION30D. GAS SUPPLY PIPING – OPERATION31E. MAIN GAS VALVE – OPERATION32CONDENSATE DRAIN PIPING33A. GENERAL.33B. CONDENSATE DRAIN PIPE MATERIAL34D. CONDENSATE DRAIN PIPE SIZING34E. CONDENSATE DRAIN PIPE SIZING34	

	B. CUSTOMER CONNECTIONS	36
	D. INTERNAL WIRING.	36
8.	BOILER CONTROL: INTERNAL WIRING & OPERATION	40
	A. CONTROL OVERVIEW	40
	B. IGNITION SEQUENCE	42
	C. BOILER CONTROL	
	E. DOMESTIC HOT WATER (DHW)	
	G. SYSTEM TEST	-
	H. STATUS & FAULT HISTORY	
	I. SENSOR RESISTANCE	
	J. MULTIPLE BOILERS	
9.	START-UP PROCEDURE	57
	A. GENERAL	57
	B. CHECK WATER PIPING	57
	C. CHECK GAS PIPING.	57
	D. CHECK OPERATION	
	E. LIGHTING & OPERATING PROCEDURES	59
10		60
	A. HARDWARE ERROR – NO COMM MAIN BOARD	60
	B. BLOCKING ERRORS	
	C. LOCKING ERRORS.	60
	D. ERROR MESSAGES IN A CASCADE	
	SYSTEM	
	E. WARNING ERRORS	
	F. DELAYED IGNITION (HARD LIGHT-OFF) G. BOILER FAILS TO RESPOND TO A CH CALL	
44	. MAINTENANCE	
11.	A. GENERAL (WITH BOILER IN USE)	67
	B. WEEKLY (WITH BOILER IN USE)	
	C. ANNUALLY (BEFORE START OF HEATING	
	SEASON)	68
	D. CONDENSATE CLEANING	~~
	INSTRUCTIONS E. INSPECTION & CLEANING OF	68
	COMBUSTION CHAMBER COILS	69
12	. BOILER DIMENSIONS & RATINGS	70
13	. REPAIR PARTS	74
AF	PPENDIX A. STATUS SCREENS	83
AF	PPENDIX B. USER MENU	87
AF	PPENDIX C. INSTALLER MENU	88
_	PPENDIX D. COMBUSTION TEST	
		93

USING THIS MANUAL

A. INSTALLATION SEQUENCE

Follow the installation instructions provided in this manual in the order shown. The order of these instructions has been set in order to provide the installer with a logical sequence of steps that will minimize potential interferences and maximize safety during boiler installation.

B. SPECIAL ATTENTION BOXES

Throughout this manual special attention boxes are provided to supplement the instructions and make special notice of potential hazards. The definition of each of these categories, in the judgement of PB Heat, LLC are as follows:

🚹 DANGER

Indicates a hazardous situation, which, if not avoided, will result in death or serious injury and major property damage.

Indicates a hazardous situation, which, if not avoided, could result in death or serious injury and major property damage.

AUTION

Indicates a hazardous situation, which, if not avoided, could result in minor or moderate injury, and minor property damage.

NOTICE

Indicates special attention is needed, not related to personal injury or property damage.

Compliance with the Energy Policy and Conservation Act:

$\underline{\Lambda}$ important notice

In accordance with Section 325 (f) (3) of the Energy Policy and Conservation Act, this boiler is equipped with a feature that saves energy by reducing the boiler water temperature as the heating load decreases. This feature is equipped with an override which is provided primarily to permit the use of an external energy management system that serves the same function.

THIS OVERRIDE MUST NOT BE USED UNLESS AT LEAST ONE OF THE FOLLOWING CONDITIONS IS TRUE:

- An external energy management system is installed that reduces the boiler water temperature as the heating load decreases.
- This boiler is not used for any space heating
- This boiler is part of a modular or multiple boiler system having a total input of 300,000 BTU/hr or greater.
- This boiler is equipped with a tankless coil.

1. PREINSTALLATION

A. GENERAL

- PUREFIRE® boilers are supplied completely assembled as packaged boilers. The package should be inspected for damage upon receipt and any damage to the unit should be reported to the shipping company and wholesaler. This boiler should be stored in a clean, dry area.
- Carefully read these instructions and be sure to understand the function of all connections prior to beginning installation. Contact your PB Heat, LLC Representative for help in answering questions.
- 3. This boiler must be installed by a qualified contractor. The boiler warranty may be voided if the boiler is not installed correctly.
- 4. A hot water boiler installed above radiation or as required by the Authority having jurisdiction, must be provided with a low water fuel cut-off device either as part of the boiler or at the time of installation.

B. CODES & REGULATIONS

- Installation and repairs are to be performed in strict accordance with the requirements of state and local regulating agencies and codes dealing with boiler and gas appliance installation.
- 2. In the absence of local requirements the following should be followed:
 - a. ASME Boiler and Pressure Vessel Code, Section IV -"Heating Boilers"
 - ASME Boiler and Pressure Vessel Code, Section VI - "Recommended Rules for the Care and Operation of Heating Boilers"

\land WARNING

Liquefied Petroleum (LP) Gas or Propane is heavier than air and, in the event of a leak, may collect in low areas such as basements or floor drains. The gas may then ignite resulting in a fire or explosion.

- c. ANSI Z223.1/NFPA 54 "National Fuel Gas Code"
- d. ANSI/NFPA 70 "National Electrical Code"
- e. ANSI/NFPA 211 "Chimneys, Fireplaces, Vents and Solid Fuel Burning Appliances"
- Where required by the authority having jurisdiction, the installation must conform to the Standard for Controls and Safety Devices for Automatically Fired Boilers, ANSI/ ASME CSD-1.
- **Please read if installing in Massachusetts** Massachusetts requires manufacturers of Side Wall Vented boilers to provide the following information from the Massachusetts code:
 - A hard wired carbon monoxide detector with an alarm and battery back-up must be installed

on the floor level where the gas equipment is to be installed AND on each additional level of the dwelling, building or structure served by the side wall horizontal vented gas fueled equipment.

- In the event that the side wall horizontally vented gas fueled equipment is installed in a crawl space or an attic, the hard wired carbon monoxide detector with alarm and battery back-up may be installed on the next adjacent floor level.
- Detector(s) must be installed by qualified licensed professionals.
- APPROVED CARBON MONOXIDE DETECTORS: Each carbon monoxide detector shall comply with NFPA 720 and be ANSI/UL 2034 listed and IAS certified.
- SIGNAGE: A metal or plastic identification plate shall be permanently mounted to the exterior of the building at a minimum height of eight (8) feet above grade directly in line with the exhaust vent terminal for the horizontally vented gas fueled heating appliance or equipment. The sign shall read, in print size no less than one-half (1/2) inch in size, "GAS VENT DIRECTLY BELOW. KEEP CLEAR OF ALL OBSTRUCTIONS".
- EXEMPTIONS to the requirements listed above:
 - The above requirements do not apply if the exhaust vent termination is seven (7) feet or more above finished grade in the area of the venting, including but not limited to decks and porches.
 - The above requirements do not apply to a boiler installed in a room or structure separate from the dwelling, building or structure used in whole or in part for residential purposes.
- This boiler installation manual shall remain with the boiler at the completion of the installation.

See the latest edition of Massachusetts Code 248 CMR for complete verbage and also for additional (non-vent related) requirements (248 CMR is available online).

If your installation is NOT in Massachusetts, please see your authority of jurisdiction for requirements that may be in effect in your area. In the absence of such requirements, follow the *National Fuel Gas Code*, ANSI Z223.1/NFPA 54 and/or CAN/CSA B149.1, *Natural Gas and Propane Installation Code*.

NOTICE

The installer must verify that at least one carbon monoxide alarm has been installed within a residential living space or home following the alarm manufacturer's instructions and applicable local codes before putting the appliance into operation.

L'installateur est tenu de vérifier qu'au moins une alarme de détection de monoxyde de carbone soit installée dans un espace résidentiel ou dans un domicile conformément aux directives du fabricant de l'alarme et aux codes locaux applicables avant de mettre l'appareil en service.

PREINSTALLATION

C. ACCESSIBILITY CLEARANCES

1. The *PUREFIRE*^{*} boiler is certified for closet installations with zero clearance to combustible construction. In addition, it is design certified for use on combustible floors. Do not install on carpeting.

\land DANGER

DO NOT INSTALL ON CARPETING.

 Figure 1.1 shows the minimum recommended clearances to allow reasonable access to the boiler for Models PF-50, PF-80, PF-110 and PF-140. For Models PF-200, PF-210, PF-300 and PF-399, Figure 1.2 shows the minimum recommended accessibility clearances. However, Local codes or special conditions may require greater clearances.



Figure 1.1: Minimum Accessibility Clearances - PF-50, PF-80, PF-110 & PF-140



Figure 1.2: Minimum Accessibility Clearances – PF-200, PF-210, PF-300 & PF-399

PREINSTALLATION

D. COMBUSTION AND VENTILATION AIR

- The PUREFIRE* boiler is designed for operation with combustion air piped directly to the boiler from outside the building (sealed combustion). Combustion air may be supplied from within the building only if adequate combustion air and ventilation air is provided in accordance with the National Fuel Gas Code or applicable sections of the local building code. Subsections 3 through 10 as follows are based on the National Fuel Gas Code requirements.
- 2. If the combustion air is piped directly to the boiler from outside the building, no additional combustion or ventilation air is required. Otherwise, follow the *National Fuel Gas Code* recommendations summarized in subsections 3 through 10.
- 3. *Required Combustion Air Volume*: The total required volume of indoor air is to be the sum of the required volumes for all appliances located within the space. Rooms communicating directly with the space in which the appliances are installed and through combustion air openings sized as indicated in Subsection 3 are considered part of the required volume. The required volume of indoor air is to be determined by one of two methods.
 - a. <u>Standard Method</u>: The minimum required volume of indoor air (room volume) shall be 50 cubic feet per 1000 BTU/Hr (4.8 m3/kW). This method is to be used if the air infiltration rate is unknown or if the rate of air infiltration is known to be greater than 0.6 air changes per hour. As an option, this method may be used if the air infiltration rate is known to be between 0.6 and 0.4 air changes per hour. If the air infiltration rate is known to be below 0.4 then the *Known Air Infiltration Rate Method* must be used. If the building in which this appliance is to be installed is unusually tight, PB Heat recommends that the air infiltration rate be determined.
 - b. Known Air Infiltration Rate Method:

$$\frac{15 \text{ ft}^3}{\text{ACH}} \left(\frac{I_{fan}}{1000^{\text{Btu}}/\text{hr}} \right)$$

where:

Required Volumefan =

- *I*_{fan} = Input of the fan assisted appliances in Btu/hr
- ACH = air change per hour (percent of the volume of the space exchanged per hour, expressed as a decimal)
- Note: These calculations are not to be used for infiltration rates greater than 0.60 ACH.
- 4. Indoor Air Opening Size and Location: Openings connecting indoor spaces shall be sized and located as follows:

a. <u>Combining Spaces on the Same Floor</u>: Provide two permanent openings communicating with additional spaces that have a minimum free area of 1 in² per 1000 Btu/hr (22 cm² per 1000 W) of the total input rating of all gas fired equipment but not less than 100 in² (645 cm²). One opening is to begin within 12 inches (305 mm) from the top of the space and the other is to begin within 12 inches (305 mm) from the floor. The minimum dimension of either of these openings shall be 3 inches (76 mm). See Figure 1.3 for an illustration of this arrangement.



Figure 1.3: Air Openings – All Air from Indoors on the Same Floor

b. <u>Combining Spaces on Different Floors</u>: Provide one or more permanent openings communicating with additional spaces that have a total minimum free area of 2 in² per 1000 Btu/hr (44 cm² per 1000 W) of total input rating of all equipment. See Figure 1.4 for an illustration of this arrangement.



Figure 1.4: Air Openings – All Air from Indoors on Different Floors

- Outdoor Combustion Air: Outdoor combustion air is to be provided through one or two permanent openings. The minimum dimension of these air openings is 3 inches (76 mm).
 - a. <u>Two Permanent Opening Method</u>: Provide two permanent openings. One opening is to begin within 12 inches (305 mm) of the top of the space and the other is to begin within 12 inches (305 mm) of the floor. The openings are to communicate directly or by ducts with the outdoors or with spaces that freely communicate with the outdoors. The size of the openings shall be determined as follows:
 - Where communicating directly or through vertical ducts with the outdoors each opening shall have a minimum free area of 1 in² per 4000 Btu/hr (22 cm² per 4000 W) of total input rating for all equipment in the space. See Figure 1.5 for openings directly communicating with the outdoors or Figure 1.6 for openings connected by ducts to the outdoors.



Figure 1.5: Air Openings – All Air Directly from Outdoors



Figure 1.6: Air Openings – All Air from Outdoors through Vertical Ducts

 Where communicating with the outdoors through horizontal ducts, each opening shall have a minimum free area of 1 in² per 2000 Btu/hr (22 cm² per 2000 W) of total rated input for all appliances in the space. See Figure 1.7.



Figure 1.7: Air Openings – All Air from Outdoors through Horizontal Ducts

b. <u>One Permanent Opening Method</u>: Provide one permanent opening beginning within 12 inches (305 mm) of the top of the space. The opening shall communicate directly with the outdoors, communicate through a vertical or horizontal duct, or communicate with a space that freely communicates with the outdoors. The opening shall have a minimum free area of 1 in² per 3000 Btu/hr of total rated input for all appliances in the space and not less than the sum of the cross-sectional areas of all vent connectors in the space. The gas-fired equipment shall have clearances of at least 1 inch (25 mm) from the sides and back and 6 inches (150 mm) from the front of the appliance. See Figure 1.8 for this arrangement.



Figure 1.8: Air Openings – All Air from Outdoors through One Opening

PREINSTALLATION

- Combination Indoor and Outdoor Combustion Air: If the required volume of indoor air exceeds the available indoor air volume, outdoor air openings or ducts may be used to supplement the available indoor air provided:
 - a. The size and location of the indoor openings comply with Subsection 3.
 - b. The outdoor openings are to be located in accordance with Subsection 4.
 - c. The size of the outdoor openings are to be sized as follows:

$$A_{req} = A_{full} x \left(1 - \frac{V_{avail}}{V_{req}} \right)$$

where:

 A_{reg} = minimum area of outdoor openings.

- A_{full} = full size of outdoor openings calculated in accordance with Subsection 4.
- V_{avail} = available indoor air volume

 V_{req} = required indoor air volume

- 7. *Engineered Installations*: Engineered combustion air installations shall provide an adequate supply of combustion, ventilation, and dilution air and shall be approved by the authority having jurisdiction.
- 8. Mechanical Combustion Air Supply:
 - a. In installations where all combustion air is provided by a mechanical air supply system, the combustion air shall be supplied from the outdoors at the minimum rate of 0.35 ft³/min per 1000 Btu/hr (0.034 m³/min per 1000 W) of the total rated input of all appliances in the space.
 - b. In installations where exhaust fans are installed, additional air shall be provided to replace the exhaust air.
 - c. Each of the appliances served shall be interlocked to the mechanical air supply to prevent main burner operation when the mechanical air supply system is not in operation.
 - d. In buildings where the combustion air is provided by the mechanical ventilation system, the system shall provide the specified combustion air rate in addition to the required ventilation air.
- 9. Louvers & Grills:
 - The required size of openings for combustion, ventilation, and dilution air shall be based on the net free area of each opening.
 - Where the free area through a louver or grille is known, it shall be used in calculating the opening size required to provide the free area specified.
 - ii. Where the free area through a louver or grille is not known, it shall be assumed that wooden louvers will have 25% free area and metal louvers and grilles will have 75% free area.
 - iii. Non-motorized dampers shall be fixed in the open position.

- b. Motorized dampers shall be interlocked with the equipment so that they are proven in the full open position prior to ignition and during operation of the main burner.
 - The interlock shall prevent the main burner from igniting if the damper fails to open during burner startup.
 - ii. The interlock shall shut down the burner if the damper closes during burner operation.
- 10. Combustion Air Ducts:
 - a. Ducts shall be constructed of galvanized steel or an equivalent corrosion- resistant material.
 - b. Ducts shall terminate in an unobstructed space, allowing free movement of combustion air to the appliances.
 - c. Ducts shall serve a single space.
 - d. Ducts shall not serve both upper and lower combustion air openings where both such openings are used. The separation between ducts serving upper and lower combustion air openings shall be maintained to the source of combustion air.
 - e. Ducts shall not be screened where terminating in an attic space.
 - f. Horizontal upper combustion air ducts shall not slope downward toward the source of the combustion air.
 - g. Combustion air intake openings located on the exterior of buildings shall have the lowest side of the combustion air intake opening at least 12 inches (305 mm) above grade.
- 11. Refer to Section 3 of this manual, Venting & Air Inlet Piping, for specific instructions for piping the exhaust and combustion air.

E. PLANNING THE LAYOUTS

- Prepare sketches and notes showing the layout of the boiler installation to minimize the possibility of interferences with new or existing equipment, piping, venting and wiring.
- 2. The following sections of this manual should be reviewed for consideration of limitations with respect to:
 - a. Venting and Air Inlet Piping: Section 3
 - b. Water Piping: Section 4
 - c. Fuel Piping: Section 5
 - d. Condensate Removal: Section 6
 - e. Electrical Connections: Section 7
 - f. Boiler Control: Section 8
 - g. Boiler Dimensions and Ratings: Section 12

This boiler is certified as an indoor appliance. Do not install this boiler outdoors or locate where it will be exposed to freezing temperatures.

\land WARNING

Do not install this boiler where gasoline or other flammable liquids or vapors are stored or are in use.

🖄 WARNING

Do not install this boiler in the attic.

2. BOILER SET-UP

A. GENERAL

- PUREFIRE^{*} boilers are intended for installation in an area with a floor drain or in a suitable drain pan. Do not install any boiler where leaks or relief valve discharge will cause property damage.
- 2. The *PUREFIRE®* boiler is not intended to support external piping. All venting and other piping should be supported independently of the boiler.
- 3. Install the boiler level to prevent condensate from backing up inside the boiler.

▲ CAUTION

This boiler must be installed level to prevent condensate from backing up inside the boiler.

 PUREFIRE[®] boilers can be wall mounted or floor standing. The following instructions provide guidance for both configurations.

B. WALL MOUNTING

- 1. Models PF-50, PF-80, PF-110 and PF-140:
 - a. A wall mounting bracket kit (54171) is included for wall mounting these boiler sizes.
 - b. Mount the bracket level on the wall using 5/16" lag bolts. Be sure the lag bolts are fully supported by wall studs or adequate wall structure.
 - c. The mounting bracket has (4) holes on 16" centers as shown in Figure 2.1. This is intended to give installers the ability to mount the bracket on two wall studs spaced at this interval. If existing wall studs are spaced differently or if the desired location is not in line with the wall studs, additional support is required.



Figure 2.1: Optional Wall Mounting Bracket for PF-50, PF-80, PF-110 and PF-140 Boilers

d. Install the two additional lag bolts supplied with the boiler into the wall structure approximately 23" below those used to attach the wall mounting bracket to the wall as shown in Figure 2.1. The depth that these are threaded into the wall can be adjusted to assure level mounting of the boiler.

\land WARNING

Make sure the boiler wall bracket is adequately supported. Do not install this bracket on dry wall unless adequately supported by wall studs.

e. If the boiler is wall mounted using the optional wall bracket, be sure that the wall provides adequate support for the boiler.

\land WARNING

The wall mounting bracket is designed to support the boiler. External piping for water, venting, air intake and fuel supply is to be supported separately

- f. Be sure to adequately support the boiler while installing external piping or other connections.
- g. Be sure that condensate piping is routed to a suitable drain or condensate pump.
- 2. All Models can be wall mounted by using the optional stand (91400).
 - a. Use the leveling feet provided with the boiler to assure proper level.
 - b. Be sure to leave adequate provisions for condensate piping and/or a pump (if required).

C. FLOOR STANDING INSTALLATION

- For floor standing installations, use the leveling feet to assure that the boiler is completely level. This will prevent condensate from backing up in the boiler.
- 2. Be sure to leave adequate space for condensate piping or a pump if required.

3. VENTING & AIR INLET PIPING

A. GENERAL

- Install the PUREFIRE® boiler venting system in accordance with these instructions and with the National Fuel Gas Code, ANSI Z223.1/NFPA 54, CAN/CGA B149, and/or applicable provisions of local building codes.
- The PUREFIRE® boiler is a direct vent appliance and is ETL Listed as a Category IV appliance with Intertek Testing Laboratories, Inc.
- 3. Sources of combustion air contaminated with chlorine, ammonia or alkali agents must be avoided. Do not install this boiler near a swimming pool, hot tubs or laundry. Do not store chemicals near the boiler.

A WARNING

The venting system for this product is to be installed in strict accordance with these venting instructions. Failure to install the vent system properly may result in severe personal injury, death or major property damage.

A WARNING

This vent system operates under positive pressure. Vent connectors serving appliances vented by natural draft shall not be connected into any portion of this venting system. Failure to comply may result in serious injury, death or major property damage.

B. APPROVED MATERIALS

- 1. Table 3.1 lists approved materials for vent pipe (and adhesives where applicable). Use only these materials for exhaust vent piping.
- PVC pipe and fittings are not to be used for venting in confined spaces such as closet installations. Use only CPVC or polypropylene (InnoFlue or PolyPro) vent pipe under these conditions.
- 3. Cellular core piping is approved for inlet air piping only.

\land WARNING

Only the materials listed below are approved for use with the *PUREFIRE*[®] boiler. Use only these components in accordance with these instructions. Failure to use the correct material may result in serious injury, death, or major property damage.

Table 3.1: Approved Materials for Exhaust Vent Pipe

Description	Material	Conforming to Standard
	PVC (Sch 40 or 80)*	ANSI/ASTM D1785
	CPVC (Sch 40 or 80)	ANSI/ASTM D1785
	PVC-DWV*	ANSI/ASTM D2665
	DuraVent FasNSeal [®] AL29-4c Stainless	UL-1738
Exhaust	DuraVent PolyPro [©] Polypropylene	ULC-S636
Vent Piping & Fittings	Z-Flex Z-DENS®	ULC-S636
& Hungs	Z-Flex Z-Vent [®] AL29-4c Stainless	UL-1738 & ULC-S636
	CentroTherm InnoFlue [®] Polypropylene	ULC-S636
	ECCO Polypropylene Vent [™]	ULC-S636

* PVC pipe/fittings are not to be used for venting within confined spaces.

Notice: Installations in Canada require compliance with ULC S636 - Standard for Type BH Gas Venting Systems.

🗥 WARNING

Use of cellular core PVC (ASTM F891), cellular core CPVC, or Radel[®] (polyphenolsulphone) for exhaust vent is prohibited. Use of these materials as exhaust vent may result in severe personal injury, death, or major property damage.

C. EXHAUST VENT/AIR INTAKE PIPE LOCATION

- Install vent piping before installing water, fuel, or condensate piping. Working from largest to smallest diameter reduces the complexity of piping interferences.
- 2. Vent and air intake piping is to be installed so that there is sufficient access for routine inspection as required in Section 11, of this manual.
- 3. The vent piping for this boiler is approved for zero clearance to combustible construction. However, a fire stop must be used where the vent pipe penetrates walls or ceilings.
- 4. The Peerless® PUREFIRE® boiler, like all high efficiency, gas-fired appliances, is likely to produce a vapor plume due to condensation. Surfaces near the vent termination will likely become coated with condensation.
- 5. The maximum combined vent and air inlet vent length for the Peerless' *PUREFIRE*' boiler is about 200 equivalent feet (60 m).Be sure that the boiler is located such that the maximum vent length is not exceeded.

NOTICE

If the maximum equivalent vent length is exceeded, the maximum burner input rate may be reduced.

- 6. Air Intake Pipe Location Sidewall Venting:
 - Provide a minimum 1 foot (30 cm) clearance from the bottom of the air intake pipe above the expected snow accumulation level. Snow removal may be necessary to maintain clearances.
 - b. Do not locate air intake pipe in a parking area where machinery may damage the pipe.
 - c. Maintain a minimum of 8" horizontal distance between exhaust vent and the air intake. Increasing this distance minimizes the potential for contamination of the inlet air with exhaust.
 - d. For multiple boiler installations, the minimum horizontal distance between the inlet of one boiler to the exhaust of an adjacent boiler is 8" center-tocenter. In addition, the minimum vertical distance between the exhaust and air inlet is 6". See Figure 3.1 for an illustration.



Figure 3.1: Vent Pipe Spacing for Multiple PUREFIRE® Boilers

- e. The exhaust outlet of the vent pipe should not be angled any more than 5° from horizontal.
- Precautions should be taken to prevent recirculation of flue gases to the air inlet pipe of the boiler or other adjacent appliances.

- 7. Sidewall Venting Configuration:
 - a. See Figure 3.2 for an illustration of clearances for location of exit terminals of direct-vent venting systems.
 - This boiler vent system shall terminate at least 3 feet (0.9 m) above any forced air inlet located within 10 ft (3 m). Note: This does not apply to the combustion air intake of a direct-vent appliance.
 - Provide a minimum of 1 foot (30 cm) distance from any door, operable window, or gravity intake into any building.
 - Provide a minimum of 1 foot (30 cm) clearance from the bottom of the exit terminal above the expected snow accumulation level. Snow removal may be required to maintain clearance.
 - Provide a minimum of 4 feet (1.22 m) horizontal clearance from electrical meters, gas meters, gas regulators, and relief equipment. In no case shall the exit terminal be above or below the aforementioned equipment unless the 4 foot horizontal distance is maintained.
 - Do not locate the exhaust exit terminal over public walkways where condensate could drip and create a hazard or nuisance.
 - When adjacent to public walkways, locate the exit terminal at least 7 feet above grade.
 - Do not locate the exhaust termination directly under roof overhangs to prevent icicles from forming or recirculation of exhaust gases from occurring.

CAUTION

Condensing flue gases can freeze on exterior building surfaces which may cause discoloration and degradation of the surfaces.

• Provide 3 feet clearance from the inside corner of adjacent walls.



Figure 3.2: Exit Terminal Location for Mechanical Draft and Direct-Vent Venting Systems

VENTING & AIR INLET PIPING

- Figures 3.3 through 3.6 show approved sidewall venting configurations using the standard fittings supplied.
- Figure 3.4 is only approved for locations in which the outdoor temperature is above -5°F (-21°C) in accordance with ASHRAE 90A-1980 recommendations.
- Figures 3.7 shows an approved sidewall vent configuration using an optional concentric vent termination kit. 3" (54498) or 4" (54499).







Figure 3.5: Exhaust and Air Inlet on Opposite Walls



Figure 3.4: Offset Exhaust and Air Inlet Terminations

VENTING & AIR INLET PIPING









- 8. Vertical Venting Configuration:
 - Figure 3.8 shows the approved venting configuration for vertical venting using the standard fittings supplied.



Figure 3.8: Standard Vertical Vent Installation

- b. Locate the air intake pipe inlet a minimum of 12" above the expected snow accumulation on the roof surface.
- c. Locate the end of the exhaust vent pipe a minimum of 12" above the inlet to the air intake pipe.
- d. Figure 3.9 shows an approved vertical vent configuration using the optional concentric vent termination kit.
- e. Figure 3.10 shows an option for routing the exhaust and air inlet piping through an unused chimney.
- f. Figure 3.11 shows this option using inlet air from a sidewall position.
- g. Figure 3.12 shows an option for routing the exhaust through an unused chimney with the combustion air supplied from inside the building. Be sure to note the requirements for combustion air as listed under Section 1.D. "Combustion and Ventilation Air". These requirements are in accordance with the National Fuel Gas Code.



Figure 3.9: Concentric Vertical Vent Installation



Figure 3.10: Venting Through a Chimney Using Outside Air



Figure 3.11: Venting Through a Chimney Using Sidewall Outside Air



Figure 3.12: Venting with a Chimney Using Inside Air

D. EXHAUST VENT/AIR INTAKE PIPE SIZING

 Table 3.2 shows Exhaust Vent/Air Intake Sizes for *PUREFIRE*[®] boilers.

Table 3.2: Exhaust Vent/Air Intake Sizing

Boiler Model	Exhaust Vent/Air Intake Size
PF-50	3″ (80 mm)
PF-80	3" (80 mm)
PF-110	3" (80 mm)
PF-140	3" (80 mm)
PF-200	3" (80 mm)
PF-210	3" (80 mm)
PF-300	4" (100 mm)
PF-399	4" (100 mm)

 Polypropylene vent systems can be installed using optional InnoFlue[®] or PolyPro[®] vent adapters. Table 3.3 shows the appropriate PB Heat stock codes.

Table 3.3: Polypropylene Vent Adapter Stock Codes

Boiler Model	Centrotherm InnoFlue®		Boiler Model	Centrotherm InnoFlue®	DuraVent PolyPro [®]
PF-50	54632	54630*	PF-200	54632	54630*
PF-80	54632	54630*	PF-210	54632	54630*
PF-110	54632	54630*	PF-300	54633	54631*
PF-140	54632	54630*	PF-399	54633	54631*

* Use *Duravent* adapter connector, Part# PPS-PAC, with PB Heat Parts 54630 and 54631.

Contact your PB Heat, LLC Representative for more information on this option.

- Combined systems using separate polypropylene exhaust & air inlet pipes which transitions to concentric can also be installed. Contact your Centrotherm or DuraVent representative for more information.
- 4. The total combined length of exhaust vent and air intake piping is 200 equivalent feet (60 m).
 - a. The equivalent length of elbows, tees and other fittings are listed in Table 3.4.

Table 3.4: Equivalent Length of Fittings

Fitting Description	Equivalent Length
Elbow, 90° Short Radius	5 feet
Elbow, 90° Long Radius	4 feet
Elbow, 45° Short Radius	3 feet
Coupling	0 feet
Air Intake Tee	0 feet
Stainless Steel Vent Kit	1 foot
Concentric Vent Kit	3 feet

b. The equivalent length can be calculated as follows.

Table 3.5: Sample Equivalent Length Calculation

	Exhaust	Air Inlet	Total
Straight Length of Pipe	50′	50′	100′
90° Elbows, SR	2 x 5′= 10′	1 x 5' = 5'	15′
45° Elbows, SR		2 x 3' = 6'	6'
Conc. Vent Termination	1 x 3	′ = 3′	3′
	То	tal	124'

NOTICE

Exhaust Vent/Air Intake length in excess of 200 equivalent feet may result in reduced input due to excessive pressure drop.

This is well below the 200 feet maximum equivalent length. If the total is above 200 equivalent feet, alternate boiler locations or exhaust penetration location should be considered.

E. EXHAUST VENT/AIR INTAKE INSTALLTION

Covering non-metallic exhaust venting material is prohibited and may result in severe personal injury, death, or major property damage.

- 1. Figures 12.1 & 12.2 show the exhaust connection on top of the boiler, near the rear in the center.
 - a. The exhaust connection for PF-50, PF-80, PF- 110 & PF-140 boilers is a 3" CPVC Female Pipe Adapter.
 - b. The exhaust connections for the PF-200/210 (3"), PF-300 (4") and PF-399 (4") are male CPVC pipe.
 - c. These connections are to be joined with suitable PVC/CPVC adhesives in accordance with manufacturers' instructions.
- 2. The Air Intake connection is to the right of the exhaust.
- 3. Both connections are clearly marked.

MARNING

This appliance uses a positive pressure venting system. All joints must be sealed completely to prevent leakage of flue products into living spaces. Failure to do this may result in severe personal injury, death or major property damage.

- 4. Remove all burrs and debris from the joints and fittings.
- 5. Horizontal lengths of exhaust vent must be installed with a slope of not less than 1/4" per foot (21 mm per meter) toward the boiler to allow condensate to drain from the vent pipe. If the vent pipe must be piped around an obstacle that causes a low point in the piping, a drain with an appropriate trap must be installed.
- 6. All piping must be fully supported. Use pipe hangers at a minimum of 4 foot (1.22 meter) intervals to prevent sagging of the pipe.
- 7. Exhaust and air inlet piping is to be supported separately and should not apply force to the boiler.
- 8. Penetration openings around the vent pipe and air intake piping are to be fully sealed to prevent exhaust gases from entering building structures.
- 9. PVC & CPVC Piping:

- a. Use only solid PVC or CPVC Schedule 40 or 80 pipe for exhaust venting. Cellular core PVC or CPVC is not approved for exhaust vent.
- b. All joints in vent pipe, fittings, attachment to the boiler stub, and all vent termination joints must be properly cleaned, primed and cemented. Use only cement and primer approved for use with PVC or CPVC pipe that conforms to ANSI/ASTM D2564.
- c. A straight coupling is provided with the boiler to be used as an outside vent termination. One of the two screens is to be installed to prevent birds or rodents from entering.
- d. An air intake tee is provided with the boiler to be used as an outside air intake termination. A screen is to be installed to prevent birds or rodents from entering.
- e. The following are optional combination air intake/ exhaust terminations that are available separately from your PB Heat, LLC distributor for use with *PUREFIRE*^{*} boilers. A 3" CPVC/PVC coupling is required for the PF-200/210 and a 4" CPVC/PVC coupling is required for the PF-300/399 models when using a concentric vent termination.

Table 3.6:	Concentric	Vent	Termination I	Kits

Boiler Model	Description	Stock Code
PF-50, PF-80,	Sidewall Vent Termination Kit – PolyPro 3PPS- HK	54498
PF-110, PF-140, PF-200, PF-210	Vertical Vent Termination Kit – PolyPro 3PPS-VK	54500
PF-300	Sidewall Vent Termination Kit – PolyPro 4PPS- HK	54499
PF-399	Vertical Vent Termination Kit – PolyPro 4PPS-VK	54501

- f. Refer to Figures 3.3 through 3.7 for sidewall venting options using PVC or CPVC pipe.
- g. Refer to Figures 3.8 through 3.12 for vertical venting options using PVC or CPVC pipe.

F. EXHAUST TAPPING FOR VENT SAMPLE

To properly install the *PUREFIRE*^{*} boiler, carbon dioxide (CO_2) and carbon monoxide (CO) levels in the exhaust vent must be determined from a sample of combustion products. To do this in PVC or CPVC pipe, a hole must be drilled in the exhaust vent pipe:

- a. Drill a 21/64" diameter hole in the pipe in a position that that the combustion analyzer probe can be inserted between 6" and 12" from the boiler connection.
- b. Tap the hole with a 1/8" NPT pipe tap.
- c. Use a 1/8" NPT PVC or Teflon Pipe Plug to seal the hole.

InnoFlue^{*} and PolyPro^{*} vent systems offer test port fittings for obtaining a sample of combustion products. See your Centrotherm or DuraVent Representative for recommendations.

See Section 9.D.7 for instructions on taking combustion readings.

G. BOILER REMOVAL FROM COMMON VENTING SYSTEM

At the time of removal of an existing boiler, follow these steps with each appliance remaining connected to the common venting system placed in operation, while the other appliances remaining connected to the common venting system are not in operation:

Retrait de la chaudière d'un système d'évacuation commun. Au moment de retirer une chaudière existante, il est important de suivre les étapes suivantes pour chaque appareil raccordé au système d'évacuation commun qui sont en service, alors que les autres appareils demeurant raccordés au système d'évacuation commun ne sont pas en service :

1. Seal any unused openings in the common venting system.

Sceller toute ouverture du système d'évacuation commun non utilisée.

2. Visually inspect the venting system for proper size and horizontal pitch and determine there is no blockage or restriction, leakage, corrosion and other deficiencies which could cause an unsafe condition.

Effectuer un contrôle visuel du système d'évacuation pour vérifier la taille et la pente horizontale et s'assurer qu'il n'existe aucun blocage ou obstruction, fuite, corrosion ni tout autre problème pouvant menacer la sécurité.

3. Insofar as is practical, close all building doors and windows and all doors between the space in which the appliances remaining connected to the common venting system are located and other spaces of the building.

Dans la mesure du possible, fermer toutes les portes et fenêtres de l'immeuble ainsi que toutes les portes entre l'espace dans lequel les appareils qui demeurent raccordés au système d'évacuation commun se trouvent et le reste de l'immeuble.

4. Turn on any clothes dryers and any appliance not connected to common venting system. Turn on any exhaust fans, such as range hoods and bathroom exhausts, so they will operate at maximum speed. Do not operate a summer exhaust fan.

Mettre en marche les sécheuses et tout autre appareil non raccordé au système d'évacuation commun. Mettre en marche tous les ventilateurs aspirant, tels que les hottes de cuisinière et les ventilateurs de salle de bain, en les faisant fonctionner à vitesse maximum.

5. Close fireplace dampers.

Ne pas faire fonctionner les ventilateurs aspirant d'été. Fermer les registres de foyers.

6. Place in operation the appliance being inspected. Follow the lighting instructions. Adjust thermostat so appliance will operate continuously.

Mettre en service l'appareil à inspecter. Suivre les instructions concernant l'allumage. Régler le thermostat afin que l'appareil fonctionne sans arrêt. Test for spillage at the draft hood relief opening after 5 minutes of main burner operation. Use the flame of a match or candle, or smoke from a cigarette, cigar, or pipe.

Vérifier toute fuite à l'orifice de décharge du coupetirage après que le brûleur ait fonctionné pendant 5 minutes. Utiliser la flamme d'une allumette ou d'une chandelle ou encore la fumée d'une cigarette, d'un cigare ou d'une pipe.

8. After it has been determined that each appliance remaining connected to the common venting system properly vents when tested as outlined above, return doors, windows, exhaust fans, fireplace dampers and any other gas-burning appliance to their previous conditions of use.

Après avoir établi que les résidus de combustion de chaque appareil qui demeure raccordé au système commun sont adéquatement évacués lorsque soumis au test décrit ci-dessus, remettre en place les portes, fenêtres, portes intérieures, ventilateurs aspirants, registres de foyer et appareils fonctionnant au gaz. 9. Any improper operation of the common venting system should be corrected so that the installation conforms with the National Fuel Gas Code, ANSI Z223.1/NFPA 54 or CAN/CGA B149 Installation Codes.

Tout fonctionnement inadéquat du système d'évacuation commun doit être corrigé de manière à respecter les normes du National Fuel Gas Code, ANSI Z223.1/NFPA 54 et/ou des Codes d'installation CAN/ACG B149.

10. When resizing any portion of the common venting system, the common venting system should be resized to approach minimum size as determined using the appropriate tables located in the chapter "Sizing of Category I Venting Systems," of the National Fuel Gas Code, ANSI Z223.1/NFPA 54 or CAN/CGA B149 Installation codes.

Lorsqu'il est nécessaire de modifier les dimensions de toute portion du système d'évacuation commun, ces dernières doivent être modifiées de manière à respecter les dimensions minimums indiquées dans les tableaux du chapitre « Sizing of Category I Venting Systems » du National Fuel Gas Code, ANSI Z223.1/NFPA 54 ou des Codes d'installation CAN/ACG B149.

A. GENERAL

- 1. Size water supply and return piping in accordance with system requirements rather than the boiler connections.
- If the PUREFIRE® boiler is used to replace an existing boiler, make sure the system piping is thoroughly cleaned and free from debris before installing this boiler. Sentinel Performance Solutions (http://www.sentinel-solutions.net/us/) offers a full line of cleaners (X300), sludge remover (X400), antifreeze (X500) and corrosion inhibitors (X100/X500) for hydronic applications.
- 3. In hydronic systems where sediment may exist, install a strainer in the boiler return piping to prevent large particles and pipe scale from entering the boiler heat exchanger. Use a large mesh screen in the strainer.
- Install this boiler so that the gas ignition system components are protected from water (dripping, spraying, etc.) during operation and service (circulator replacement, condensate trap cleaning, sensor replacement, etc.).

B. WATER QUALITY

PUREFIRE® boilers are intended for use in a closed-loop hydronic system. Make-up fresh water for the system will include oxygen, calcium and other substances which may cause corrosion, calcium scale buildup or other attacks on the hydronic system and boiler components.

The following steps should be taken to maximize the longevity of the boiler and system:

- Water hardness must be between 3 Grains/Gal (gpg) and 9 Grains/Gal (gpg). Use of a water treatment system may be required on make-up water in areas with hard water.
- The systems water pH level should fall between 6 pH and 8 pH. The slightly alkaline water will work to prevent corrosion and neutralize any acidic buildup over time minimizing potential sources of corrosive attacks on the heat exchanger.
- 3. The system should be flushed and cleaned thoroughly with fresh water and a rinsing agent prior to boiler installation. Any new system must be cleaned to remove any flux or welding residue. Any existing system must be cleaned to remove scale and particulate matter prior to boiler connection to the system. Thoroughly flush any cleaning agent from the system with clean water prior to connecting the boiler. See Table 4.1 for recommended cleaning agents.
- 4. High oxygen levels in the system water will allow scale buildup to occur. Steps must be taken to minimize oxygen levels in the system. The following items are recommended during installation:

\land WARNING

Failure to properly analyze and treat system water when installing a high efficiency boiler can cause heat exchanger failure due to water passageway fouling. Black oxide sludge (magnetite – Fe_3O_4), red oxide sludge (iron oxide – Fe_2O_3), and calcium scale (limescale) will settle over the hottest portion of the heat exchanger coils. This buildup will reduce thermal transfer in the areas where the buildup is greatest resulting in an increased fouling rate. The high temperatures in these locations will compromise the natural corrosion resistance of the stainless steel material leading to accelerated failure of the heat exchanger.

Failure to address the causes of the fouling in the system can void heat exchanger warranty, and risk property damage, personal injury or death.

System must be cleaned before the boiler is connected!

- Flush the system with fresh water
- Use a cleaning agent appropriate for the system material and debris to be removed
- Thoroughly flush cleaning agent residue from the system with fresh water

The following actions must be taken after the boiler is connected to the system:

- Treat system water with a corrosion and scale inhibitor to prevent oxidization and scale buildup. Follow the inhibitor manufacturer's instructions when treating the system water

- a. Provide Air Elimination Means: An automatic air vent should be installed at the highest point in the system and at any points air could potentially be trapped. When replacing an existing boiler, ensure any automatic air vents installed in the system are functioning correctly and installed in a proper location. A hydronic separator is another option to provide a low velocity zone for trapped air bubbles to separate and be eliminated from the system while providing primary/secondary operation.
- b. It is recommended that a water meter be installed on the system fresh water intake to monitor the system for any leaks by monitoring make-up water usage. Untreated fresh water sources will introduce oxygen, minerals and contaminants into system.
- c. Correct any system leaks prior to placing the boiler in operation.

 Table 4.1:
 Recommended Water Treatment Products for use in Stainless Steel Condensing Boiler Applications

	Supplier			
	Fernox Sentinel Sotin ADEY			ADEY
Universal	Restorer F3	X300		
Cleaner	or F5	A300	-	-
Sludge Remover	Cleaner F3 or F5	X400	Sotin 212	-
Inhibitors	Protector F1/ Alphi 11	X100, X500	Sotin 212	MC1+
Antifreeze	Alphi 11	X500	-	-

\land WARNING

Do not use petroleum based cleaners when cleaning the boiler system. Damage to the gaskets found in typical system components can occur resulting in significant property damage.

C. OPERATING PARAMETERS

- The PUREFIRE® boiler is designed to operate in a closed loop hydronic system under forced circulation. This requires the system to be completely filled with water and requires a minimum water flow through the boiler to operate effectively.
- 2. The minimum system pressure is 14.5 psig (100 kPa).
- 3. Table 4.2 lists the minimum flow rates for each *PUREFIRE*^{*} model. If a glycol solution is to be used, contact your PB Heat, LLC representative for minimum flow rates.

Table 4.2: Minimum Flow Rate

PureFire®	Minimum Flow Rate		
Model	Water GPM (LPM)	50% Glycol Solution GPM (LPM)	
PF-50	2.2 (8.3)	2.8 (10.6)	
PF-80	3.3 (12.5)	4.1 (15.5)	
PF-110	4.4 (16.7)	5.5 (20.8)	
PF-140	5.5 (20.8)	6.8 (25.7)	
PF-200	5.5 (20.8)	6.8 (25.7)	
PF-210	5.5 (20.8)	6.8 (25.7)	
PF-300	13.2 (50.0)	16.5 (62.5)	
PF-399	13.2 (50.0)	16.5 (62.5)	

Section 4.F provides detailed information about using glycol for freeze protection.

Table 4.3 provides the water volume of the heat exchanger including the supply and return pipes that are attached at the factory.

PureFire [®] Model	Total Water Capacity Gallons (Liters)
PF-50	0.62 (2.35)
PF-80	0.72 (2.73)
PF-110	0.89 (3.37)
PF-140	1.25 (4.73)
PF-200	1.19 (4.50)
PF-210	1.19 (4.50)
PF-300	2.60 (9.84)
PF-399	2.60 (9.84)

Table 4.3: Heat Exchanger Water Capacity

D. SYSTEM COMPONENTS

Figure 4.1 shows the symbol key for piping diagrams in this section. The following are brief descriptions of system components.

- Pressure/Temperature Gauge: A combination pressure/ temperature gauge is provided with each PUREFIRE* boiler to be mounted in the piping from the boiler supply to the system as shown in Figure 4.2 & 4.3. Most local codes require this gauge.
- Air Elimination: Closed loop hydronic systems require air elimination devices. As the system water is heated, dissolved oxygen and other gases will separate from the liquid. An air elimination device (such as a TACO Vortech^{*} Air Separator) is required to remove the dissolved gases preventing corrosion in the piping system and eliminating noise.
- 3. *Expansion Tank*: An expansion tank (such as a Bell & Gossett Series HFT) is required to provide room for expansion of the heating medium (water or glycol solution). Consult the expansion tank manufacturer's instructions for specific information regarding installation. The expansion tank is to be sized for the required system volume and capacity. In addition, be sure that the expansion tank is sized based on the proper heating medium. Glycol solutions may expand more than water for a similar temperature rise.

A CAUTION

Use only inhibited propylene glycol solutions which are specifically formulated for hydronic systems. Unlike automotive antifreeze, solutions for hydronic applications contain corrosion inhibitors that will protect system components from premature failure due to corrosion.

🕂 WARNING

Use only inhibited propylene glycol solutions which are specifically formulated for hydronic systems. Ethylene glycol is toxic and may cause an environmental hazard if a leak or spill occurs.



THREE WAY MIXING VALVE ZONE VALVE DIFFERENTIAL PRESSURE BYPASS VALVE CHECK VALVE (BACKFLOW PREVENTER) CIRCULATOR DIVERTER TEE TEMPERATURE

PRESSURE GAUGE

ISOLATION VALVE

BALANCING VALVE

PRESSURE REGULATOR

Figure 4.1: Piping Symbol Key

- 4. *Y-Type Strainer or Filter Ball*" *Valve*: PB Heat, LLC recommends the use of a strainer device in the system to prevent dirt or sediment from clogging the heat exchanger. A 20 mesh stainless steel screen is adequate to protect the heat exchanger. The strainer should be cleaned often in the first several months of operation. The Filter Ball" Valve from Jomar International incorporates a strainer into a ball valve which allows the technician to isolate the water circuit while cleaning the strainer.
- Flow Control Valve: Flow control valves such as the TACO Flo-Chek or Bell & Gossett Flo-Control[™] are used to prevent gravity circulation by incorporating a check valve with a weighted disc.
- 6. Pressure Reducing Valve: A pressure reducing valve, such as the Bell & Gossett B-38 or a TACO #329, is used in a hydronic system to automatically feed water to the system whenever pressure in the system drops below the pressure setting of the valve. These valves should not be used on glycol systems unless close supervision of the glycol solution is practiced.
- Back Flow Preventer: A back flow preventer (check valve) is required by some jurisdictions to prevent water in the hydronic system from backing up into the city water supply. This is especially important on systems in which glycol solution is used as the heating medium.
- 8. *Pressure Relief Valve*: The boiler pressure relief valve is shipped separately for field installation.

The valve is to be installed as shown in Figures 4.2 or

🗥 WARNING

Do not operate this appliance without installing the pressure relief valve supplied with the boiler or one with sufficient relieving capacity in accordance with the ASME Rating Plate on the boiler heat exchanger.

4.3. Pipe the discharge of the relief value to withing 12" of the floor and close to a floor drain.

A CAUTION

Pipe the discharge of the relief valve as close as possible to the floor and away from high traffic areas. Pipe the discharge to a floor drain. Failure to do so may result in personal injury and/or property damage.

Provide piping that is the same size or larger than the relief valve outlet.

9. *Low Water Cut Off*: When installing a probe type LWCO, locate the LWCO in the boiler supply above the top jacket panel. Refer to Section 7. Electrical Connection in this manual for wiring details.



Figure 4.2: Relief Valve Installation – PF-50, PF-80, PF-110 & PF-140

Circulator: The boiler circulator is to be sized to overcome the pressure drop of the system while providing the flow required by the boiler.

- a. If the boiler is piped in a secondary loop of a primary/secondary heating system, the circulator will need only to overcome the resistance of the boiler and any fittings in that loop.
- b. The circulator should be sized based on gross output of the boiler. Table 4.4 shows the Boiler Output as reported to the Hydronics Institute Section of AHRI.
- c. The required flow is calculated based on the design temperature difference from the return to the supply of the boiler. For a PF-110 with a design temperature difference of 20°F the calculation is as follows.



Table 4.4: Boiler Inputs and Outputs

PureFire* Model	Boiler Input Btu/hr (kW)	Gross Output Btu/hr (kW)
PF-50	50,000 (14.7)	46,000 (13.5)
PF-80	80,000 (23.4)	74,000 (21.7)
PF-110	110,000 (34.2)	102,000 (29.9)
PF-140	140,000 (41.0)	131,000 (38.4)
PF-200	199,000 (58.3)	183,000 (53.6)
PF-210	210,000 (61.5)	193,000 (56.6)
PF-300	300,000 (87.9)	289,000 (84.9)
PF-399	399,000 (116.9)	373,000 (109.3)







Figure 4.4: PUREFIRE' Circulator Sizing Graph (General Pump – Primary/Secondary)

- d. The boiler pressure drop for various flow rates can be determined using Figure 4.4, the *PUREFIRE®* Boiler Circulator Sizing Graph.
- e. Table 4.5 provides the flow rate and pressure drop information that corresponds to various system temperature rise values (DT). The pressure drop shown is for the boiler only. If there is significant pressure drop in the system, this should be included when specifying circulators.

Table 4.5: Flow Rate and Pressure Drop for Various System Temperature Rise Values

		Flow Rate & Pressure Drop														
∆T (°F)	PF	-50	PF	-80	PF-	110	PF-	140	PF-	200	PF-	210	PF-	300	PF-	399
(''	GPM	FT	GPM	FT	GPM	FT	GPM	FT	GPM	FT	GPM	FT	GPM	FT	GPM	FT
40	2.3	2.17	3.7	3.92	5.1	3.74	6.5	2.70	9.2	5.77	9.6	6.23	14.5	3.11	18.7	4.97
35	2.6	2.72	4.2	4.95	5.8	4.75	7.4	3.51	10.5	7.13	11.0	7.69	16.6	3.99	21.3	6.38
30	3.1	3.54	4.9	6.49	6.7	6.27	8.7	4.75	12.2	9.10	12.8	9.81	19.3	5.32	24.9	8.50
25	3.7	4.83	5.8	8.95	8.1	8.70	10.4	6.80	14.6	12.14	15.4	13.09	23.2	7.47	29.8	11.93
20	4.6	7.06	7.3	13.25	10.1	12.99	13.0	10.55	18.3	17.27	19.2	18.63	29.0	11.32	37.3	18.08
15	6.1	11.52	9.7	21.97	13.5	21.78	17.3	18.58	24.4	27.21	25.6	29.35	38.7	19.34	49.7	30.90
10	9.2	22.97	14.6	44.81	20.2	45.11	26.0	41.26	36.6	51.64	38.4	55.71	58.0	41.14	74.6	65.74

Circulator Manufacturer	Temp. Difference	PF-50	PF-80	PF-110	PF-140	PF-200	PF-210	PF-300	PF-399
Тасо		005*	009	0014	0014	1400-20	1400-20	2400-60	1400-50
Grundfos		UPS15-58FC Med Speed	UPS15-58FC Hi Speed	UPS26-99FC Med Speed	UPS26-99FC Med Speed	UPS32-80F Med Speed	UPS32-80F Med Speed	UPS26-150 SF Hi Speed	UPS32-160F Med Speed
Bell & Gossett	20°F	NRF-22	NRF-22	NRF-36	NRF-25	NRF-36	NRF-36	NRF-45 Speed 3	PL-55
Wilo	201	Star S 21 FX Med Speed	Star S 21 FX Hi Speed	Star S 21 FX Hi Speed	Star 30 F	Top S 1.25 x 25 Max	Top S 1.25 x 25 Max	Top-S 1.5 x 20 1 - 115V Min	Top S 1.25 x 35 Max
Armstrong		Astro 230CI Speed 2	Astro 250CI Speed 3	Astro 280CI Speed 2	Astro 280CI Speed 2	E9	E9	_	E21
Тасо		006F*	007	008	007	0014	0014	0011	1400-20
Grundfos		UPS15-58FC Lo Speed	UPS15-58FC Med Speed	UPS15-58FC Hi Speed	UPS15-58FC Hi Speed	UPS26-99FC Med Speed	UPS26-99FC Med Speed	UPS26-99 FC Med Speed	UPS32-80F Med Speed
Bell & Gossett	25°F	NRF-9F/LW	NRF-22	NRF-22	NRF-22	NRF-45	NRF-45	NRF-36 Speed 2	PL-50
Wilo	231	Star S 21 FX Low Speed	Star S 21 FX Med Speed	Star S 21 FX Hi Speed	Star S 21 FX Hi Speed	Star 30 F	Star 30 F	Star 17 FX	Top S 1.25 x 35 Max
Armstrong		Astro 230CI Speed 2	Astro 230CI Speed 3	Astro 230CI Speed 3	Astro 230CI Speed 3	Astro 280CI Speed 2	Astro 280CI Speed 2	_	E11
Тасо		006F*	005*	005*	005*	0014	0014	0011	0013
Grundfos	- 30°F	UP15-10F	UPS15-58FC Med Speed	UPS15-58FC Med Speed	UPS15-58FC Med Speed	UPS26-99FC Med Speed	UPS26-99FC Med Speed	UPS44-43 Med Speed	UPS26-99FC Hi Speed
Bell & Gossett		NRF-9F/LW	NRF-22	NRF-22	NRF-22	NRF-25	NRF-25	NRF-45 Speed 1	NRF-36
Wilo	501	Star S 21 FX Min Speed	Star S 21 FX Med Speed	Star S 21 FX Med Speed	Star S 21 FX Hi Speed	Star 30 F	Star 30 F	Star 30 F	Star 17 FX
Armstrong		Astro 230CI Speed 1	Astro 230CI Speed 2	Astro 230CI Speed 2	Astro 230CI Speed 3	Astro 280CI Speed 2	Astro 280CI Speed 2	_	Astro 290CI Speed 3
Тасо		006F*	006F*	006F*	006F*	0010	0010	0011	0014
Grundfos		UP15-10F	UPS15-58FC Lo Speed	UPS15-58FC Med Speed	UPS15-58FC Med Speed	UPS15-58FC Hi Speed	UPS15-58FC Hi Speed	UPS15-55 SFC Hi Speed	UPS26-99FC Hi Speed
Bell & Gossett	35°F	N/A	NRF-9F/LW	NRF-9F/LW	NRF-9F/LW	NRF-22	NRF-22	NRF-25 Speed 2	NRF-45
Wilo	551	Star S 21 FX Min Speed	Star S 21 FX Min Speed	Star S 21 FX Med Speed	Star S 21 FX Med Speed	Star S 21 FX Hi Speed	Star S 21 FX Hi Speed	Star S 33 RFC	Star 30 F
Armstrong		Astro 230CI Speed 1	Astro 230Cl Speed 2	Astro 230CI Speed 2	Astro 230Cl Speed 2	Astro 250CI Speed 3	Astro 250CI Speed 3	_	Astro 290CI Speed 2
Тасо		006F*	006F*	006F*	006F*	007	007	0011	0010
Grundfos		UP15-10F	UPS15-58FC Lo Speed	UPS15-58FC Lo Speed	UPS15-58FC Lo Speed	UPS15-58FC Hi Speed	UPS15-58FC Hi Speed	UPS15-58FC Hi Speed	UPS26-99FC Med Speed
Bell & Gossett	40°F	N/A	NRF-9F/LW	NRF-9F/LW	NRF-9F/LW	NRF-22	NRF-22	NRF-25 Speed 2	NRF-33
Wilo		Star S 21 FX Min Speed	Star S 21 FX High Speed	Star S 21 FX Hi Speed	Star S-21 F	Star 30 F			
Armstrong		Astro 230Cl Speed 1	Astro 230Cl Speed 1	Astro 230Cl Speed 2	Astro 230Cl Speed 2	Astro 250Cl Speed 3	Astro 250Cl Speed 3	_	Astro 290CI Speed 2
* A model 007 ci	rculator can l								

- f. Table 4.6 provides a list of recommended circulators for boilers on a secondary loop of a primary/ secondary system which uses water as a heating medium.
- g. Special consideration must be given if a glycol based anti-freeze solution is used as a heating medium.
 Propylene glycol has a higher viscosity than water, therefore the system pressure drop will be higher.

NOTICE

The circulator sizing given is for primary/secondary installations only. The system circulators must be sized based on the flow and pressure drop requirements of the system.

11. Indirect Water Heater: An indirect water heater should be piped to a dedicated zone. The PUREFIRE® boiler provides electrical terminals for connecting a domestic hot water (DHW) circulator. Examples of piping for the indirect water heater are shown under subsection "D", System Piping of this section.

E. SYSTEM PIPING

Table 4.7: Guide of Maximum Flow Rates for Different Pipe Sizes with Input

	Maximum Flow Rates and Input					
Steel Pipe						
Pipe Size	Pipe Size Maximum Flow (GPM) BTU/HR					
1/2"	2	15,000				
3/4"	4	40,000				
1″	8	80,000				
1-1/4"	16	140,000				
1-1/2″	25	220,000				
2″	50	450,000				
	Copper Tubing					
Tube Size	Maximum Flow (GPM)	BTU/HR				
1/2"	1.50	15,000				
3/4"	4	40,000				
1″	8	80,000				
1-1/4"	14	140,000				
1-1/2″	22	220,000				
2″	45	450,000				

- 1. Figure 4.5 shows a single boiler with multiple heating zones. In this case, the DHW zone is piped in parallel to the heating zones on the primary loop.
- For a single boiler with one heating zone and one DHW zone which utilizes an indirect water heater like the Peerless* Partner*, pipe the boiler as shown in Figure 4.6. In systems like this, the DHW circulator must be sized to provide the minimum flow rate through the boiler.
- 3. In Figure 4.7 an additional boiler is added and more heating zones are shown. Notice that the two boilers are piped in parallel on the secondary loop. This maximizes the efficiency of the boilers since the lowest temperature system water is returning to both boilers.

- 4. Figure 4.8 shows a multiple boiler system with several different types of heat distribution units. This system illustrates how different temperature zones can be supplied from the same source by blending supply and return water to the zone.
- In Figure 4.9 zone valves are used instead of zone circulators. Notice that the system is piped using reverse return piping to help balance the flow through the zones. If the zone lengths vary balancing valves are required on each loop.

F. FREEZE PROTECTION

- 1. Glycol for hydronic applications is specially formulated for heating systems. It includes inhibitors which prevent the glycol from attacking metallic system components. Make sure that the system fluid is checked for correct glycol concentration and inhibitor level.
- Use only inhibited polypropylene glycol solutions of up to 50% by volume. Ethylene glycol is toxic and can chemically attack gaskets and seals used in hydronic system.
- 3. The anti-freeze solution should be tested at least once per year and as recommended by the manufacturer of the product.
- 4. Anti-freeze solutions expand more than water. For example, a 50% by volume solution expands 4.8% with a 148°F temperature rise while water expands about 3% for the same temperature increase. Allowance for this expansion must be considered in sizing expansion tanks and related components.
- 5. The flow rate in systems utilizing glycol solutions should be higher than in a water system to compensate for decreased heating capacity of the fluid.
- Due to increased flow rate and fluid viscosity, the circulator head requirement will increase. Contact the pump manufacturer to correctly size the circulator for a particular application based on the glycol concentration and heating requirements.
- A strainer, sediment trap, or some other means for cleaning the piping system must be provided. It should be located in the return line upstream of the boiler and must be cleaned frequently during the initial operation of the system. Glycol is likely to remove mill scale from new pipe in new installations.
- 8. Glycol solution is expensive and leaks should be avoided. Weld or solder joints should be used where possible and threaded joints should be avoided. Make-up water should not be added to the system automatically when glycol solution is used. Adding make-up water will dilute the system and reduce the ability of the solution to protect from freezing.
- Check local regulations to see if systems containing glycol solutions must include a back-flow preventer or require that the glycol system be isolated from the water supply.
- 10. Do not use galvanized pipe in glycol systems.

- 11. Use water that is low in mineral content and make sure that there are no petroleum products in the solution.
 - a. Less than 50 ppm of calcium
 - b. Less than 50 ppm of magnesium
 - c. Less than 100 ppm (5 grains/gallon) of total hardness
 - d. Less than 25 ppm of chloride
 - e. Less than 25 ppm of sulfate
- 12. Check with the local water supplier for chemical properties of the water.
- The following test will determine if the water is of the appropriate hardness. Collect a sample of 50% water to 50% propylene glycol. Let the solution stand for 8-12 hours shaking it occasionally. If white sediment forms, the water is too hard and should not be used to dilute the glycol.
- 14. Mix the solution at room temperature.
- 15. Do not use a chromate treatment.
- 16. Refer to Technical Topics #2a published by the Hydronics Institute for further glycol system considerations.



Recommended Piping – One Boiler, Primary/Secondary with Two Zones (Zone Circulator) Figure 4.5:







Figure 4.7: Two Boilers, Primary/Secondary with Four Zones (Zone Circulator)



27



Figure 4.9: Three Boilers, Primary/Secondary with Four Zones (Zone Valves)

G. SPECIAL APPLICATIONS

- If the PUREFIRE® boiler is used in conjunction with a chilled medium system, pipe the chiller in a separate secondary loop.
 - a. Assure that the boiler circulator is disabled during chiller operation so that chilled water does not enter the boiler.
 - b. Install a flow control valve (spring check valve) to prevent gravity flow through the boiler.
 - c. See Figure 4.10 for recommended system piping for chiller operation.
- For boilers connected to heating coils in a forced air system where they may be exposed to chilled air circulation, install flow control valves or other automatic means to prevent gravity circulation of the boiler water during cooling cycles. See Figure 4.11 for an illustration.



Figure 4.10: Boiler in conjunction with a Chilled Water System



Figure 4.11: Boiler Connected to a Heating Coil in a Forced Air System

5. FUEL PIPING

A. GENERAL

- All fuel piping to the *PUREFIRE*^{*} boiler is to be in accordance with local codes. In the absence of local regulations refer to the National Fuel Gas Code, ANSI Z223.1/NFPA 54.
- Size and install fuel piping to provide a supply of gas sufficient to meet the maximum demand of all appliances supplied by the piping.
- PUREFIRE* boilers are intended for operation with Natural Gas or Propane with sulfur content of less than 105 ppm (150 mg/m³) peak with an annual average of less than 20 ppm (30 mg/m³). Excessive sulfur content in fuel input can result in black deposits resembling coffee grounds in the combustion chamber of the boiler.

B. FUEL LINE SIZING

1. The required flow rate of gas fuel to the boiler can be determined by the following.

Input Rate
$$(ft^3/hr) = \frac{Boiler Input Rate}{Gas Heating Value} \frac{(Btu/hr)}{(Btu/ft^3)}$$

The gas heating value can be supplied by the gas supplier.

- 2. As an alternative, use Table 5.1 to determine the required gas flow rate which uses typical heating values for natural gas and liquefied petroleum (LP) gas.
- 3. Table 5.2 shows the maximum flow capacity of several pipe sizes based on 0.3" of pressure drop.
 - a. The values shown are based on a gas specific gravity of 0.60 (Typical for natural gas).
 - b. Multiply the capacities listed by the correction factors listed for gas with a specific gravity other than 0.60 to obtain the corrected capacity.
- 4. Size and install the fuel gas supply piping for no more than 0.5 inches of water pressure drop between the gas regulator and the boiler.

C. GAS SUPPLY PIPING - INSTALLATION

- 1. Do not install any piping directly in front of the boiler or along either side. Always provide access to the front cover and side panel openings.
- 2. Install a sediment trap as shown in Figure 5.1. Be sure to allow clearance from the floor or other horizontal surface for removal of the pipe cap.

🕂 WARNING

Use a pipe joint sealing compound that is resistant to liquefied petroleum gas. A non-resistant compound may lose sealing ability in the presence of this gas, resulting in a gas leak. Gas leaks may potentially cause an explosion or fire.

Table 5.1: Required Fuel Input

	Required I	nput Rate*		
PureFire® Model	Natural Gas ft ³ /hr (m ³ /hr)	LP Gas ft ³ /hr (m³/hr)		
PF-50	50 (1.4)	20 (0.6)		
PF-80	80 (2.3)	32 (0.9)		
PF-110	110 (3.1)	44 (1.2)		
PF-140	140 (4.0)	56 (1.6)		
PF-200	199 (5.6)	79 (2.2)		
PF-210	210 (5.9)	84 (2.4)		
PF-300	300 (8.5)	120 (3.4)		
PF-399	399 (11.3)	166 (4.7)		

* Natural gas input rates are based on 1,000 Btu/ft³, LP input rates are based on 2,500 Btu/ft³.

Table 5.2: Pipe Capacity:

Maximum Capacity of pipe in cubic feet per hour (cubic meters per hour) with a pressure drop of 0.3" of water (75 Pa).

Pipe Length ft (m)	1/2" NPT Pipe	3/4" NPT Pipe	1" NPT Pipe	1-1/4" NPT Pipe	1-1/2" NPT Pipe
10	132	278	520	1,050	1,600
(3.0)	(3.7)	(7.9)	(14.7)	(29.7)	(45.3)
20	92	190	350	730	1,100
(6.1)	(2.6)	(5.4)	(9.9)	(20.7)	(31.1)
30	73	152	285	590	890
(9.1)	(2.1)	(4.3)	(8.1)	(16.7)	(25.2)
40	63	130	245	500	760
(12.2)	(1.8)	(3.7)	(6.9)	(14.2)	(21.5)
50	56	115	215	440	670
(15.2)	(1.6)	(3.3)	(6.1)	(12.5)	(19.0)
60	50	105	195	400	610
(18.3)	(1.4)	(3.0)	(5.5)	(11.3)	(17.3)
70	46	96	180	370	560
(21.3)	(1.3)	(2.7)	(5.1)	(10.5)	(15.9)
80	43	90	170	350	530
(24.4)	(1.2)	(2.5)	(4.8)	(9.9)	(15.0)
90	40	84	160	320	490
(27.4)	(1.1)	(2.4)	(4.5)	(9.1)	(13.9)
100	38	79	150	305	460
(30.5)	(1.1)	(2.2)	(4.2)	(8.6)	(13.0)

The values are based on a specific gravity of 0.60 (typical for natural gas). See Table 4.3 for capacity correction factors for gases with other specific gravities.

Specific Gravity	0.50	0.55	0.60	0.65	0.70	0.75
Correction Factor	1.10	1.04	1.00	0.96	0.93	0.90
Specific Gravity	0.80	0.85	0.90	1.00	1.10	1.20
Correction Factor	0.87	0.84	0.82	0.78	0.74	0.71
Specific Gravity	1.30	1.40	1.50	1.60	1.70	1.80
Correction Factor	0.68	0.66	0.63	0.61	0.59	0.58

- 3. Install a ground joint union between the sediment trap and the boiler to allow service to the appliance.
- 4. Install a service valve as shown in Figure 5.1 to allow the gas supply to be interrupted for service.
- 5. Maintain a minimum distance of 10 pipe diameters between the gas pressure regulator and the boiler.
- Check all gas piping for leaks prior to placing the boiler in operation. Use an approved gas detector, noncorrosive lead detection fluid, or other leak detection method. If leaks are found, turn off gas flow and repair as necessary.

🗥 WARNING

When checking for leaks, do not use matches, candles, open flames or other methods that provide an ignition source. This may ignite a gas leak resulting in a fire or explosion.

 Figure 5.1 shows the gas shutoff valve for the *PUREFIRE** boiler. This valve is to be used in addition to the gas service valve shown upstream of the sediment trap.



Figure 5.1: Gas Supply Pipe and Shut-off

D. GAS SUPPLY PIPING - OPERATION

- 1. The gas line must be properly purged of air to allow the boiler to operate properly. Failure to do so may result in burner ignition problems.
- 2. Table 5.3 shows the maximum and minimum fuel gas supply pressure to be measured at the gas valve inlet pressure tap. See figure 5.2.
 - a. Gas pressure below 3.5 inches of water column for Natural gas and 8 inches of water column for LP gas may result in ignition failures and hard ignitions.
 - b. Gas pressure above 13.5 inches of water may result in damage to the automatic gas valve.

CAUTION

Do not subject the gas valve to more that 1/2 psi (13.5" W.C.) of pressure. Doing so may damage the gas valve.

Fuel Turne	Pressure Inches W.C. (Pa)				
Fuel Type	Minimum	Maximum			
Natural Gas	3.5	13.5			
LP Gas	8	13.5			

- 3. To check the gas supply pressure to the gas valve:
 - a. Turn off the power at the service switch.
 - b. Close the gas shutoff valve.
 - c. Using a flat screwdriver, turn the screw inside the inlet tap fitting (see Figure 5.2) one turn counter clockwise.
 - d. Attach the tube from the manometer to the pressure tap fitting.
 - e. Open the gas valve and start the boiler.
 - f. Read and record the gas pressure while the boiler is firing at max input as well as with any other appliances to the same gas line at their maximum inputs.
 - g. Turn off the boiler and close the gas shutoff valve.
 - h. Remove the manometer tube from the pressure tap fitting.
 - i. Turn the internal screw clockwise to close the valve.
 - j. Turn on the gas shutoff valve and boiler service switch.
 - k. Fire the boiler and check for fuel gas odor around the gas valve. If an odor is evident check to make sure that the pressure tap fitting is closed.
- 4. All gas piping must be leak tested prior to placing the boiler in operation.
 - a. If the leak test pressure requirement is higher than 13.5 inches of water column, the boiler must be isolated from the gas supply piping system.
 - b. If the gas valve is exposed to pressure exceeding 13.5 inches of water column, the gas valve must be replaced.
- Install the boiler such that the gas ignition system components are protected from water (dripping, spraying, rain, etc.) during operation and service (circulator replacement, condensate collector and neutralizer cleanout, control replacement etc.)

FUEL PIPING

E. MAIN GAS VALVE - OPERATION

- 1. Figure 5.2 is an illustration of the gas valve/venturi assembly for the *PUREFIRE** boiler.
 - Adjustments should not be made to the gas valve without instrumentation to measure carbon dioxide (CO₂) and carbon monoxide (CO) emissions in the vent pipe.
 - b. Turning the throttle screw clockwise will decrease the gas flow (decreasing CO₂) and turning it counterclockwise will increase the gas flow rate (increasing CO₂). Markings adjacent to the throttle screw show + and – indicating this operation.
 - c. The recommended CO_2 settings are given in Table 5.4. In no case should the boiler be allowed to operate with CO emissions above 150 ppm.

Table 5.4: Recommended CO₂ Settings

	Natur	al Gas	Propa	ne (LP)
	Low Fire	High Fire	Low Fire	High Fire
Carbon Monoxide (CO)	< 75 ppm	< 150 ppm	< 75 ppm	< 150 ppm
Carbon Dioxide (CO ₂)	8.8% to 11.5%	8.5% to 9.7%	9.8% to 12.5%	9.5% to 10.5%
Excess Oxygen (O ₂)	0.7% to 5.4%	3.9% to 6.0%	1.9% to 6.0%	4.9% to 6.5%
Excess Air	3.2% to 31.2%	20.1% to 35.4%	8.9% to 35.9%	27.6% to 39.8%

1 Combustion measurements should be taken during steady state operation. Values during significant transitions may exceed the numbers shown.

 $2\,$ Conversions to excess oxygen and excess air are based on natural gas consisting of 100% methane (CH_4) or 100% propane (C_3H_8)

2. Refer to Section 3, Venting and Air Intake for information on obtaining vent samples from this boiler.



Figure 5.2: Gas Valve/Venturi

NOTICE

Instructions (PF8032) for converting from natural gas to LP gas and from LP gas to natural gas are included in the boiler folder.

6. CONDENSATE DRAIN PIPING

A. GENERAL

- 1. The disposal of all condensate into public sewage systems is to be in accordance with local codes and regulations. In the absence of such codes, follow these instructions.
- Proper piping and removal of condensation from combustion is critical to the operation of a condensing appliance. Follow these instructions carefully to assure that your *PUREFIRE** boiler operates correctly.
- 3. Depending on several factors, the condensate from gas fired condensing appliances may have a pH value as low as 2.5 (similar to cola soft drinks). Some local codes require the use of neutralization equipment to treat acidic condensate.

B. CONDENSATE SYSTEM

The *PUREFIRE®* condensate system is designed to prevent condensate from backing up into the heat exchanger, trap the condensate to prevent combustion gases from escaping and neutralize acidic condensate. Refer to Figure 6.1 for an illustration of the system components.



Figure 6.1: Condensate Trap System

1. Condensate Drain Hoses: The PF-50, PF-80, PF-110, and PF-140 boilers have two drain hoses attached to the heat exchanger. The first hose drains condensate from the combustion chamber of the boiler. The second hose drains condensate from the vent system. This prevents dirt and debris from the venting system from entering the heat exchanger and fouling the heating surface.

PF-200, PF-210, PF-300 and PF-399 boilers have only one drain attached directly to the combustion chamber. To prevent debris from entering the heat exchanger, a separate drain can be added to the vent system at the top bulkhead drain connection as shown in Figure 6.2. However, be sure to adequately trap any vent system debris. If the top bulkhead drain connection is NOT used, a $\frac{3}{4}$ " PVC or CPVC cap MUST be attached to the connection using proper solvent glue to prevent flue gasses from escaping from the vent system.



Figure 6.2: Separate Vent Condensate Drain Installation

- Condensate Collector Container: The condensate collector container is a transparent container in the base of the boiler near the back. This container collects the condensate and acts as a part of a trap to prevent combustion gases from escaping. The container is fitted with a level switch that will prevent the boiler from operating if the condensate line is clogged.
- 3. *Condensate Float Switch*: This switch will prevent the boiler from operating if the condensate outlet is clogged before the level of condensate reaches the heat exchanger.

CONDENSATE DRAIN PIPING

- 4. Condensate Neutralizer Container: The condensate neutralizer container is an additional transparent container near the front of the boiler. Fill this container with the condensate neutralizer provided. The neutralizer will be consumed during normal operation and should be checked occasionally to determine if additional neutralizer is necessary. Neutralizer is available in 1 lb bags (#54159) from your PB Heat Distributor.
- 5. *Bulkhead fitting*: The bulkhead fitting allows the condensate tubing to pass through the jacket without providing a path for leakage from the jacket. A PVC TEE is to be attached to the outlet of this fitting to prevent siphoning of the trap.
- 6. *Neutralizer*: Condensate neutralizer is provided in a package with the boiler to fill the condensate neutralizer container (Item 4).
- 7. *Neutralizer Cap*: This cap provides access for adding and inspecting the condensate neutralizer.
- 8. *Condensate Drain Tube*: This pre-formed tube connects the condensate system to the bulkhead fitting for attachment to an external drain.

C. CONDENSATE DRAIN PIPE MATERIAL

The condensate drain is to be piped using PVC, polypropylene, or other material resistant to acidic condensate. Do not use steel, brass or galvanized pipe for this purpose. The acidic condensate will attack most metals and corrode.

D. CONDENSATE DRAIN PIPE SIZING

The bulkhead fitting for condensate connection is for 3/4" schedule 40 PVC Pipe. Be sure to use 3/4" or larger tubing from the boiler to the drain.

E. CONDENSATE DRAIN PIPE INSTALLATION

1. Connect a 3/4" schedule 40 PVC Tee to the outlet of the bulkhead fitting as shown in Figure 6.3. Pipe from the bottom of the tee to a suitable drain.



Figure 6.3: Condensate Drain Piping

- 2. Be sure that the piping slopes away from the boiler with a pitch of 1/4" per foot of pipe.
- 3. If the boiler condensate drain is above the level of a gravity drain, a condensate pump should be used. Table 6.1 lists several available brands. Contact your PB Heat, LLC Distributor for availability.

Table 6.1: Recommended Condensate Pumps

Brand Name	Model Number
ITT Bell & Gossett	LS
Little Giant	VCMA-15UL
Beckett	CB151LSUL
Hartell	KT-15-1UL
7. ELECTRICAL CONNECTIONS

A. GENERAL

This appliance is to be wired in accordance with local codes and regulations as defined by the Authority having jurisdiction. In the absence of such local codes, the *PUREFIRE®* boiler is to be wired in accordance with the latest edition of the National Electrical Code, ANSI/NFPA 70.

B. CUSTOMER CONNECTIONS

- 1. Electrical knockouts are provided on the top panel of the boiler to connect supply wiring, circulator wiring and wiring to various instruments.
- 2. Electrical terminals are located behind the User Interface and can be accessed by loosening the two nuts shown in Figure 7.1.



Figure 7.1: Electrical Terminal Access

- a. Remove one of the nuts and leave the other fully loosened in order to leave the display interface panel connected to the appliance.
- b. The terminals can be removed by gently pulling them away from their wired blocks. This allows the installer to easily attach wires to the connector before plugging it into the block.

- 3. Figure 7.2 shows customer connections for the PF-50, PF-80, PF-110 and PF-140 boilers.
 - a. Terminals 1-10 on the left side are for low voltage customer connections to the CH thermostat, outdoor sensor, DHW sensor or thermostat, system sensor and low water cutoff contacts. The outdoor sensor is included. The DHW sensor (54157) and the system sensor (54156) are optional components and the low water cutoff, if used, is to be supplied by others.
 - Terminals 11-20 on the right side are for line voltage customer connections to DHW, CH, and General Circulators; voltage supply, and low water cutoff (LWCO) power output.
- 4. Figure 7.3 shows customer connections for the PF-200, PF-210, PF-300 and PF-399 boilers.
 - a. Terminals 1-10 on the left side are for low voltage customer connections to the CH thermostat, outdoor sensor, DHW sensor or thermostat, system sensor and low water cutoff contacts. The outdoor sensor is included. The DHW sensor (54157) and the system sensor (54156) are optional components and the low water cutoff, if used, is to be supplied by others.
 - b. Terminals 11 & 12 on the left side are for connecting multiple boilers together using a cascade link which is described in Section 8.
 - c. Terminals 15 & 16 are used with the OPTIONAL PFA-1 Interface board (part# 54271) for 0-10 volt input signal.
 - d. Terminals 17 through 26 on the right side are for line voltage customer connections to DHW, CH, and General Circulators; voltage supply, and low water cutoff (LWCO) power output.
 - e. Terminals 27 through 30 are a ground bus for any line voltage ground connections.
 - f. Terminals 31 & 32 are used with the OPTIONAL PFA-1 Interface board (part# 54271) for Alarm Contacts.



CUSTOMER CONNECTIONS: PF-50, PF-80, PF-110 AND PF-140

Figure 7.2: Customer Connections – PF-50, PF-80, PF-110 & PF-140

^{*} USE AN ISOLATION RELAY (RIB2401B OR EQUAL) TO POWER PUMPS AND/OR 3-WAY VALVES IF THE COMBINED LOAD EXCEEDS 3 AMPS.

CUSTOMER CONNECTIONS: PF-210, PF-300, PF-399 AND PF-460



** USE AN ISOLATION RELAY (RIB2401B OR EQUAL) TO POWER PUMPS AND/OR 3-WAY VALVES IF EXCEEDING 10 AMPS ON ANY PUMP TERMINAL.

Figure 7.3: Customer Connections – PF-200, PF-210, PF-300 and PF-399

5. Note that the service switch does not disconnect power to the convenience outlet.

C. ZONE CIRCULATOR WIRING

Wiring for a typical circulator zone relay is shown in Figure 7.4.



ZONE PUMP LOADS ARE CARRIED BY PUREFIRE CONTROL. IF CH ZONE PUMP LOADS PLUS GENERAL PUMP LOAD IS MORE THAN 3 AMPS, INSTALL RELAY TO ISOLATE CH PUMP TERMINAL



D. INTERNAL WIRING

Figure 7.5 shows the complete boiler wiring schematic for PF-50, PF-80, PF-110 and PF-140 boilers. Figure 7.6 shows the schematic wiring diagram for the PF-200, PF-210, PF-300 and PF-399 boilers. The following is a list of internal wiring components.

- 1. User Interface: The user interface is attached to the front of the electrical junction box and is accessible by removing the tinted lens on the front of the boiler. This interface allows users and installers to communicate with the control.
- Supply/Return Sensors: These component, located on the left header are a pair thermistors that provide supply and return water temperature information to the control. Be sure to use only a PUREFIRE* supply thermistors for this boiler.
- Limit Switch: This component is a bi-metal switch that will prevent the boiler from reaching temperatures above 203°F (95°C) to prevent damage to the boiler. Be sure to use only a PUREFIRE* supplied switch
- 4. *Flue Sensor*: This thermistor provides flue temperature information to the control. It is located in the back of the electrical junction box behind the user interface.
- 5. *Condensate Drain Float Switch*: This switch is mounted in the condensate collector below the heat exchanger in the rear of the cabinet.
- Service Switch: The service switch interrupts the power to the PUREFIRE® boiler to allow service to be performed.



ELECTRICAL CONNECTIONS



Figure 7.6: Internal Wiring Schematic for PF-200, PF-210, PF-300 & PF-399 boilers.

- 7. *Convenience Outlet*: The convenience outlet is provided for a condensate pump during operation. It is not switched with the service switch to allow its use for lighting during maintenance.
- 8. *Flame Sensor*: The flame sensor uses the principal of flame rectification to sense the burner flame. This is located on the right side of the heat exchanger front plate. After ignition, the control also senses flame through the ignition electrode.
- 9. *Gas Valve*: The gas valve is connected through a special cord and connector. The connector is attached to the valve with a screw.
- 10. *Ignition Electrode*: This electrode is located on the left side of the heat exchanger front plate. A 10,000 volt charge is initiated by the control to provide a spark for lighting the burner. After the burner lights, and no spark is present, the control uses this electrode as a second source of flame detection.
- Combustion Air Fan: The combustion air fan has two connections. There is a 120 volt power connection (3-wire) and a low voltage control connection (4-wire).
- 12. *Blocked Vent Switch:* This switch is only needed and used on PF-200/210/300/399 to detect a blockage on the exhaust vent.
- 13. PUREFIRE^{*} Link Adapter (Green Plug): The adapter is used by Factory Engineers to review control settings.
- 14. *Burner Plate Switch:* This switch (Part #50045) is used to detect overheating of the burner plate, primarily caused by broken insulation on the inside of the burner plate.

- 15. *Thermal Fuse:* This fuse (Part #54466) is used on the PF-200/210/300/399 to detect overheating of the back of the combustion chamber, primarily caused by a broken target wall insulation panel on the back of the combustion chamber.
- 16. *Relay Module:* This module is used on the PF-200/210/300/399 to allow circulator pumps with a maximum draw of 10 Amps each for DHW, CH, and General to be connected to terminals 17/18, 19/20, and 21/22 respectively.

NOTICE

Maximum Amp Draw for circulator pumps on PF-50/80/110/140 is 3 amps TOTAL for either General Pump + DHW pump OR General Pump + CH Pump.

NOTICE

If the fuse blows in the boiler control, a spare fuse (found in a holder on the control cover) can be used as a replacement. DIAGNOSE POSSIBLE CAUSES FOR BLOWN FUSE BEFORE REPLACING. Additional fuses can be ordered as need from your Peerless Boiler Distributor (Part #5650). See Figure 10.1 for location of Boiler Control fuse and spare fuse.

NOTICE

Relay module fuses are rated for 10 amp resistive load. For inductive loads use 7.5 amps.

8. BOILER CONTROL: INTERNAL WIRING & OPERATION

A. CONTROL OVERVIEW

The *PUREFIRE*[®] boiler control is one of the primary safety devices for the boiler. It controls the ignition sequence, temperature limits, circulators and gas flow to the boiler. It also provides many unique features.

The control provides 8 central heating modes and 3 domestic hot water modes. To provide maximum flexibility, several special features are also included.

1. Central Heating (CH) Modes:

The *PUREFIRE*[®] boiler control allows the installer to choose from several different central heating modes. The following table shows the central heating modes. In addition, the table shows the display text associated with each CH mode and a brief description of the operation.

 Domestic Hot Water (DHW) Modes: The PUREFIRE* boiler control also allows the installer to choose from three different DHW modes.

Table 8.1: Central Heating (CH) Modes

Central Heating Mode	Description	Restrictions
0 (Indoor Thermostat)	Fixed Setpoint	Not for space heating
1 (Thermostat and Outdoor Reset)	Outdoor Reset	No restrictions
2 (Permanent Demand and Outdoor Reset)	Outdoor Reset	No restrictions
3 (Permanent Demand and Setpoint)	Fixed Setpoint	Not for space heating
4 (Analog 0-10 VDC Input – Setpoint)	Analog Input	External Energy
5 (Analog 0-10 VDC Input – Modulation Rate)	Analog Input	Management System
6 (Hydro-Air Unit)	Fixed Setpoint	Not for space heating
7 (Internal Reset) Default *	Internal Reset	No restrictions

Table 8.2: Domestic Hot Water (DHW) Modes

Domestic Hot Water Mode	Description
0 (No DHW)	No DHW tank is used.
1 (DHW Tank with sensor)	The domestic water tank is equipped with a temperature sensor. The <i>PUREFIRE</i> [®] control modulates the boiler firing rate based on tank temperature
2 (DHW Tank with thermostat)	The domestic water tank is equipped with a thermostat. The <i>PUREFIRE</i> [*] control responds to the demand from the thermostat and modulates the boiler firing rate targeting the DHW boiler setpoint. If no domestic hot water tank is connected, this feature will not function.

Table 8.3: Pump Modes

Pump Mode	Display Text Brief Description					
0	DHW or CH & DHW pump	The General pump is always on when the burner is on. The CH pump runs on CH demand. The DHW pump runs on DHW demand. Either the CH or DHW pump runs; they never run at the same time				
1	General pump with 3-way valve	The General pump is always on when burner is on. A line voltage (120 VAC) 3-way valve is operated to supply water to the DHW tank.				
2	Manifold with pump for DHW	This mode is not used for most operations. Consult factory if needed.				

3. Special Features:

The *PUREFIRE*[®] control offers several special features to give the installer options in setting up the boiler. These options are shown in the following table and described in detail later in this section.

Table 8.4: Control Features

Feature	Description
System Response Time	Allows the installer to adjust the response time of the burner modulating control. This can be set differently for central heating (CH) or domestic hot water (DHW) demands. This is known as "I" value.
Maximum Firing Rate	Allows the installer to adjust the maximum firing rate of the burner modulating control. This can also be set differently for CH or DHW demands.
Cascade	Up to 16 boilers can operate together in stages to satisfy the CH or DHW demand.
One Hour Retry	One hour after a lockout on ignition, fan speed or flame failure, the <i>PUREFIRE</i> [*] control will reinitiate boiler operation.
Adjustable Blower Postpurge	The blower postpurge may be increased to counteract the effects of high winds or unusual wind currents.
Flame Signal Log	This troubleshooting tool captures the flame signal at four increments during the two second flame proving period. This will help service people to quickly diagnose problems with flame rectification.
Freeze Protection	Activates pumps if water temperatures fall below the specified value. If the temperature continues to fall, the burner is activated.
DHW Tank Warm Hold	Prevents the boiler from ramping up to high power if the control determines that the DHW demand is only due to tank standby losses.
Additional Safety Functions	Allows the installer to choose between a low water cutoff and a flow switch for water level safety shutdown.
Vent Temperature Safety Limit	Reduces the firing rate if the exhaust vent temperature approaches the maximum limit of the vent material specified. The control will shut down the burner if the temperature continues to climb.
System Type Presets	Automatically sets the reset calculation based on the type of heat distributions (finned tube baseboard, cast iron radiators, cast iron baseboard, low or high mass radiant).
Temperature Boost	Increases the boiler supply temperature target if the control determines that the load cannot be met at the current reset temperature (Outdoor Reset Modes).
Warm Weather Shutdown	Shuts down the boiler if the outdoor temperature exceeds an installer defined limit (Outdoor Reset Modes).
Limited DHW Priority	The <i>PUREFIRE</i> [*] control provides DHW priority for boiler operation. The control will switch back to CH if a demand remains present for an installer set switch time.
System Test	The <i>PUREFIRE</i> [*] boiler will allow the installer to operate the boiler at low power, ignition power or high power for setup and troubleshooting.
Fault History	This mode is not used for most operations. Consult factory if needed.

B. IGNITION SEQUENCE

Figure 8.1 shows the ignition sequence for the *PUREFIRE*[®] boiler control. Table 8.5 describes each step in the sequence in detail. The *PUREFIRE*[®] boiler control provides dual sensing of the flame to maximize the reliability. The control senses the burner flame with both the flame sensor and the ignition electrode.

Igntion Cycle

	Standby	Pre-Purge	Pre-Ignition Safe	ty Oi		ff Burner On	Post Purge 1	Post Purge 2	Circulator Post Purge	State
Demand	Ľ			= =	c = c =					On Off
Fan						\bigcirc	(High Ignition Low Off
Pump	Ţ			= =						On Off
Gas Valve					 					On Off
Ignitor					Ľ					On Off
Flame Signal				==	Ć					On Off
		5 seconds	2 seconds	4 seconds	2 seconds	Maximum 24 hours 0 milliseconds	10 seconds maximum	30 seconds minimum	Depends on boiler settings	

Figure 8.1: Ignition Cycle – Graphical Representation

Table 8.5: Ignition Sequence

Period	Demand Status	User Interface Display							
Standby	No demand is present	16:36 STANDBY 160°F							
	If the power is on to the <i>PUREFIRE</i> [*] boiler and there is no heat demand, the user interface will display "Standby" and show the boiler supply temperature in the lower right corner. The time, in 24 hour format, is shown in the upper right. When a heat demand (either CH or DHW) is present, the boiler begins the ignition cycle.								
Pre Purge	A CH or DWH demand must be present to initiate ignition. Once initiated the boiler will light.	16:36 CENTRAL HEATING Trial For Ignition							
Fie Purge	When a demand is present, the <i>PUREFIRE</i> [*] control starts the combuuser interface displays the Source of the call for heat along with "T stable or until a fault occurs. Once the ignition sequence begins it	5							

BOILER CONTROL: INTERNAL WIRING & OPERATION

Period	Demand Status	User Interface Display
Safety On/Off	A heat demand has no influence in the Safety On/Off period. The Safety On/Off step will continue even if the demand has ended.	16:36 DOMESTIC HOT WATER Trial For Ignition
	This step very quickly opens and closes the gas valve relays and de off during this test.	termines if the control is operating correctly. The CH pump is turned
Pre-Ignition	A heat demand has no influence in the Pre-Ignition period.	16:36 CENTRAL HEATING Trial For Ignition
Ignition	A heat demand has no influence in the Ignition period.	16:36 CENTRAL HEATING Ignition Retry 16:36 NO IGNITION Fan Post Purge
	turned off and the control checks for a flame signal through both the the end of the Ignition period, the control initiates a post-purge and tl ignition failures, the control will post purge and lockout. The control	ignition electrode and the flame sensor. If no flame signal is present at nen begins the ignition cycle again. If there are three consecutive records 4 flame signal values during the final 2 seconds of this
Burner On	A heat demand must be present for the control to stay in this period.	16:36 CENTRAL HEATING 100%Input 160°F
	occurs. The maximum run period for the burner is 24 hours. If the	boiler runs continuously for 24 hours, the control will override the
Post Purge 1	After the Post Purge period begins, a heat demand will be ignored until after this period.	16:36 CENTRAL HEATING Fan Post Purge
	a fety On/Off step will continue even if the demand as ended. Image: Control is control, the CH pump is if during this test. heat demand has no influence in the Pre-ignition period. Image: CE ENTRAL HEATING Trial For Ignitic nee the internal check is complete, the control begins a Pre-ignition sequence. The igniter is energized while the gas valve rema a fame is detected at the end of the pre-ignition period. Image: CE ENTRAL HEATING Trial For Ignitic heat demand has no influence in the ignition period. Image: CE ENTRAL HEATING Trial For Ignitic Image: CE ENTRAL HEATING Trial For Ignitic heat demand has no influence in the ignition period. Image: CE ENTRAL HEATING Trial For Ignitic Image: CE ENTRAL HEATING Trial For Ignitic heat demand has no influence in the ignition period. Image: CE ENTRAL HEATING Trial For Ignitic Image: CE ENTRAL HEATING Trial For Ignitic heat demand has no influence in the ignition period. Image: CE ENTRAL HEATING Trial For Ignitic Image: CE ENTRAL HEATING Trial For Ignitic heat demand has no influence in the ignitic period. Image: CE ENTRAL HEATING Trial For Ignitic Image: CE ENTRAL HEATING Trial For Ignitic is period. Image: CE ENTRAL HEATING Trial For Ignitic Image: CE ENTRAL HEATING Trial For Ignitic is period. Image: CE ENTRAL HEATING Trial For Ignitic Image: CE ENTRAL HEATING For Ignit is peri	re that the flame has extinguished. If a flame is detected after the
Post Purge 2	During this period a heat demand has no effect on operation.	16:36 SUPPLY AT SETPOINT Fan Post Purge
	During this period, the combustion air fan runs at high speed to pu purge period is 30 seconds. It is adjustable up to 120 seconds.	rge combustion gases from the heat exchanger. The default fan post
Pump Purge	No heat demand is present.	
	The operation of the circulators and the boiler depend on the pum	p mode and the heat demand status.

C. BOILER CONTROL

- 1. Installation Location & Vent Material:
 - The *PUREFIRE*[®] boiler allows the installer to input the installation location and the vent material used. This information is used to determine the suitable vent temperature limit based on National Codes. Table 8.6 shows the vent temperature limit based on the location and vent material. The Vent Material selection can be found in the Installer Menu \rightarrow CH Settings.

Table 8.6: Vent Temperature Limits

Vent Limit Temperature										
Vent	Loca	tion								
Material	U.S.A.	Canada								
PVC	190°F (80°C)	149°F (65°C)								
CPVC	230°F (110°C)	190°F (80°C)								
PP(s)	230°F (110°C)	230°F (110°C)								

The *PUREFIRE*[®] control will reduce the boiler firing rate if the vent temperature approaches the vent temperature limit. If the vent temperature continues to rise, the control will shut down the boiler.

2. Freeze Protection:

The *PUREFIRE*[®] boiler control is intended to prevent the central heating system from freezing. The default temperature to activate this function is 50°F (10°C).

If the supply temperature drops to below the freeze protection setpoint, the general pump and/or the CH pump (depending on pump mode) will be activated. If the supply or return temperature drops more than 9°F (5°C) below the setpoint, the control lights the boiler using the ignition sequence described in section 8.B.

The control will operate the burner at minimum power until the both the supply and return boiler temperature are more than $9^{\circ}F$ ($5^{\circ}C$) above the freeze protection setpoint.

While this function is active the interface panel will display the following:

														1	6		3	6
С	Е	Ν	Т	R	Α	L		Н	Ε	Α	Т	I.	Ν	G				
F	r	е	е	z	е		Ρ	r	0	t	е	С	t	i	0	n		
		1	%		n	р	u	t						1	6	0		F

3. Blower Postpurge Time:

The *PUREFIRE*[®] boiler control allows the installer to change the burner postpurge timing. This is useful under extreme conditions where high winds and unusual wind currents prevent proper purging of the combustion chamber.

This parameter is adjustable from 30 seconds to 120 seconds with the 30 second minimum as its default. It is important to note that increased purge times may slightly reduce the boiler efficiency.

4. Additional Safety Functions:

The *PUREFIRE*[®] boiler control is equipped with terminals for either a low water cutoff or a flow switch. The low water cutoff option is the factory default and a factory supplied jumper is installed. This jumper is to be removed if a low water cutoff or flow switch is installed. Low Water Cutoff: Connect the power supply wires for a probe type low water cutoff to the 120 vac LWCO terminals (#19 & #20 for PF-50/80/110/140); #25 & #26 for PF-200/210/300/399)in the main terminal box. The contacts should be wired to terminals #9 & #10.

🟦 DANGER

Be sure that THERE IS NOT A JUMPER in the probe type low water cutoff which would supply 120 volts to the contact terminals. Failure to remove the jumper will result in damage to the boiler controls.

<u>Flow Switch</u>: If a flow switch is used, simply wire the contacts to terminals #9 and #10 in the main terminal box.

D. CENTRAL HEATING

1. Heating Modes:

Table 8.1 provides an overview of the central heating (CH) modes. The following are detailed descriptions of the operation of these modes. In accordance with Federal regulations under the Energy Policy and Conservation Act of 2012, all boilers must be equipped with a feature that saves energy by reducing the boiler water temperature as the heating load decreases. This feature may be equipped with an override feature to allow the use of an external energy management system that serves the same function.

<u>Mode 0 – Indoor Thermostat</u>: This mode responds to a thermostat contact closure between terminals #1 & #2 in the electrical panel to target a fixed supply (outlet) temperature selected in the User Menu. Based on the Federal regulations this mode cannot be used for space heating unless the boiler is the managing boiler of a multiple boiler cascade system having a total input of 300,000 btu/hr or greater.

NOTICE

Before selecting a mode that requires an outdoor sensor, connect the outdoor sensor to terminals #3 & #4. Failure to do this will result in a blinking screen warning as covered in Section 10.D.

> <u>Mode 1 – Thermostat and Outdoor Reset</u>: This mode responds to a thermostat contact closure between terminals #1 & #2 in the electrical panel to target a temperature calculated by the control. In this mode, the installer selects the temperatures which define the target temperature based on the current outdoor temperature. As the outdoor temperature increases, the target temperature is decreased. Detailed explanations of the operating principal and the settings for this mode are provided below in subsection 3.

The factory default settings will target a supply temperature of 180°F when the outdoor temperature drops to 10°F or below. The target supply (outlet) temperature will be 70°F when the outdoor temperature is 70°F. <u>Mode 2 – Permanent Demand and Outdoor Reset</u>: Mode 2 operates much like Mode 1 except that no thermostat contact closure is required between terminals #1 & #2 in the electrical panel to operate the boiler. The boiler will attempt to constantly maintain the target temperature calculated by the control. The factory defaults for this mode are the same as in Mode 1. Details for outdoor reset are covered in subsection 3 below.

A contact closure between terminals #1 & #2 will result in a target temperature setback of 18°F. This feature may be used in conjunction with a timer or switch for unoccupied setback periods.

<u>Mode 3 – Permanent Demand</u>: Mode 3 also operates without a thermostat closure although it targets a fixed temperature selected from the User Menu. *Based on the Federal regulations this mode cannot be used for space heating unless the boiler is the managing boiler of a multiple boiler cascade system having a total input of 300,000 btu/hr or greater.*

<u>Mode 4 – 0-10 VDC Input to Modulate Setpoint</u>: The optional PFA-1 Interface Adapter Kit (54271) allows the control to accept an analog 0-10 VDC external signal which changes the target supply temperature. A minimum input of 2 VDC is required to activate the boiler. Voltage inputs between 2 &10 VDC will proportionally adjust the boiler outlet temperature target.

This mode is commonly used in conjunction with a Building Management System (BMS) to control the boiler outlet target based on the building requirements.

<u>Mode 5 – 0-10 VDC Input to Modulate Firing Rate</u>: In this mode, the optional PFA-1 Interface Adapter Kit (54271) accepts an analog 0-10 VDC external signal to directly control the boiler input rate. Similar to Mode 4, a minimum input of 2 VDC is required to activate the boiler. At 2 volts the display will show 1% of modulation which is equivalent to the minimum input. 10 VDC will cause the modulation to increase to 100% of input. The input rate between these two points is proportional to the signal. Note that the boiler high limit is set a 210°F and will cause a lockout if this temperature is reached.

<u>Mode 6 – Hydro-Air Units</u>: This mode is specifically designed for boiler supplying hot water to a hot water

coil in a forced air heating system using fixed supply target and activated by a thermostat contact closure between terminals #1 & #2 in the electrical panel.

Based on the Federal regulations this mode cannot be used for space heating unless the boiler is the managing boiler of a multiple boiler cascade system having a total input of 300,000 btu/hr or greater.

Using CH Mode 1 with the Hydro-Air presets described below in subsection 3 is likely a better option for this operation.

<u>Mode 7 – Internal Reset</u>: This is the default setting for the CH Mode. In this mode, the control calculates the target supply (outlet) water temperature based on the frequency and duration of central heat (CH) demand from the thermostat contact closure between terminals #1 & #2 in the electrical panel.

- As the thermostat demands become longer and more frequent, which indicates a larger heating load, the boiler supply target temperature will increase.
- As the thermostat demands become shorter and less frequent, indicating a smaller heating load, the boiler supply target temperature will decrease.

The rate of temperature change can be adjusted to enhance the efficiency and comfort level. Figure 8.2 shows how the boiler supply target temperature increases and decreases over time depending on whether or not there is a call for heat. The graph shows the default values for all of the settings which affect CH Mode 7. Table 8.7 shows these values.

Table 8.7: CH Mode 7 Menu Settings

Menu Setting	Minimum	Default	Maximum
Increment (Temp. Increase)	0.9°F	1.8°F	36.0°F
Decrement (Temp. Decrease)	0.9°F	0.9°F	36.0°F
Boiler Design Temperature	60°F	180°F	189°F
Mild Weather Boiler Temp.	35°F	120°F	160°F

The target boiler water temperature will not increase beyond the Boiler Design Temperature or decrease below the Mild Weather Boiler Temperature.



Figure 8.2: Internal Reset Operation

2. Setpoint operation:

When operating in CH mode 0, 3 or 6 the user can select a target temperature for the boiler supply. The control modulates the boiler based on three conditions: 1) The difference between the current supply temperature and the target; 2) The speed with which the supply temperature increases; and 3) The speed at which the system reacts to the temperature increase.

When the boiler supply temperature approaches the target setpoint, the burner will modulate down to decrease the input. If the temperature begins to decrease, the control will increase the input rate.

3. Outdoor Reset Operation:

To maximize fuel savings, *PUREFIRE** boilers are factory equipped for outdoor reset operation. The following describes the operating principal of this feature.

Operating Principle:

- Heat Loss decreases as Outdoor Temperatures increases.
- Heat distribution system is sized for Design Conditions (Coldest Outdoor Temperature).
- Boilers operate more efficiently at lower water temperatures.
- Condensing boilers have no minimum return water temperature.

The integrated control system on the *PUREFIRE*^{*} boiler adjusts the boiler supply setpoint based on outdoor temperature. In the installer menu, under "CH Settings" there are two parameters that define the design point of the boiler. The design point represents the conditions for which the boiler was sized.

Figure 8.3 shows a graphical representation of Outdoor Reset operation. The bold line shows the target supply temperature under the conditions indicated.

Boiler Design Temperature: The boiler design temperature required to heat the boiler under a design load is called Boiler Design Temperature. Figure 8.3 shows this at 160°F. This indicates that at any outdoor temperature below the design temperature the control will target 160°F unless the Boiler Maximum (described later) is set lower than this temperature. The factory default value for Boiler Design Temperature is 180°F (82°C).

<u>Outdoor Design Temperature</u>: The Outdoor Design Temperature is the outdoor temperature used to calculate the heat loss from the building. Figure 8.3 shows this at 10°F.

Commonly used values for this can be found in Table 8.8: Outdoor Design Temperature for Many North American Cities. The factory default for this value is 0°F (-18°C).

<u>Mild Weather Boiler Temperature</u>: This is the temperature required to heat the space under a minimum load. Table 8.7: System Type Presets, shows recommended values for this temperature setting based on the heat distribution system type. Figure 8.3 shows this temperature at its factory default of 70°F (21°C). Note that, depending on the type of heat distribution used, this value should be set higher. For example, if the boiler targets 70°F when a hydro air heater is used, relatively cold air is likely to be supplied to the space if there is no thermostat to keep it from running.

<u>Mild Weather Outdoor Temperature</u>: This is the outdoor temperature at which the boiler should operate at its minimum heating load. Figure 8.3 shows this value at the factory default value of 70°F (21°C). At any outdoor temperature above this value, the boiler will target the Mild Weather Boiler Temperature until the outdoor temperature exceeds the Warm Weather Shutdown Temperature (described later). Note that this is limited by the Boiler Minimum Temperature (described later).

<u>System Type Presets</u>: The *PUREFIRE*^{*} Control allows the installer to select preset values for Boiler Design Temperature and Mild Weather Boiler Temperature based on the type of heat distribution used. Table 8.8 shows the system types and the corresponding boiler temperatures.

Table 8.8: System Type Presets

	Temperatures							
System Type	Boiler Design	Mild Weather Boiler						
1. Finned Tube Baseboard	180	140						
2. Hydro Air Unit	189	140						
3. Cast Iron Radiator	160	120						
4. Cast Iron Baseboard	150	110						
5. Low Mass Radiant	140	70						
6. High Mass Radiant	120	70						
7. User Defined (Default)	180	70						

Type #7 is designated user defined and shows the default boiler temperatures. Once this choice is selected, the installer can change the numbers as desired.

<u>Boiler Minimum</u>: This value is the lower limit of the boiler target temperature. Figure 8.3 shows that a Boiler Minimum temperature of 80°F will not allow the target to drop below this value.

This is useful if the boiler is used in conjunction with a fan coil unit, kick space heater, unit heaters or other instance where a low boiler supply temperature can cause uncomfortable conditions. The default value for Boiler Minimum is OFF.

Boiler Maximum: If the boiler is installed in an installation where high water temperatures can cause damage to tubing or floors, this will limit the maximum temperature that can be achieved. Figure 8.3 shows this value at 150°F, which is below the Boiler Design Temperature. Notice that the target temperature will not exceed the Boiler Maximum. The default value for Boiler Maximum is 185°F (85°C).

<u>Boost Function</u>: The boost function increases the boiler supply target temperature by the value, "Temp", if the demand is not satisfied in the value, "Time." Both of these values are selected by the installer. The default for these values are as follows: Temp = $0^{\circ}F$ and Time = 255 minutes.

This function is designed to help the boiler recover from a setback condition. It will also help if too low of a value is chosen for the boiler design and/or mild weather temperature.

This value will continue to increase by the Temp value if the demand continues through consecutive Time periods.

The value is allowed to exceed the design temperature but can never exceed the boiler maximum temperature.

NOTICE

If thermostat terminals #1 & #2 are installed with a permanent jumper in CH mode 1, Thermostat and Outdoor Reset, the boiler target will eventually reach and remain at Boiler Maximum indefinitely even with Boost Temp and Time set to 0. In this case CH mode 2 would be a better choice for Permanent Demand with Outdoor Reset.

> Warm Weather Shutdown: In any CH mode utilizing outdoor reset, the warm weather shutdown feature prevents the boiler from operating if the outdoor temperature (read from the outdoor sensor) exceeds the selected value. The default value for Warm Weather Shutdown is 70°F (21°C).

> Figure 8.3 shows a graphical representation of this value (vertical line) at 75°F outdoor temperature. This feature only affects CH demands. The boiler will operate for DHW demands regardless of outdoor temperature.

4. Other Features:

<u>Pump Post Purge</u>: The *PUREFIRE*[®] control allows the installer to set post purge times for the CH and/or General Pumps. The circulator will continue to run for the time selected after the call for heat has ended.

These values are settable from 0 to 900 seconds and the factory default is 60 seconds.

<u>Ramp Delay Step Modulation</u>: This feature is useful for systems with very small zones which can cause a boiler to short cycle. The Ramp Delay Step Modulation function only applies to Central Heating and is not applied to DHW demands.

After the ignition sequence, the control modulates down to 20% of input. Then the input rate is gradually increased until the supply temperature approaches its target. At this time, the control modulates normally.

<u>Anti-Cycling</u>: The *PUREFIRE®* boiler control allows the installer to set a minimum off time to prevent short cycling of the boiler. This only affects short cycling due to reaching the temperature limit setpoint. If the CH or DHW demand cycles, the control will cycle to match the demand.

The minimum off time can be set from 0 to 15 minutes in 1 minute increments. It has a default of 3 minutes.

The value for "TDiff" is the difference in temperature between the supply temperature and the target temperature that will override the minimum off time. This temperature difference indicates the presence of a substantial heat load.

The default value for TDiff is 30°F and can be set to values between 20°F and 40°F. TDiff can also be disabled by choosing "Off". To do this push the down arrow until "Off" is displayed.



Figure 8.3: Outdoor Reset Operation

BOILER CONTROL: INTERNAL WIRING & OPERATION

City	State	0	DT	City State OD		DT	City	State	ODT		
Mobile	AL	29°F	-2°C	Springfield	IL	2°F -17°C		Albuquerque	NM	16°F	-9°C
Anchorage	AK	-18°F	-28°C	Indianapolis	IN	2°F	-17°C	New York City	NY	15°F	-9°C
Juneau	AK	1°F	-17°C	Des Moines	IA	-5°F	-21°C	Rochester	NY	5°F	-15°C
Flagstaff	AZ	4°F	-16°C	Wichita	KS	7°F	-14°C	Greensboro	NC	18°F	-8°C
Tucson	AZ	32°F	0°C	Bowling Green	КҮ	10°F	-12°C	Fargo	ND	-18°F	-28°C
Little Rock	AR	20°F	-7°C	New Orleans	LA	33°F	1°C	Columbus	ОН	5°F	-15°C
Fayetteville	AR	12°F	-11°C	Bangor	ME	-6°F	-21°C	Tulsa	ОК	13°F	-11°C
Sacramento	CA	32°F	0°C	Portland	ME	-1°F	-18°C	Portland	OR	24°F	-4°C
San Diego	CA	44°F	7°C	Baltimore	MD	13°F	-11°C	Philadelphia	PA	14°F	-10°C
San Francisco	CA	38°F	3°C	Boston	MA	9°F	-13°C	Pittsburgh	PA	5°F	-15°C
Boulder	CO	8°F	-13°C	Springfield	MA	0°F	-18°C	Charleston	SC	28°F	-2°C
Denver	CO	1°F	-17°C	Detroit	MI	6°F	-14°C	Sioux Falls	SD	-11°F	-24°C
Hartford	СТ	7°F	-14°C	Marquette	MI	-8°F	-22°C	Dallas	ΤХ	22°F	-6°C
Waterbury	СТ	2°F	-17°C	Minneapolis	MN	-12°F	-24°C	Salt Lake City	UT	8°F	-13°C
Wilmington	DE	14°F	-10°C	Jackson	MS	25°F	-4°C	Burlington	VT	-7°F	-22°C
Orlando	FL	38°F	3°C	St. Louis	MO	6°F	-14°C	Richmond	VA	17°F	-8°C
Tallahassee	FL	30°F	-1°C	Billings	MT	-10°F	-23°C	Seattle	WA	27°F	-3°C
Atlanta	GA	22°F	-6°C	Omaha	NE	-4°F	-20°C	Spokane	WA	2°F	-17°C
Boise	ID	10°F	-12°C	Carson City	NV	9°F	-13°C	Morgantown	WV	8°F	-13°C
Idaho Falls	ID	-6°F	-21°C	Manchester	NH	-3°F	-19°C	Green Bay	WI	-9°F	-23°C
Chicago	IL	-4°F	-20°C	Atlantic City	NJ	13°F	-11°C	Cheyene	WY	-1°F	-18°C

Table 8.9: Outdoor Design Temperature (ODT) – U.S. Cities

Maximum CH Input Limit: The PUREFIRE® control allows the installer to limit the maximum input of the boiler under a CH load if desired. This can be used when the boiler is sized primarily for a DHW load and is oversized for the CH load. This can be set between 50% and 100% and the default is 100%.

<u>CH Response Time</u>: This feature allows the installer to adjust the response time of the boiler. The "I" value is adjustable from 15 to 100 with 15 providing the fastest response. The default value is 70. If the boiler achieves its target very quickly with limited modulation, increase the "I" value to reduce the response time. If the boiler modulates very slowly to its target and has problems keeping up with the load, reduce the "I" value to increase the response time.

E. DOMESTIC HOT WATER (DHW)

1. DHW Modes:

Table 8.2 provides an overview of the domestic hot water modes. The following are detailed descriptions of the operation of these modes:

<u>Mode 0 – No DHW</u>: When this mode is selected, the control will not respond to either a thermistor signal or a contact closure at the DHW terminals (#5 & #6). There is also no output to DHW Pump Terminals.

<u>Mode 1 – DHW Store with Sensor</u>: In this mode, the *PUREFIRE®* control accepts a temperature input from an optional domestic tank sensor (54157). This sensor provides the DHW water temperature value to the control. The control targets the user selected DHW setpoint and modulates the boiler firing rate accordingly.

\Lambda WARNING

Be sure to use only the tank sensor indicated. Other sensors will not provide accurate tank temperatures and may cause severe personal injury due to scalding.

NOTICE

Before selecting Mode 1, connect the DHW sensor to terminals #5 & #6. Failure to do this will result in a blinking screen warning as covered in Section 10.D.

\land DANGER

Water temperatures over 125°F can instantly cause severe burns or death from scalding. Children, elderly and disabled individuals are at the highest risk of scalding. See instruction manual for the indirect tank before setting the water heater temperature. Instruct users to feel the water temperature before bathing or showering. Anti-scald valves are recommended.

> <u>Mode 2 – DHW Store with Thermostat</u>: This is the default mode for the control. In this mode, the *PUREFIRE®* control is connected to the DHW tank temperature limit. When the limit closes, the control modulates the boiler firing rate to target a boiler supply setpoint. This setpoint is a user selected value with a factory default of 180 °F. The allowable range for this value is 134°F to 189°F.

NOTICE

The "Store Warm Hold" function will not be functional if the DHW tank mode is set to 2. This requires a DHW tank sensor.

2. DHW Priority:

The *PUREFIRE®* boiler control provides limited domestic hot water priority with an installer selectable maximum time limit.

DHW	SE	ТТ	I	Ν	G	S						2	
CH/ Tim		W	S	w		t	С	3	0	m	i	n	▼

The CH/DHW Switch Time indicates the maximum amount of time that the boiler should operate to satisfy a CH demand or a DHW demand.

If there is a domestic hot water demand during a call for central heating, the control will immediately shut down the CH pump, start the DHW pump and target the DHW setpoint.

The control will continue to target the DHW setpoint until the time limit is reached or the demand is satisfied. Then, if there is still a CH demand, it will shut down the DHW pump, start the CH pump and target the required CH temperature.

If there is a central heating demand during a DHW call, the boiler will continue targeting the DHW setpoint with the DHW pump operating and the CH pump idle until the time limit is reached.

For example, if the CH/DHW Switch Time is set for 30 minutes, and a CH demand is activated after 6 minutes of a DHW call the following will occur. The boiler will continue to target the DHW setpoint and the DHW pump will continue to run for the remaining 24 minutes. After which time, the control will shut down the DHW pump, start the CH pump and target the required CH temperature.

3. Store Warm Hold:

When using a DHW tank sensor, the *PUREFIRE*[®] boiler control can detect if the DHW heat demand is required only to overcome standby heat loss in the tank and is not a result of a hot water draw. In this instance, the burner will fire at low power (1% on the display) and continue until the tank setpoint is satisfied.

4. Heat Dump Function:

Brookhaven National Laboratories have performed studies that show diverting excess boiler heat to the DHW tank after a CH demand will greatly improve the system efficiency of the boiler installation. The Heat Dump Function is designed to take advantage of this.

Essentially the boiler will operate normally on a call for heat. Once the call for heat ends, the pumps will operate to dump heat to the indirect tank. Which pumps operate depends on the pump mode and DHW mode selected.

- <u>Pump Mode 0 DHW Mode 1 & 2</u>: The DHW pump will operate to divert excess boiler heat to the indirect tank. The CH pump shuts down until this is accomplished.
- <u>Pump Mode 1 DHW Mode 1 & 2</u>: The General pump will operate and the 3-way valve will direct excess boiler heat to the indirect tank.

Pump Mode 2 – DHW Mode 1 & 2: The General pump will operate with the DHW pump to direct excess boiler heat to the DHW Tank. The CH pump is deactivated.

The pumps/3-way valves operate to dump heat to the DHW tank until the return temperature is less than the installer selected "Min Diff" temperature or until the "Max Time" limit is reached. This function can be disabled by choosing "Off" on the menu under "DHW Heat Dump."

5. Maximum DHW Input Limit:

The *PUREFIRE*[®] control allows the installer to limit the maximum input of the boiler under a DHW load if desired. This can be used when the boiler is sized primarily for a CH load and is oversized for the DHW load. This can be set between 50% and 100% and the default is 100%.

6. DHW Response Time:

This feature allows the installer to adjust the response time of the boiler. The "I" value is adjustable from 15 to 100 with 15 providing the fastest response. The default value is 60. If the boiler achieves its setpoint very quickly without modulating, increase the "I" value to reduce the response time.

F. SERVICE NOTIFICATION

The *PUREFIRE*^{*} boiler control allows the installer to enable Service Notification through the installer menu. After enabling this feature, the installer selects the number of hours, the number of cycles, or the date when the "SERVICE" text appears on the display screen. This will prompt the user to call for service on the appliance.

The following chart shows the range and default values for the Service Notification feature.

If desired, the installer can set a specific date for the Service Notification.

Notification	Min.	Max.	Default
Notification	On	Off	Off
Hours	0	8,000	4,000
Cycles	0	50,000	10,000

Table 8.10: Service Notification Value Ranges

To access the Notification menu operate the boiler under System Test, enter the installer menu by holding down the "Menu" and "Select" keys simultaneously for 10 seconds. Then press the " $\mathbf{\nabla}$ " key until the " $\mathbf{\rightarrow}$ " indicates "Service Notif." Press the "Select" key to choose the menu.

The first option is to reset the Notification Timer / Counter. Pressing the "Select" key will reset the timers and counters and "Done" will be shown in place of "Reset" on the lower right of the screen.

Pressing the " $\mathbf{\nabla}$ " key displays the "SERVICE Notification on" screen. The default setting for "Notification on:" is "Off" indicating that no notification will occur. The installer can choose from the number of hours (HRS), the number of cycles (CYCLES) or the Date at which the "SERVICE" indication will appear on the display screen.

The menus that follow allow the installer to choose the actual values for the Service Notification.

G. SYSTEM TEST

The System Test feature allows the installer or service person to make the control operate at Low Power, Ignition Power, or Maximum Power. This is a setup and troubleshooting tool that allows the installer or service person to obtain combustion readings or observe operation.

To operate the boiler under System Test, enter the installer menu by holding down the "Menu" and "Select" keys simultaneously for 10 seconds. Then press the " $\mathbf{\nabla}$ " key until the " \rightarrow " indicates System Test. Press the "Select" key to choose the menu. The default setting for System Test is "Off". Choose the desired setting and press "Select" again to initiate the test.

Once the System Test is initiated, the service person may exit the menu screen by pressing the "Menu" key until the status screen is displayed. "System Test" will be displayed at the top of the display screen until the operator exits the system test mode.

NOTICE

Be sure to set the System Test parameter back to "Off" before leaving the installation. Otherwise, problems with cycling or insufficient heat may occur.

H. STATUS & FAULT HISTORY

1. General:

The *PUREFIRE®* boiler control allows the installer to view the status of several key parameters. In addition, it provides details in English about the last 15 Blocking Errors and the last 15 Lockout Faults.

The Status and Fault History can be viewed from the Installer Menu. The Installer Menu Structure is shown in Appendix C of this manual.

This menu can be accessed by pressing and holding the "Menu" and "Select" keys simultaneously for 10 seconds. The " \rightarrow " indicator will be indicating "Status". Press the "Select" Key to access this feature.

2. Status:

<u>Current Supply Setpoint</u>: The first screen indicates the current supply setpoint. In CH Mode 0, 3, and 6 this will be the setpoint selected from the User Menu. If the boiler is operating an outdoor reset mode (CH Mode 1 or 2) this value will be the target setpoint temperature calculated based on the outdoor temperature. In CH Mode 4, this value will correspond to the 0-10 V signal input.

<u>Fan Speeds</u>: By pressing the " \checkmark " key the operator can view the current fan speed and the low power fan speed. The current fan speed will be directly comparable to the current input rate. The low power fan speed is a factory preset software parameter that indicates the minimum input to the boiler.

Pressing the " \checkmark " key again displays the ignition and high power fan speed. Both of these are factory preset software parameters that cannot be changed by the installer. The ignition speed is the speed at which the blower runs during the ignition period. The high power fan speed corresponds to the maximum input to the boiler. Flame Signal/Failures: Pressing the " $\mathbf{\nabla}$ " key again will display the Flame Signal/Failures Screen. The flame signal is an indication of combustion stability of the burner. If this value is below 2.8 μ A (microampere) the control will close the gas valve and the burner will recycle through the ignition cycle. The flame signal should be above 5.0 μ A in normal operation.

If the control loses its flame signal 3 times during one call for heat, it will lock out the control indicating, "Flame Failure". The number of flame failures in the history of the control is displayed below the flame signal on the menu screen.

The *PUREFIRE*[®] boiler control uses dual flame sensing to minimize nuisance lockouts. See Section 10, Troubleshooting, to address flame failure issues.

Ignition Attempts: Once again, press the " \checkmark " key to advance to the Ignition attempts status screen. This screen displays the number of successful and failed ignition attempts that have been made by the control. If excessive ignition attempts are shown on this screen, reference Section 10, Troubleshooting.

<u>Boiler Run Time</u>: Pressing the " \forall " key again advances the menu to show Boiler Run Time. This indicates the number of hours that the boiler has operated under CH or DHW demand. The values are rounded to the nearest hour.

3. Fault History:

The following sections provide instructions on how to access the fault history that is stored on the control. The *PUREFIRE*^{*} control stores the last 15 blocking errors and the last 15 lockout errors and allows the installer or service person to review the fault history of the control.

Section 10, Troubleshooting, provides detailed descriptions and troubleshooting approaches to the errors reported by the control.

Last Block: By continuing to press the " \checkmark " key, the status menu displays the following screen. The last block indicates the last blocking error (error that does not cause a lockout). The first number indicates the time interval in minutes since the previous error. The #EXX represents the Error Code which can be referenced in Section 10, Troubleshooting. The last two lines provide an English description of the error.



Last Lock: The next screen accessed by pressing the " $\mathbf{\nabla}$ " key provides information about the last lockout error. Again the first number represents the interval since the last lockout error. #AXX represents the Fault Code which can be referenced in Section 10, Troubleshooting. Again the last two lines provide an English description of the fault.



BOILER CONTROL: INTERNAL WIRING & OPERATION

I. SENSOR RESISTANCE

See Figure 8.4 for typical resistance of the boiler sensors.



Figure 8.4: Sensor Resistance

J. MULTIPLE BOILERS

NOTICE

Before selecting cascade operation, connect the System sensor to terminals #7 & #8. Failure to do this will result in a blinking screen warning as covered in Section 10.D.

- PUREFIRE® boiler controls can operate together to control up to 16 boilers for one central heat or domestic hot water demand. Only the addition of a system sensor (54156) is required to provide this operation. The System Sensor must be placed on the Primary loop downstream of the Boiler loop for proper Cascade operation. See Figure 8.5 and 8.6 for examples of System sensor location.
- 2. Overview:
 - <u>Master Boiler</u>: In a multiple boiler system, a boiler designated as the "Master" boiler controls the function of the boiler system.
 - Attached to a system sensor which monitors the system water temperature.
 - Can also be connected to an outdoor sensor (54112), included with each boiler, as well as an optional DHW sensor (54157) or a standard DHW thermostat.
 - Determines which boiler operates first (lead) and when to bring on additional boilers.
 - Determines the setpoint temperature of individual boilers.
 - Shuts down all boilers in the system if the LWCO contacts are opened.

- <u>Dependent Boilers</u>: The "dependent" boilers operate at the setpoint temperature that the Master boiler specifies.
 - Maintain all of their own safety parameters such as safety limit, vent temperature limit, and freeze protection.
 - Control their own general circulator that is energized whenever there is a call for either Central Heat or Domestic Hot Water.
 - Shuts down the individual boiler if the dependent boiler LWCO contacts are opened.

3. System Piping & Wiring:

- a. Multiple boilers with multiple zones with zone valves.
 - Figure 8.5 shows a typical system which uses a CH circulator, a DHW circulator and zone valves to distribute the heating load to the building.
 - A three zone valve control panel (not included) controls circulation to individual zones.

NOTICE

The central heating (CH) circulator and the domestic hot water (DHW) circulator must be sized in accordance with good Engineering practices based on the required flow and pressure drop of the system. Failure to do so may result in system performance problems.

- A call from any of the heating zones initiates a contact closure from the zone relay across the CH thermostat connections (terminals #1 &2) on the master boiler. This initiates ignition of the "lead" boiler and its general pump. In addition, the CH circulator is energized.
- A call for domestic hot water can either be initiated internally by the control when it sees a drop in indirect tank temperature or by a tank thermostat. In either case, the lead boiler is ignited and its general pump operates. The DHW circulator is also energized.
- b. Multiple boilers with multiple zones with zone circulators.
 - Figure 8.6 shows a typical system which uses a circulator zone control panel to control the central heating zones.
 - The DHW circulator can be operated by the priority zone or can be connected directly to the boiler (as shown). In either case, the priority zone cannot be used for heating.
 - Again, a call for heat from any of the heating zones causes the master boiler to initiate operation of the lead boiler and its general circulator. The CH circulators are controlled by the zone control relay panel.
 - A DHW call results in the operation of the lead boiler and its general pump. The DHW pump is also energized.
 - Wiring for a typical circulator zone relay is shown in Figure 7.4.



Multiple Boiler (Cascade) Piping / Electrical Connections for Systems with Zone Valves Figure 8.5:

BOILER CONTROL: INTERNAL WIRING & OPERATION



Figure 8.6: Multiple Boiler (Cascade) Piping / Electrical Connections for Systems with Zone Circulators

BOILER CONTROL: INTERNAL WIRING & OPERATION

4. Setting up Multiple Boiler Operation:

- For dependent units, change CH Mode to Mode 0-Indoor Thermostat prior to addressing the unit. This can be found under the Central Heating Menu only when addressed as boiler 0 or 1.
- b. Setting the Boiler Address:
 - Press the "Menu" and "Select" keys simultaneously for 5 seconds to enter the Installer Menu.
 - Use the "▼" key to scroll down to "Cascade Settings" on the menu.
 - Pressing "Select" will cause the Boiler Address value to blink. Use the "▼" or "▲" key to change the value.
 - The master boiler will be designated as Boiler Address: 1.
 - All dependent boilers must have sequential boiler address settings as shown on the following table.

Boiler	Cascade	System	Outdoor	DHW
Operation	Address	Sensor	Sensor	Sensor
Stand-alone Boiler	0	Not Active	Active	Active
Boiler #1 Master	1	Active	Active	Active
Boiler #2	2	Not	Not	Not
Dependent		Active	Active	Active
Boiler #3	3	Not	Not	Not
Dependent		Active	Active	Active
Ļ	Ļ	Ļ	Ļ	Ļ
Boiler #16	16	Not	Not	Not
Dependent		Active	Active	Active

Table 8.11: Cascade Addresses and Sensor Functions

- Once a boiler is designated as a dependent boiler, the display will show the individual boiler supply temperature and its status.
- The master boiler will display the system temperature and the overall status of the cascade system.
- By pressing the "▼" or "▲" key the operator can view the master boiler status.
- c. Connecting the Cascade Links PF-50 through PF-140.
 - Remove the User Interface Display from the boiler by pressing the tab on bottom edge and rotating it outward and upward as shown in Figure 8.7.
 - There will be two sets of terminals on the subbase still attached to the boiler. The first set will have wires attaching the display to the Main Control board.
 - Attach 2 wires to the second set of terminals on each boiler to be connected.
 - For the Master Boiler only, slide the switch lever toward the center of the panel to the "ON" position.
 - For all dependent boilers, the switch should remain in the "OFF" position toward the side of the printed circuit board.



Figure 8.7: Cascade Link Connection & Switch Setting

Re-assemble the User Interface Display and connect wires to each boiler in the system.

DISPLAY BOARD

(BACK VIEW)

- All of these wires are to be connected to the Master Boiler as shown in Figure 8.8.
- d. Connecting the Cascade Links PF-200, PF-210, PF-300 and PF-399.
 - Remove the User Interface Display from the Master boiler only.
 - Slide the Master Switch Lever toward the center of the printed circuit board. The Master Switch Lever is not marked with "ON" or "OFF" but the switch is in the "ON" position when it is moved to the left as viewed from the back of the display. This position is shown in Figure 8.7.
 - Re-attach the User Interface Display.
 - Connect wires from terminals #11 & #12 between all boilers in the system.
- 5. Cascade Operation:

SUB-BASE

- a. When a call for Central Heat (CH) or Domestic Hot Water (DHW) is present, the Master boiler chooses which boiler will lead based on the <u>Cascade Rotation</u> <u>Interval</u>.
- Before starting the Lead boiler, the Master control will first check to be sure that the System temperature is lower than the System Setpoint + <u>Stop Boiler Differential</u>.
- c. After a Trial For Ignition (TFI), the lead boiler will modulate its input rate to meet the heat demand.
- d. Any time that a boiler is started the <u>Cascade Start</u> <u>Delay Time</u> will be initiated and no boiler will be allowed to start before this time elapses. This is to allow time for the system to stabilize before bringing on an additional boiler.
- e. After the delay time has elapsed, one of the following conditions must be met before starting the next boiler:
 - The System Temperature must be lower than the Set Point minus the <u>Cascade Start Boiler</u> <u>Differential</u> temperature, or

To cascade PF-50 and PF-80 models, check that the display sub-base has the cascade link as illustrated in Figure 8.6.



MULTIPLE BOILER CASCADE LINK WIRING: PF-50, PF-80, PF-110 AND PF-140



MULTIPLE BOILER CASCADE LINK WIRING: PF-200, PF-210 AND PF-399

Figure 8.8: Interconnection of Cascade Link Wires

- The input rate of all boilers operating must be higher than the <u>Next Boiler Start Rate</u>.
- f. After operation of the second boiler is initiated, the <u>Cascade Start Delay Time</u> must elapse before bringing on additional boilers. Again, in order to initiate operation of additional boilers one of the same conditions must be met.
- g. When the boiler system approaches its Setpoint, the boilers will reduce input rates at approximately equal values. When the input rates of all of the operating boilers fall below the <u>Next Boiler Stop</u> <u>Rate</u>, the master control will shut down the last boiler that started after the Cascade Stop Delay Time has elapsed.
- h. The <u>Calculated Setpoint Max Offset Up</u> and <u>Calculated Setpoint Max Offset Down</u> are applied to individual boilers in multiple boiler cascade operation.
 - These temperature offset values are used to change the response of individual boilers to the system setpoint.
 - Increasing these values will cause the system to react more quickly, but may result in frequent cycling.
 - Decreasing these values will cause the system to react more slowly to achieve the setpoint.
 - By increasing the <u>Calculated Setpoint Max Offset</u> <u>Up</u> value, the Master boiler will offset individual boiler setpoints temperature by a larger amount in order to achieve the system setpoint.

- By increasing the <u>Calculated Setpoint Max Offset</u> <u>Down</u> value, the boilers will decrease the boiler setpoints by a larger amount to achieve the system setpoint.
- i. The <u>Rotation Interval</u> is the frequency at which the Master Boiler will change the Lead boiler in the sequence.
 - For example, if the <u>Rotation Interval</u> is set to 5 days and there are 4 boilers operating together, the following chart shows the operating sequence over the next 25 days.

Table 8.12: Rotation Interval Sequence

Days of Operation	Start/Stop Sequence
1-5	1-2-3-4
6-10	2-3-4-1
11-15	3-4-1-2
16-20	4-1-2-3
21-25	1-2-3-4

6. Multiple Boilers – Boost & Warm Weather Shutdown (WWSD):

a. To use the Boost function with multiple boilers, the parameters on the master boiler are used. Boost parameters set on dependent boilers have no effect on the system operation.

BOILER CONTROL: INTERNAL WIRING & OPERATION

b. Similarly, the WWSD Temperature set on the master boiler will prevent any boilers from operating for a CH demand when the outdoor temperature is above this value.

7. Multiple Boilers – Ramp Delay:

- a. The ramp delay feature can be set on each individual boiler.
- b. However, it is important to note that since the dependent boilers treat DHW demands as a CH call, the ramp delay will take effect even when the DHW tank calls.

8. Multiple Boilers – Anti-Cycling:

- a. The Anti-Cycling feature is active on all boilers unless it is disabled.
- b. This will prevent dependent boilers from operating within the prescribed time limit. However, it will only prevent the boiler from cycling on its own limit. Repetitive calls from the master boiler will result in cycling.

9. Multiple Boilers – DHW Operation:

- a. Since the DHW tank sensor or thermostat is connected only to the Master boiler, this is the only boiler that will receive the DHW demand.
- b. The master control will start boilers as necessary to meet the demand.
- c. Boilers with a boiler address of 2 or higher will automatically be switched to DHW Mode 0 (No DHW).

9. START-UP PROCEDURE

A. GENERAL

- 1. Confirm that all water, gas and electricity are turned off.
- 2. Verify that the water piping, venting & air intake piping, gas piping, electrical wiring and electrical components are installed in accordance with the manufacturer's instructions. Be sure that the boiler is installed in accordance with this manual and good engineering practice.
- 3. Turn on electricity and gas to the boiler.
- 4. Fill the condensate tanks with water to within 2-3" of the top of the tanks to prevent flue gasses from escaping the vent during initial start-up.

B. CHECK WATER PIPING

- 1. Fill the boiler and system with water, making certain to purge all air from the system. Open each vent in the system until all air is released and water begins to be discharged. Then close the vent.
- 2. The pressure reducing valve on the fill line will typically allow the system to be pressurized to 12 PSI. Consult manufacturers instructions for operation of the valve and expansion tank.
- 3. Check joints and fittings throughout the system and repair as required.

C. CHECK GAS PIPING

- 1. Turn on gas to the boiler using the shut-off valve upstream of the sediment trap. Be sure that the gas shut-off valve supplied with the boiler is in the closed position.
- 2. Connect a manometer to the gas supply upstream of the supplied manual gas valve.
- 3. Confirm that the gas supply pressure to the boiler is between the minimum and maximum values as indicated in Section 5.
- 4. If a supply pressure check is required, isolate the boiler and gas valve before performing the pressure test. If the supply pressure is too high or too low, contact the fuel gas supplier.
- Double check the fuel gas supply pressure after the boiler is running to be sure that the pressure doesn't drop off significantly under operation.

D. CHECK OPERATION

- 1. Either disconnect or set CH thermostat and DHW tank thermostat to assure that no call for heat.
- 2. Turn on electricity and all manual gas valves to the boiler. Check to see if the LCD display is lit. The control will display, "Standby".

- 3. Refer to Section 8, Boiler Control, to set up the control for the desired operation.
- Use the ignition sequence, Figure 8.1 to follow the light off and shutdown sequences and to assist in troubleshooting operation problems. If the boiler does not function properly, consult Section 10, Troubleshooting.
- 5. After starting the boiler, be certain that all controls are working properly and that the combustion is properly set up. Paragraphs 6 and 7 below provide instructions on how to do this.
- 6. Check that the boiler will shut down when the supply water temperature reaches the control setpoint.
 - a. Note the boiler setpoint by accessing the User Menu, Status Display. Press the "Menu" key on the keypad. Choose Status by pressing the "Select Key". Use the "t" and "s" key to scroll through the CH and DHW setpoints. Refer to Appendix B for the User Menu.
 - b. Use the System Test Mode in the Installer Menu to choose High Input Power.
 - c. Monitor the boiler temperature on the temperature gauge (supplied for field mounting) and on the Status display.
 - d. The boiler should shut down at the boiler setpoint plus 10°F (5.6°C). If it does not shut down turn off the boiler and contact your PB Heat representative.
- 7. Check combustion readings in the boiler vent pipe.
 - a. For PVC or CPVC exhaust vent pipe only: Drill and tap a 1/8" NPT threaded hole in the boiler vent pipe within 12" (305 mm) of the boiler vent connection. (21/64" Drill and 1/8" NPT Pipe Tap recommended) This is to be used as the combustion test port for the combustion analyzer. See Figure 9.1.



Figure 9.1: Drill and Tap Combustion Test Port

START-UP PROCEDURE

- Polypropylene vent systems from Centrotherm or Duravent should include a sample port fitting connected to the exhaust outlet port of the boiler. In this case, this fitting is to be used as the test port for the combustion analyzer.
- c. Using a combustion analyzer with the capability to read carbon dioxide (CO₂) and carbon monoxide (CO), place the probe into the combustion test port. See Figure 9.2.
- d. Manually set the boiler to Maximum power by entering the System Test Mode. See Appendix C, Installer Menu.



Figure 9.2: Insert Analyzer Test Probe into Test Port

- Verify that the fan speed indicated is within 30 rpm of the maximum power fan speed in Table 12.3.
- Verify that the CO and CO₂ emissions are within the parameters specified in Table 5.4.
- e. Manually set the boiler to Low Power by entering the System Test Mode. See Appendix C, Installer Menu.

- Verify that the fan speed indicated is within 100 rpm of the Low Power fan speed listed in Table 12.3.
- Verify that the CO and CO₂ emissions are within the parameters specified in Table 5.4.
- f. If the values in either of these instances falls outside the parameters listed in Table 5.4, turn off the boiler and contact your PB Heat representative. For best results, the value should be set for the middle of the range (9% for Natural Gas and 10% for LP Gas).
- g. Be sure to set the System Test mode to Off so that the boiler will modulate correctly in accordance with the load.
- h. After removing the analysis probe from the vent pipe, insert a PVC or Stainless Steel pipe plug into the test port. See Figure 9.3.
- i. Record the combustion readings on the "Startup Combustion Record" in Appendix D. It is very important to record all of the information requested on the sheet for follow up and troubleshooting.



Figure 9.3: Insert Pipe Plug into Test Port

NOTICE

To prevent moisture damage to control and blower:

During Boiler operation verify that there are no water leaks from any fittings on the boiler header and that all vent connections are water tight and properly assembled.

E. LIGHTING & OPERATING PROCEDURES



Figure 9.4: Lighting & Operating Instructions

10. TROUBLESHOOTING

A. HARDWARE ERROR- NO COMM MAIN BOARD

If the display shows "NO COMM MAIN BOARD", Contact your PB Heat, LLC representative or PB Heat Technical Support.

B. BLOCKING ERRORS

- 1. When a Blocking Error occurs the controller will display a message and an "E" error code on the display module.
- 2. These error messages and several suggested corrective actions are included in Table 10.1.
- 3. Certain Blocking Errors will, if uncorrected, become Locking Errors as described is Paragraph B.

C. LOCKING ERRORS

- 1. When a Locking Error occurs the controller will display a message and an "A" error code on the display module.
- 2. These error messages and several suggested corrective actions are included in Table 10.2.
- 3. Press the reset key to clear the Locking Error and resume operation. Be sure to observe the operation of the unit to prevent a recurrence of the fault.
- 4. The PUREFIRE® control will retry for ignition after one hour of being in a lockout condition. This will prevent lockout errors from resulting in "No Heat" calls if there is an intermittent problem.
- 5. The PUREFIRE® control logs the flame signal four times during the last 2 seconds of the ignition period. This is to aid in troubleshooting ignition errors. A flame signal below 2.8 micro amps at the end of this period will result in a lockout. If the flame signal is low, remove the flame sensor and igniter for inspection. Also, be sure that the lead to the flame sensor is not grounded.

🕂 WARNING

When servicing or replacing any components of this boiler be certain that:

- The gas is off.
- All electrical power is disconnected.

\land DANGER

When servicing or replacing components that are in direct contact with the boiler water, be certain that:

- There is no pressure in the boiler. (Pull the release on the relief valve. Do not depend on the pressure gauge reading).
- The boiler water is not hot.
- The electrical power is off.

🗥 WARNING

Do not use this appliance if any part has been under water. Improper or dangerous operation may result. Contact a qualified service technician immediately to inspect the boiler and to repair or replace any part of the boiler which has been under water.

A CAUTION

If overheating occurs or the gas supply fails to shut off, do not turn off electrical power to the circulating pump. This may aggravate the problem and increase the likelihood of boiler damage. Instead, shut off the gas supply to the boiler at the gas service valve.

CAUTION

Label all wires prior to disconnection when servicing controls. Wiring errors may cause improper and dangerous operation. Verify proper operation after servicing.

\land CAUTION

The convenience outlet is powered even when the service switch is off.



A LINE VOLTAGE POWER ISSUE.

Figure 10.1 Main Control Board Fuse Location

D. ERROR MESSAGES IN A CASCADE SYSTEM

See paragraph D and the Cascade section of Appendix A for further information on how errors are displayed when using a Cascade System.

TROUBLESHOOTING

 Table 10.1:
 Control Board Blocking Error Codes (automatic reset):

"E" CODE	Error Display	Internal No.	Error Description	Corrective Action
E01	SUPPLY SENSOR NOT CONNECTED	51	Supply sensor not connected.	Check harness and sensor.
E02	RETURN SENSOR NOT CONNECTED	52	Return sensor not connected.	Check harness and sensor.
E04	DHW SENSOR NOT CONNECTED	55	DHW sensor not connected.	If DHW Mode is not intended to be set to Mode 1, DHW Store with Sensor, then change it to the appro- priate Mode. Check harness and sensor.
E05	STACK SENSOR OPEN	57	Flue gas sensor open.	Check vent temperature, harness, sensor.
E11	SUPPLY SENSOR SHORT	59	Supply sensor shorted.	Check harness and sensor.
E12	RETURN SENSOR SHORT	60	Return sensor shorted.	Check harness and sensor.
E13	STACK SENSOR SHORT	65	Flue gas sensor shorted.	Check harness and sensor.
E14	DHW SENSOR SHORT	63	DHW sensor shorted.	Check harness and sensor.
E19	COMMUNICATION ERROR E2PROM ERROR	0	Problems reading from or writing to e2prom.	Contact PB Heat Representative.
E20	FALSE FLAME DETECTED	35	False Flame detected.	Verify no flame in observation port. Check Sensor.
E21	HOT/NEUTRAL REVERSED	44	Phase and neutral of mains supply are reversed.	Verify polarity of incoming wiring. Check boiler ground and harness.
E22	POOR GROUND	43	No earth connected or internal hardware error.	Check boiler ground and harness.
E23	NET FREQUENCY ERROR	45	Mains frequency differs more than 2% from 60Hz.	Contact electrical provider and/or an electrician.
E24	POOR GROUND	46	Earth connection is not ok.	Check boiler ground and harness.
E25	BLOCKED VENT	38	Blocked Vent Switch is Open	This error applies to PF-200, PF-210, PF-300 and PF-399 models. Check for blocked vent pipe or blocked heat exchanger. Check switch and tubing to switch.
E26	BLOCKED CONDENSATE DRAIN	41	Condensate drain blocked.	Check condensate tanks, hoses, condensate switch, and harness.
E30	HIGH STACK TEMPERATURE	39	Flue gas sensor above max flue setpoint + diff.	If flue pipe is hot, check flue temperature and compare to values shown Table 8.5. Check for proper gas input and combustion readings, check for dirty heat exchanger. If flue pipe is not hot, check flue sensor and harness.
E31	LOW WATER	36	Water level is too low.	Check boiler water level, low water cut-off, harness. If a LWCO is not used, a jumper should be placed between terminals #9 and #10, LWCO Contact.
E32	HIGH RETURN TEMP	40	Return temperature is above 194°F (90°C).	Check for reversed supply and return piping or pump installed backwards.
E42	INTERNAL HDWRE ERROR	47	Internal hardware error.	See Note*
E45	INTERNAL HDWRE ERROR	31	Internal hardware error.	See Note*
E46	INTERNAL HDWRE ERROR	32	Internal hardware error.	See Note*
E47	INTERNAL HDWRE ERROR	33	Internal hardware error.	See Note*
E48	INTERNAL HDWRE ERROR	34	Internal hardware error.	See Note*
E51	RESET BUTTON ERROR PLEASE WAIT.	66	Reset button pressed more than 7 times within one minute.	Wait five minutes. If error does not clear, replace control.

* If persistent blocking errors, E42 through E48, occur, systematically disconnect all wires that were not supplied by the factory with the exception of the power supply (CH T'stat, DHW T'stat, LWCO and Pumps). If the error code goes away, determine if there may be feedback from one of the circuits. If the Error occurs with all of these disconnected, there is likely a problem with the control board.

TROUBLESHOOTING

"A" CODE	Error Display	Internal No.	Error Description	Corrective Action
A01	IGNITION ERROR	1	Three consecutive unsuccessful ignition attempts.	 Watch the igniter through the observation window. If no spark is present, check the spark electrode for the proper 3/16" gap. (DO NOT try to bend the electrodes if they have been operating for an extended period. Heat causes them to become brittle and they may break.) Remove any corrosion from the spark electrode with abrasive. If a spark is present but no flame results, check the gas supply to the boiler. Check for either high or low gas pressure. (See table 5.3) Try restricting the air to the burner by covering the air inlet vanes on the swirl plate. If ignition results, check the combustion products using a combustion analyzer. If the combustion is out of tolerance (see table 5.4) contact your PB Heat representative. If a flame is present but the burner drops out, check the flame sensor log in the Installer Menu (Meas. 1, 2, 3, 4). The flame Meas. Values are the flame signal at 1/2 second intervals during the last 2 seconds of trial for ignition after the spark has stopped but before proving ignition. If Meas. 4 is below 3.1 µA, the control will not stay running. If the flame signal is too low, remove the burner plate and check the distance between the sensor and the burner. (DO NOT try to bend the electrode if it has been operating for an extended period. Heat will cause it to become brittle and it may break.) Determine if the gas valve is opening by monitoring gas pressure. Also, listen for the solenoid valve to pull in. If the harness appears correct, replace the gas valve. (Before beginning this replacement, connect the gas valve to be sure it operates correctly before removing the old one. If it doesn't operate correctly, the existing valve may not be bad.
A02	FLAME FAILURE	24	Three consecutive flame failures during one demand.	 If boiler sparks, lights briefly and then goes out: Disconnect the flame sensor cable and then retry ignition. If the flame stays lit, allow the boiler to run for several minutes and then reattach the cable. If the problem persists, remove the flame sensor and inspect the burner through the sensor opening. If metal fibers are protruding from the burner, use a blunt probe to move the fibers away from the sensor. If the unit locks out on flame failure during normal operation:
A03			High Temperature Limit Open (Set Temperature 205°F)	 Check CH, DHW, General Pump Operation Assure that there is adequate flow through the boiler by checking the status menu and assuring less than 40°F temperature rise across the boiler. Check the resistance reading through the High Limit Temperature Switch when the boiler is cool (below 160°F). If the switch shows an open circuit, replace the switch.

Table 10.2: Control Board Locking Error Codes (manual reset):

** If persistent locking errors, A04 through A18, occur, systematically disconnect all wires that were not supplied by the factory with the exception of the power supply (CH T'stat, DHW T'stat, LWCO and Pumps). If the error code goes away, determine if there may be feedback from one of the circuits. If the Error occurs with all of these disconnected, there is likely a problem with the control board.

 Table 10.2 (cont'd):
 Control Board Locking Error Codes (manual reset):

"A" CODE	Error Display	Internal No.	Error Description	Corrective Action
A04	INTERNAL ERROR GAS VALVE RELAY	5	Gas Valve Relay Problems.	See Note**
A05	INTERNAL ERROR SAFETY RELAY	6	Safety Relay Problems.	See Note**
A09	INTERNAL SOFTWARE ERR RAM ERROR	9	Internal Software Error.	See Note**
A10	COMMUNICATION ERROR E2PROM ERROR	12	No Communication with E2prom.	See Note**
A12	SOFTWARE OUT OF DATE E2PROM OUT OF DATE	10	Contents of e2prom is not up-to-date.	See Note**
A13	INTERNAL ERROR	13	Internal Software Error	See Note**
A14	INTERNAL ERROR	14	Internal Software Error	See Note**
A15	INTERNAL ERROR	16	Internal Software Error	See Note**
A16	INTERNAL ERROR	22	Internal Software Error	See Note**
	INTERNAL ERROR	19	Internal Software Error	See Note**
A19	FALSE FLAME DETECTED AFTER SHUTDOWN	20	Flame signal detected 10 sec. after closing the gas valve.	 Check flame sensor to be sure there is no short to ground. Check igniter to be sure there is not short to ground. This could also indicate that the gas valve doesn't close completely.
A20	FALSE FLAME DETECTED BEFORE IGNITION	21	Flame signal detected before gas valve opened.	Check flame sensor to be sure there is no short to ground. Check igniter to be sure there is not short to ground.
A23	FLOW_SW_NOT_OPEN	25	CH flow switch not work- ing.	 Check for electrical continuity between wires connected to terminals 9 & 10 from field supplied flow switch. If there is continuity when the circulator is off, there is a system pip- ing or circulator control problem.
A24	FLOW_SW_NOT_CLOSED	26	CH flow switch not work- ing.	 Check for electrical continuity between wires connected to terminals 9 & 10 from the field supplied flow switch. If there is no continuity, check to be sure the circulator is working. If the circulator is working correctly, check the flow switch.
A32	FAN NOT RUNNING	23	Internal Software Error.	
A33	FAN SPEED ERROR	8	Fan speed detected is more than 300 rpm different from targeted value for more than 60 seconds.	 Does the fan run at full speed after resetting the control? Check connections in the 4-wire connection to the blower. If the connections are correct, there may be a problem with the harness or the main control board. Does the fan run normally after resetting the control? Under System Test in the Installer Menu on the display, choose "Low Power". If the boiler locks out when targeting low power, check the voltage to the fan. If the voltage is within specification, replace the blower. Does the fan not run after pressing reset? Check for signs of moisture around the fan motor. Check for evidence of recirculating flue gas (corrosion inside the cabinet). DO NOT replace the blower without determining the cause of the failure. Otherwise, the failure may reoccur.
A50	RETURN HIGHER THAN SUPPLY	11	Boiler return water tem- perature higher than supply for more than 5 ignition attempts.	 Check system piping. Assure that the water is entering the return connection and exiting the supply connection. Compare the supply thermistor reading to the temperature gauge, if they don't agree, replace the supply thermistor.

** If persistent locking errors, A04 through A18, occur, systematically disconnect all wires that were not supplied by the factory with the exception of the power supply (CH T'stat, DHW T'stat, LWCO and Pumps). If the error code goes away, determine if there may be feedback from one of the circuits. If the Error occurs with all of these disconnected, there is likely a problem with the control board.

E. WARNING ERRORS

The *PUREFIRE*[®] boiler control will display a blinking screen under several conditions. Several of these conditions provide the error information directly on the screen. Table 10.3 shows sensor errors and corresponding corrective actions.

1. Outdoor Sensor Error:

a. If the boiler control is set to a CH mode which requires an outdoor sensor (CH Mode 1 or 2) and the sensor is not connected, the screen will blink. Pressing the "Reset" key will display the following error screen.



In this condition, the control will continue to operate, targeting the Boiler Design Temperature as a fixed value. To operate at the maximum efficiency while the sensor circuit is being repaired or replaced, use CH Mode 7, Internal Reset.

b. If the boiler control is set to a CH mode in which an outdoor sensor is required and the sensor is shorted, the screen will blink. Pressing the "Reset" key will display the following error screen.



- c. The boiler will not operate until this problem is corrected.
- If the Outdoor Sensor is open, the status screen will read -40°F and the boiler will run at the boiler design temperature as set up in the installer menu.

S	Т	Α	Т	U	S							A
	S	у	s	t		m		1	6	0	F	
	۷		n	t				1	3	0	F	
	0	u	t	d	0	0	r		4	0	F	$\mathbf{\nabla}$

2. DHW Sensor Error:

- a. If the boiler control is set to operate on DHW Mode 1 (DHW Sensor), and there is no sensor connected the boiler will not satisfy a DHW call for heat.
- b. The display will blink and the DHW temperature will read 14°F if there is an open circuit at the sensor terminals. Pressing the "Reset" key will display the following error screen.



- c. This will also occur if the wires are not properly connected.
- d. If there is a short at the DHW sensor terminals and the DHW mode is set to Mode 1, the DHW system will not operate. The display will blink to indicate a warning error. Pressing the "Reset" key will display the following error screen.



3. Flue Sensor Error:

a. If the control senses that the flue temperature does not rise to above 50°F after ignition, and either the supply water temperature rises above 120°F or the return water temperature rises above 80°F, the control will display "Flue Sensor Hold" and run at 1% Input.

FLUE	s	ΕN	IS	ORI				:	36
1	% I	np	u	t	1	6	3		F

 b. If "Flue Sensor Hold" continues for an extended period of time, the display will blink. Pressing the "Reset" key will display the following error screen.

														1	6		3	6
w	а	r	n	n	g		Ν	u	m	b	е	r		#	W	0	4	
F	1	u	e	S	е	n	s	0	r		0	р	е	n				
W	a	r	n	n	g													

4. Cascade – System Sensor Error:

a. In a multiple boiler cascade installation a system sensor must be connected to the system. If no system sensor is connected or if there is an open circuit the display will blink and the display screen will read as follows:



b. If there is a short circuit in the system sensor wiring, the display screen will read similarly. Notice that a short circuit results in a high system temperature reading (244°F).

															1	6		3	6
	С	Α	S	С	A	D	Е		S	Т	Α	Ν	D	В	Y				
S	Y	S	Т	Е	М		S	Е	Ν	S	0	R		F	A	I.	L		
	0	1		В	0			е	r	s		0	n		2	4	4		F

c. Under either of these conditions, the Master boiler will set the supply setpoints of all of the boilers to match the system setpoint. It will continue to bring on and shut off boilers based on the thermostat demand (terminals #1 and #2) and the Boiler Start/ Stop Delay Time.

5. Cascade – Loss of Communication with Master Boiler:

a. If a dependent boiler is not communicating with the Master boiler, and it is set as address 2-16, the screen will blink with the following information displayed.



b. The boiler that is not communicating with the Master boiler will not run until the problem is corrected. Other boilers connected to the Master boiler and the Master boiler itself will operate normally.

TROUBLESHOOTING

Table 10.3: Control Board Warning Error Codes

"W" CODE	Error Display	Error Description	Corrective Action
#W00	16:36 Warning Number#W00 Outdoor Sensor Open Warning Blinking Screen – Press "Reset" key to view this message	Outdoor Sensor Open	 Check to see if the Outdoor Sensor is connected. Check wiring connectons to outdoor sensor. Remove wires from terminals #3 and #4 on the boiler and check the resistance between them. If the reading shows an open circuit there is an broken/disconnected wire or sensor. Reconnect or replace.
#W01	16:36 Warning Number#W01 Outdoor Sensor Short Warning Blinking Screen – Press "Reset" key to view this message	Outdoor Sensor Shorted	 Check wiring connection to Outdoor Sensor. Remove the wires from terminals #3 and #4 on the boiler and check the resistance between them. If this reading is below 3000 W check the read- ing at the sensor. If the reading is the same at the sensor, replace the sensor. If the reading is higher at the sensor, replace the wiring.
#W02	16:36 Warning Number#W02 DHW Sensor Open Warning Blinking Screen – Press "Reset" key to view this message	DHW Sensor Open	 Be sure the optional DHW Sensor (54157) is connected. Remove the wires from terminals #5 and #6 on the boiler and check the resistance between them. a. If the resistance is above 10 k W, check the resistance at the sensor. b. If the reading at the sensor is the same, replace the sensor. c. If the reading at the sensor is lower, replace the wiring.
#W03	16:36 Warning Number#W03 DHW Sensor Shorted Warning Blinking Screen – Press "Reset" key to view this message	DHW Sensor Shorted	 Check wiring connection to DHW Sensor. Remove the wires from terminals #5 and #6 on the boiler and check the resistance between them. a. If this reading is below 1000 W, check the reading at the sensor b. If the reading is the same at the sensor, replace the sensor. c. If the reading is higher at the sensor, replace the wiring.
#W04	16:36 Warning Number #W04 Flue Sensor open Warning	Flue Sensor Open	 Check wiring connection to flue sensor. Compare sensor resistance to Figure 8.3. If resistance value is incorrect, replace sensor.

E. DELAYED IGNITION (HARD LIGHT-OFF)

There are several factors that may cause a delayed ignition in the PureFire boiler due to a pressure pulse at light-off.

Table 10.4: Hard Light-Off Conditions:

Condition	Condition Description	Corrective Action				
LOW GAS PRESSURE	If the gas inlet pressure at the inlet port on the gas valve is below 3.5" of water for Natural Gas and 8" of water for LP at 100% of modulation, a hard light-off may occur. This may be due to slow introduction of the gas/air mixture at light-off.	Be sure that the incoming gas pressure does not drop below 3.5" of water for Natural Gas and 8" of water for LP at any point in its operation. Be sure to check while other appliances are in operation.				
HIGH GAS PRESSURE	If the gas inlet pressure at the inlet port on the gas valve is above 13.5" of water when the boiler is off, a delayed ignition may occur. This is because the gas pressure may inhibit the smooth opening of the gas valve at light-off.	Be sure that the incoming gas pressure is not above 13.5" while the boiler is off or at any time during its operation.				
INCORRECT AIR/FUEL RATIO	Using a suitable combustion analyzer, check the products of combustion to assure correct combustion air/fuel ratio as described in Section 9.D.7 of these instructions.	If the vent CO ₂ or CO is out of range in accordance with table 5.4 in these instructions, please contact your PB Heat representative.				
SPARK GAP IS TOO LARGE	If the spark gap between the ignition electrode and ground rod is too large, a delayed ignition may occur. This may be due to decreased spark energy of the larger spark.	If the boiler is natural gas-fired, the spark gap should be between 1/8" and 3/16". If the fuel is LP gas, the spark gap should be between 3/16" and 1/4".				
SPARK GAP IS TOO SMALL	If the spark gap between the ignition electrode and ground rod is too small, a delayed ignition may occur. This may be due to a narrow ignition window from the small spark.	If the boiler is natural gas-fired, the spark gap should be between 1/8" and 3/16". If the fuel is LP gas, the spark gap should be between 3/16" and 1/4".				
SPARK PLACEMENT	If the placement of the spark is the wrong distance from the burner a delayed ignition may occur. The distance of the spark from the burner surface should be approximately 3/8". If the spark gap is farther away from the burner, a significant amount of combustible mixture may be introduced into the combustion chamber before ignition. This may result in a delayed ignition.	If the spark gap is more than 3/8" from the burner, replace the ignitor and assure that the spark is 3/8" or less.				
WEAK SPARK	 A weak spark at the gap between the ignition electrode and ground rod on the ignitor may be attributed to several problems. Deterioration of the insulated spark wire Dirt on the insulated portion of the spark electrode that may provide a path for spark energy to ground 	 Check the spark wire for wear or damage. Replace if necessary. Check the porcelain insulation on the spark electrode for evidence of dirt. Clean the insulator if dirt is evident. 				

F. BOILER FAILS TO RESPOND TO A CH CALL

If the display screen shows "STANDBY" and does not respond when a thermostat call has been initiated, use the following procedure to check operation.

- 1. Enter the "Installer Menu" by pressing the "Menu/Return" key and the "Select" key simultaneously for 5 seconds.
- 2. Using the "t"key move the cursor to "SYSTEM TEST" and press "Select".
- 3. Use the "t"key again to move the cursor to "Low Power".
- 4. Press the "Menu/Return" key twice to return to the status screen.
- 5. If the boiler operates, return to "SYSTEM TEST" and select "OFF". If not, contact technical support.
- 6. Next, remove any wires from terminals #1 & #2 (CH Thermostat). See the illustration below.

- 7. Place a jumper in terminals #1 & #2, shown in Figure 10.2 below, to simulate a heating call.
- 8. If the boiler operates, there may be voltage feedback to the thermostat terminals from the source. Check for stray voltage or isolate the contacts.



Figure 10.2: CH Thermostat Terminals

11. MAINTENANCE

\land WARNING

Product Safety Information Refractory Ceramic Fiber Product

This appliance contains materials made from refractory ceramic fibers (RCF). Airborne RCF fibers, when inhaled, have been classified by the International Agency for Research on Cancer (IARC), as a possible carcinogen to humans. After the RCF materials have been exposed to temperatures above 1800°F, they can change into crystalline silica, which has been classified by the IARC as carcinogenic to humans. If particles become airborne during service or repair, inhalation of these particles may be hazardous to your health.

Avoid Breathing Fiber Particulates and Dust

Suppliers of RCF recommend the following precautions be taken when handling these materials:

Precautionary Measures:

Provide adequate ventilation.

Wear a NIOSH/MSHA approved respirator.

Wear long sleeved, loose fitting clothing and gloves to prevent skin contact.

Wear eye goggles.

Minimize airborne dust prior to handling and removal by water misting the material and avoiding unnecessary disturbance of materials.

Wash work clothes separately from others. Rinse washer thoroughly after use.

Discard RCF materials by sealing in an airtight plastic bag.

First Aid Procedures:

Inhalation: If breathing difficulty or irritation occurs, move to a location with fresh clean air. Seek immediate medical attention if symptoms persist.

Skin Contact: Wash affected area gently with a mild soap and warm water. Seek immediate medical attention if irritation persists.

Eye Contact: Flush eyes with water for 15 minutes while holding eyelids apart. Do not rub eyes. Seek immediate medical attention if irritation persists.

Ingestion: Drink 1 to 2 glasses of water. Do not induce vomiting. Seek immediate medical attention.

MAINTENANCE

A. GENERAL (WITH BOILER IN USE)

General boiler observation can be performed by the owner. If any potential problems are found, a qualified installer or service technician/agency must be notified.

- 1. Remove any combustible materials, gasoline and other flammable liquids and substances that generate flammable vapors from the area where the boiler is contained.
- 2. Observe general boiler conditions (unusual noises, vibrations, etc.)
- Observe operating temperature and pressure on the combination gauge located in the supply piping on the left side of the boiler. Boiler pressure should never be higher than 5 psi below the rating shown on the safety relief valve (25 psig maximum for a 30 psig rating). Boiler temperature should never be higher than 240° F.
- 4. Check for water leaks in boiler and system piping.
- Smell around the appliance area for gas. If you smell gas, follow the procedure listed in the Lighting Operating Instructions to shut down appliance in Section 9, Start-Up Procedure Part B.

B. WEEKLY (WITH BOILER IN USE)

Flush float-type low-water cut-off (if used) to remove sediment from the float bowl as stated in the manufacturer's instructions.

C. ANNUALLY (BEFORE START OF HEATING SEASON)

A CAUTION

The following annual inspection must be performed by a qualified service technician.

- 1. Check boiler room floor drains for proper functioning.
- 2. Check function of the safety relief valve by performing the following test:
 - a. Check valve piping to determine that it is properly installed and supported.
 - b. Check boiler operating temperature and pressure.
 - c. Lift the try lever on the safety relief valve to the full open position and hold it for at least five seconds or until clean water is discharged.
 - d. Release the try lever and allow the valve to close. If the valve leaks, operate the lever two or three times to clear the valve seat of foreign matter. It may take some time to determine if the valve has shut completely.
 - e. If the valve continues to leak, it must be replaced before the boiler is returned to operation.
 - f. Check that operating pressure and temperature have returned to normal.
 - g. Check again to confirm that valve has closed completely and is not leaking.

- 3. Test low-water cut-off (if used) as described by the manufacturer.
- 4. Test limit as described in Section 9, Part D, "Check Operation".
- Test function of ignition system safety shut-off features as described in Section 9, Part D, "Check Operation".

🏦 DANGER

When servicing or replacing components, be absolutely certain that the following conditions are met:

- Water, gas and electricity are off.
- The boiler is at room temperature.
- There is no pressure in the boiler.

The convenience outlet is powered even when the service switch is off.

- 6. Remove the top/front jacket panel and inspect for any foreign debris that may have entered through air intake vent.
- 7. Inspect burner for deterioration. Replace if necessary.
- 8. With boiler in operation check that condensate is dripping from condensate tubing. Check for any restriction in condensate drain line.

D. CONDENSATE CLEANING INSTRUCTIONS

- 1. Removal of Condensate Tanks.
 - a. Close manual gas shutoff valve on top of boiler and turn off power to the boiler by placing the boiler service switch to the off position.
 - b. Remove the front jacket panel.
 - c. Remove the wing nut securing the front tank and disconnect the tank from the upper right drain hose. (Some condensate may spill out of this port).
 - d. Remove the cap from the tank and position a container in front of the boiler and tilt the tank to drain condensate into the container.
 - e. Tank and lower hose may be by removed by disconnecting the lower hose from the rear tank.
 - f. Clean tank and hose with water and inspect the rear tank for sediment in the lower connection port. The rear tank can be removed for cleaning if required by removing the wing nut and disconnecting the two float switch wire leads. NOTE: Special care must be taken when removing the hoses from the top of the rear tank. They must be held secure and do not pull hoses downward and away from their upper connections to the heat exchanger and vent adapter.
 - g. After cleaning, replace tanks and reconnect hoses and wire leads to float switch. Fill the front tank with water and check for any leaks at connections.
 - h. Replace the front jacket panel, open the manual gas valve and place the boiler service switch to the on position.

- Before re-starting the *PUREFIRE** boiler follow the steps below:
 - a. Reconnect the thermostat wires.
 - b. Open the manual gas shutoff valve and reset the thermostats.
 - c. Observe the boiler function to make sure you see a condensate flow.
 - d. If you do not observe a condensate flow, repeat the above procedure.
- 3. If the problem is not corrected at this point, it is possible that there is a material deposit problem. Follow the Coil Cleaning Instructions (Subsection 9E) below to dissolve deposits and clean the heat exchanger.

🗥 WARNING

It is extremely important to make sure there is no blockage in the exhaust vent. Failure to do so may result in serious personal injury or death.

E. INSPECTION & CLEANING OF COMBUSTION CHAMBER COILS

Before beginning this procedure, you must have on hand the following items:

- a nylon or brass brush (not steel)
- "Rydlyme" (recommended for best results) (available online www.rydlyme.com) or "CLR" (available at most hardware stores)
- 1. Shut the boiler down and access the heat exchanger using the following steps:
 - a. Close the manual gas shutoff valve and wait for the unit to be cool to the touch.
 - b. Disconnect the condensate piping from the outside connections (not from the *PUREFIRE*^{*} side) so the flow can be observed.
 - c. Disconnect compression nut on gas valve inlet and disconnect the gas valve electrical connector.
 - d. Remove the six 10 mm nuts from the burner plate assembly. Disconnect wire leads to the spark igniter and flame sensor. Disconnect two Molex plugs from blower motor.
 - e. Pull the entire burner plate towards you to access the heat exchanger coils.
 - f. Significant deposits may be caused by the recirculation of exhaust gasses, poor fuel quality or contamination of the air supply. Review Section 3, Venting & Air Inlet Piping, if deposits are evident.
- Using a spray bottle filled with the recommended product "Rydlyme" or "CLR", spray liberally on the coils, making sure the solution penetrates and funnels down through the condensate hose. If the condensate hose is blocked, let the chemical penetrate for at least 15 minutes or until it drains.

- 3. Use the nylon or brass brush (do not use steel) and scrub coils to remove any buildup, then vacuum the debris from the coils.
- 4. Spray coils with clear water, making sure to confine the spray to the area being cleaned (try to avoid wetting the back ceramic wall of the unit). Flush the combustion chamber with fresh water. At this point, the PUREFIRE* should be ready to power back up.
- 5. Reinstall the burner plate assembly using the following steps:
 - a. Inspect the inside of the heat exchanger for dirt and debris.
 - b. Install the burner plate assembly and replace the six 10 mm nuts.
 - c. Reconnect the wire leads to the spark igniter, flame sensor and gas valve. (Be sure that the spark igniter is connected to the lead with the large insulated connection boot.) Reconnect two Molex plugs on blower motor.
 - d. Connect the compression nut on the gas valve inlet and reattach the gas valve electrical connector.
 - e. Reset thermostats. (IMPORTANT: BE SURE THAT THE VENT CONNECTION IS NOT BLOCKED.)

WARNING

It is extremely important to check for leaks when reconnecting the gas valve. Failure to do so may result in severe personal injury, death or major property damage.

- f. Turn the power to the *PUREFIRE*[®] on. Observe the display module to assure proper operation.
- g. Initiate a call for heat** and observe the condensate flow.
- h. Reconnect the condensate piping to the drain connection.

**NOTE: When firing the boiler the first few times you may experience some fluttering of the gas burner that may result in a flame lockout. This is normal and will require you to recycle the unit until this clears up. This is caused by water still present in the combustion chamber.

 Inspect exhaust vent and air intake vents for proper support and joint integrity. Repair as necessary. Refer to Section 5, VENTING.

WARNING

Leaks in the vent system will cause products of combustion to enter structure (vent system operates under positive pressure).

7. Inspect exhaust vent and air intake vent terminations for obstructions or corrosion. Corrosion is an indication of exhaust gas recirculation.

12. BOILER DIMENSIONS & RATINGS





SERIES PEERLESS [®] PUREFIRE [®] DIMENSIONS (INCHES)													
Boiler Model	"A"	"В"	"C"	"D"	"E"	"F"	"G"	"H"	"J"	"К"	"L"	"M"	
PF-50	13-3/4	17-3/16	29-1/2	3-1/8	4-13/16	2-7/16	4-1/2	5-1/4	3	1	N/A	N/A	
PF-80	13-3/4	17-3/16	29-1/2	3-1/8	4-13/16	2-7/16	4-1/2	5-1/4	3	1	N/A	N/A	
PF-110	19-3/8	17-3/16	29-1/2	3-1/8	7-5/8"	2-7/16	4-1/2	5-1/4	3	1	N/A	N/A	
PF-140	19-3/8	17-3/16	29-1/2	3-1/8	10-1/2	2-7/16	4-1/2	5-1/4	3	1	N/A	N/A	
PF-200	16-3/4	17-3/16	40-1/2	1	3	3/4	1-3/4	4-1/2	2-15/16	6-1/2	3-9/16	2-1/4	
PF-210	16-3/4	17-3/16	40-1/2	1	3	3/4	1-3/4	4-1/2	2-15/16	6-1/2	3-9/16	2-1/4	
PF-300	28-1/8	17-3/16	40-1/2	1-1/2	4	3/4	2-11/16	5-1/4	3-9/16	5-13/16	7-1/16	2	
PF-399	28-1/8	17-3/16	40-1/2	1-1/2	4	3/4	2-11/16	5-1/4	3-9/16	5-13/16	7-1/16	2	

Table 12.1: Boiler Dimensions
BOILER DIMENSIONS & RATINGS





Table 12.2: Boiler Ratings

SERIES PEERLESS* PUREFIRE* BOILER RATINGS								
	Series Peerless [®] PUREFIRE [®]							
Boiler		out BH)	Heating Capacity	Net Rating	AFUE			
Model	Min.	Max.	(МВН)	(MBH)	(%)			
PF-50	16	50	47	41	95.0			
PF-80	20	80	75	65	95.0			
PF-110	27.5	110	103	90	95.0			
PF-140	35	140	131	114	95.0			
PF-200	42	199	185	161	95.0			
PF-210	42	210	195	170	95.1			
			Gross Output (MBH)	Net Rating (MBH)	Thermal Efficiency (%)			
PF-300	60	300	290	252	96.5			
PF-399	80	399	380	330	95.2			

* For installations over 2000 Ft above sea level, the boiler will de-rate by 3.5% per every additional 1000 Ft in elevation with no adjustment to the boiler. Input values based on manufactures recommended CO2 percentages.

Table 12.3: Combustion Air Fan Speeds

	SERIES PEERLESS [®] PUREFIRE [®] COMBUSTION AIR FAN SPEEDS					
Boiler	Input		Fan Speed			
Model	Rate	Low Power	Ignition	High Power		
PF-50	50 MBH	1350	2790	3360		
PF-80	80 MBH	1470	3780	4800		
PF-110	110 MBH	1590	4200	5280		
PF-140	140 MBH	1440	3990	4800		
PF-200	199 MBH	1350	4650	5940		
PF-210	210 MBH	1350	4650	6150		
PF-300	300 MBH	1440	5430	5640		
PF-399	399 MBH	1710	5790	7740		

BOILER DIMENSIONS & RATINGS

Table 12.4. Pokerike Main Control Specifications			
SERIES PEER	LESS® PUREFIRE® MAIN CONTROL SPECIFICATIONS		
Power Supply	120 VAC Nominal (102-132 VAC); 60 Hertz (40-70 Hz) Phase Neutral		
Fuse (5650)	3.15 Amp, 250 VAC		
Blower Voltage	120 VAC		
Gas Valve Voltage	120 VAC		
Thermostat Contacts	24 VAC		
DHW Contacts	24 VAC		
Flame Current Limits	Minimum (running): 1.5 μΑ Minimum (ignition): 1.7 μΑ Maximum: 10 μΑ		
Temperature Sensors	All PureFire* NTC thermistors are 12k W @ 77°F (25°C). They operate on 5 VDC. Supply Sensor: 14°F (-10°C) to 244°F (118°C) Return Sensor : 14°F (-10°C) to 244°F (118°C) Flue Sensor: 50°F (10°C) to 280°F (138°C) Outdoor Sensor: -40°F (-40°C) to 185°F (85°C)		
	Optional Sensors DHW Sensor: 14°F (-10°C) to 244°F (118°C) System Sensor : 14°F (-10°C) to 244°F (118°C)		
Standards	Europe: CE EN298 North America: ANSI Z21.20 / CSA C22.2		

Table 12.4: PUREFIRE® Main Control Specifications

Table 12.5: Electrical Ratings

	SERIES PEERLESS [®] PUREFIRE [®] ELECTRICAL RATINGS								
	Gunada		Blov	wer	Gas \	/alve	Pur	nps	Max Total
Boiler Model	Supply Voltage (-15%, +10%)	Frequency (±1.2 hz)	Voltage (VAC)	Current (Amps)	Voltage (VAC)	Current (Amps)	Voltage (VAC)	Max. Current (Amps)	Service Current to Boiler
PF-50	120 VAC	60 hz	120	0.53	120	0.09	120	2.48	3.15
PF-80	120 VAC	60 hz	120	0.53	120	0.09	120	2.48	3.15
PF-110	120 VAC	60 hz	120	0.78	120	0.09	120	2.23	3.15
PF-140	120 VAC	60 hz	120	0.71	120	0.09	120	2.30	3.15
PF-200	120 VAC	60 hz	120	2.58	120	0.09	120	20.00	22.67
PF-210	120 VAC	60 hz	120	2.58	120	0.09	120	20.00	22.67
PF-300	120 VAC	60 hz	120	2.58	120	0.21	120	20.00	22.79
PF-399	120 VAC	60 hz	120	2.58	120	0.21	120	20.00	22.79

THIS PAGE INTENTIONALLY LEFT BLANK

13. REPAIR PARTS

Repair parts are available from your local PB Heat, LLC distributor or from Parts To Your Door at 1 (610) 916-5380 (www.partstoyourdoor.com).

Note: Remember to include the boiler model number and serial number when ordering parts.



Figure 13.1: General Repair Parts – PF-50, PF-80, PF-110 & PF-140

Table 13.1: General Repair Parts

1 Fout Door Panel with Ball Stude 5118 2 Cortrol Index 5118 3 Display Index Basil, PF 50-399 1 54163 4 Display Index Gester 1 54163 5 Bracker Display Module, Basil, Che Solays 1 PF2007-1 6 Hex Nut, B6-32 with Lackwaher, (Local Hardware Supply) 2 5439 7 Strew, RF2 x 1/2" (En Pline Head, (Local Hardware Supply) 2 5449 8 Fexible Gas Line - 1/2" (Incide Instaware Supply) 1 54130 11 Screw, RT0 x 1/2", NPT X Colson, (Local Hardware Supply) 2 5534 12 Coupling, YPT X Colson, (Local Hardware Supply) 2 5534 13 Nupple, T NPT X Scing, Brass, (Local Hardware Supply) 2 5534 14 Total Hardware Supply 2 5534 15 Buik Head Titterg for Condensate Connection 1 54132 16 Gasker for huik Head Hardware Supply 4 5413 17 Leg Leveler 5414 54140 18 Hook Nut, Head Hardware Supply 2 5451 19 Convenience Outlet 5414 54132 10 Ista Hardware Supply 4 54132 10		Description	Quantity Required	Stock Code
3 Display Module, 852RC, PF 50-399 1 54702 4 Display Bracke Gaslat 1 54133 5 Bracke Tor Display Module 1 P12007-1 6 Hex Nut, #5-32 with Lockwasher, (Local Hardware Supply) 2 51553 7 Streew, #62 x 1, 21' G Milling Head, (Local Hardware Supply) 1 54203 9 Nipple, 1' WT x Cloce, (Local Hardware Supply) 1 54203 10 Manal Shut-off Value, 1/2' NPT, (Local Hardware Supply) 4 99921 11 Screw, #10 x 1/2' Long Heat, Hardware Supply) 4 99921 12 Coupling, 1' NPT x Sci Local Hardware Supply) 2 5534 13 Nipple, 1' NPT x Sci Local Hardware Supply) 2 5543 14 Jacket Side Panels - PF-10/1/40 1 54120 15 Bulk Head Fitting for Condensate Connection 1 54134 16 Gasket for Sult Head Fitting for Condensate Connection 1 54134 16 Gasket for Sult Head Fitting for Condensate Connection 1 54134 17 Leg Leveler </td <td>1</td> <td>Front Door Panel with Ball Studs</td> <td>1</td> <td>54168</td>	1	Front Door Panel with Ball Studs	1	54168
4 Display Bracket Gasket 1 \$4133 5 Bracket for Display Module 1 Pr2007.1 6 Het XNL, Hei-32 with Lockwasher, (Local Hardware Supply) 2 \$5433 7 Screw, H6-32 x1/2' LG Phillips Head, (Local Hardware Supply) 1 \$9203.1 9 Nipple, 1'' MPT XGDee, (Local Hardware Supply) 1 \$9203.1 10 Manual Shut-off Vaire, 1/2'' KDF, (Local Hardware Supply) 4 \$9992.2 11 Screw, #10 x 1/2'' LGP Hildradware Supply) 4 \$9992.2 12 Coupling, 1'' MPT Brass, (Local Hardware Supply) 2 \$5849 13 Nipple, 1'' MPT S''s LGB Bardware Supply) 2 \$5849 14 Jacket Side Panels - PF-10740 1 \$4132 15 Gasket for Sulk Head Fitting 1 \$41340 16 Gasket for Julk Head Fitting 1 \$41340 17 Legle Head 4 \$4292 18 Hook Bolt 1 \$41340 10 Gasket for Julk Head Fitting 54136 11 <t< td=""><td>2</td><td>Control Lens</td><td>1</td><td>54167</td></t<>	2	Control Lens	1	54167
Backet for Display Module 1 PF2007-1 6 Hex Nut, R6-32 with Lockwasher, (Local Hardware Supply) 2 51533 7 Srew, R6-32 x1/21 (6 Initing Head, (Local Hardware Supply) 1 54038 8 Flexible Gas Line - 1/2" (includes gasket and hardware) 1 54038 9 Nipple, Y1 W7 X-Cose, (Local Hardware Supply) 1 54130 10 Screw, R10 x 1/2" (Local Hardware Supply) 2 5534 11 Screw, R10 x 1/2" (Local Hardware Supply) 2 5534 12 Coupling: YWF arsos, (Local Hardware Supply) 2 5534 13 Nipple, 1" WT X-Cose, (Local Hardware Supply) 2 5534 14 Iddet Side Panels - PF-10/140 1 54132 15 Bulk Head Fitting for Condensate Connection 1 54134 16 Gasket for Bulk Head Fitting for Condensate Connection 1 54134 16 Gasket for Bulk Head Fitting for Condensate Connection 1 54136 16 Gasket for Bulk Head Fitting for Condensate Connection 1 54136 16 <td< td=""><td>3</td><td>Display Module, 852RC, PF 50-399</td><td>1</td><td>54702</td></td<>	3	Display Module, 852RC, PF 50-399	1	54702
6 Hex Nut, #6-32 with Locknasher, (Local Hardware Supply) 2 51553 7 Screw, #6-32 A (21 G Philips Head, (Local Hardware Supply) 2 5449 8 Flexible Gas Line - 1/2 (Local Hardware Supply) 1 54203 9 Nipple, 1" NPT S (Cose, (Local Hardware Supply) 1 54310 10 Manual Shur-of Wuhe, 1/2 YanP, (Local Hardware Supply) 4 99992 11 Screw, HO X 1/2" Long Hex. Hd, (Local Hardware Supply) 2 5860 12 Coupling, 1" NPT Sins (acal Hardware Supply) 2 5860 13 Nipple, 1" NPT Sins (acal Hardware Supply) 2 5860 14 Screw, For Sins, (Local Hardware Supply) 2 5860 15 Bulk Head Fitting Sins, (Local Hardware Supply) 1 54132 16 Gasket for Bulk Head Fitting 1 54134 17 Leg Leveler 4 5429 18 Hook Bolt 1 54134 19 Control Module, S2XM - PF-30 1 54283 20 Hex. Nut, #6-32 Whi Dckwasher, (Local Hardware Supply)	4	Display Bracket Gasket	1	54153
7 Screw, #6-32 x 1/2" (G Phillips Head, (Local Hardware Supply) 2 5449 8 Hexble Gas Line - 1/2" (Includes gastet and hardware) 1 54203 10 Manual Shut off Valve, 1/2" NFT, (Local Hardware Supply) 11 54130 11 Screw, #10 x 1/2" Cong Hex. Hd., (Local Hardware Supply) 2 5534 12 Gauging, 1" NFT Siss, (Local Hardware Supply) 2 5549 13 Nipple, 1" NFT Siss, (Local Hardware Supply) 2 5569 14 Jacket Side Panels - PF-10/140 11 54132 15 Bulk Head Fitting for Condensate Connection 11 54134 16 Gastet for Bulk Field Hitting 2 5551 17 Leg Leveler 4 5429 18 Hock Rolt 1 54134 10 Hock Rolt 1 54282 11 Statist 54282 5451 12 Hock Rolt 1 54282 13 Incertor Module, 823NN - PF-30 1 54282 14 March Rolt Module, 823NN - P	5	Bracket for Display Module	1	PF2007-1
8 Flexible Gas Line - 1/2" (includes gasket and hardware) 1 54203 9 Nipple, 1" NPT X Close, (Local Hardware Supply) 1 99211 10 Manual Stund TWare, 12" NPT, (Local Hardware Supply) 2 5534 11 Strew, #10 x 12" Long Brass, (Local Hardware Supply) 2 5534 12 Coupling, 1" NPT x 5" Long Brass, (Local Hardware Supply) 2 5569 12 Jacket Side Panes - PF-50/80 1 54123 13 Isbite, Side Panes - PF-10/140 1 54130 14 Legt Leveler 1 54136 15 Bulk Head Fitting for Condensate Connection 1 54136 16 Gasket for Bulk Head Fitting 1 54136 17 Legt Leveler 1 54136 18 Hook Rolt 2 5451 19 Control Module, S2MN - PF-30 1 54283 10 Hex Nut, R-32 with Lockwasher, (Local Hardware Supply) 1 54284 2 Switch, Round Togle, 120 WAC 1 54283 2	6	Hex Nut, #6-32 with Lockwasher, (Local Hardware Supply)	2	51553
9 Nipple, 1" NPT x Close, (Local Hardware Supply) 1 99211 10 Manual Shut off Valve, 1/2" NPT, (Local Hardware Supply) 1 54130 11 Strew, 10x 1/2" Clong Hardware Supply) 2 5534 12 Coupling, 1" NPT hass, (Local Hardware Supply) 2 5584 13 Nipple, 1" NPT x 5" Long Brass, (Local Hardware Supply) 2 5869 14 Jacket Side Panels - PF-10/140 1 54173 15 Bulk Head Fitting for Condensate Connection 1 54140 16 Gasket for Bulk Head Fitting 2 5451 17 Leg Leveler 4 5429 18 Hook Bolt 2 5451 10 Convenience Oulet 1 54136 10 Kont In Lodwasher, (Local Hardware Supply) 1 54282 11 54284 Control Module, 852MN - PF-50 1 54282 11 54284 Control Module, 852MN - PF-30 1 54284 12 Control Module, 852MN - PF-10 1 54284	7	Screw, #6-32 x 1/2" LG Phillips Head, (Local Hardware Supply)	2	5449
10 Manual Shut-off Valve, 1/2" NPT, (Local Hardware Supply) 1 54130 11 Screw, #10 x 1/2" Long Hex, H.4, (Local Hardware Supply) 2 5534 13 Nipple, 1" NPT Fass (Local Hardware Supply) 2 5584 14 Jacket Side Panels - PF-50/0. 1 541/3 15 Bulk Head Fitting for Condensate Connection 1 541/3 16 Gasket for Bulk Head Fitting 4 541/3 16 Gasket for Bulk Head Fitting for Condensate Connection 1 541/3 16 Gasket for Bulk Head Fitting 4 541/3 17 Leg Leveler 4 541/3 18 Hook Bolt 2 5551 10 Control Module, St2MN - PF-30 1 54282 18 Hook Module, St2MN - PF-10 1 54283 19 Control Module, St2MN - PF-10 1 54285 20 Vert/Air Inlet Adapter, 3" 1 54285 21 Gasket for Module, St2MN - PF-10 1 54133 23 Screw, #10 x 5/8" Long	8	Flexible Gas Line - 1/2" (includes gasket and hardware)	1	54203
11 Screw, #10 x 1/2" Long Hex. Hd., (Local Hardware Supply) 4 99992 12 Coupling, 1" NPT 6rass, (Local Hardware Supply) 2 5534 13 Nipple, 1" NPT 5" Sing Brass, (Local Hardware Supply) 2 5586 14 Jacket Side Panels - PF-50/80 1 54173 15 Bulk Head Fitting 1 54149 16 Gasket for Bulk Head Fitting 1 54134 17 Leg Leveler 4 5429 18 Hook Bolt 2 5551 19 Convenience Outlet 1 54136 10 Leg Leveler 1 54236 11 Mok Bolt 1 54236 12 Control Module, S52MN - PF-50 1 54284 Control Module, S52MN - PF-80 1 54284 Control Module, S52MN - PF-10 1 54284	9	Nipple, 1" NPT x Close, (Local Hardware Supply)	1	99211
12 Coupling, 1" NPT Brass (Local Hardware Supply) 2 5534 13 Nipple, 1" NPT Sr Ss (Local Hardware Supply) 2 5869 14 Jacket Side Panels - PF-50300 1 54173 15 Bulk Head Fitting for Condensate Connection 1 54140 16 Gasket for Bulk Head Fitting 1 54140 17 Leg Leveler 4 5229 18 Hook Bolt 2 5451 19 Convenience Outlet 1 54136 10 Control Module, 852MN - PF-30 1 54283 11 Softast 54283 5573 12 Control Module, 852MN - PF-40 1 54283 14 Control Module, 852MN - PF-10 1 54283 14 Softast Fer.80 1 54283 12 Switch, Round Toggle, 120 VAC 1 54283 13 Saftast Vent/Air Intet Adapter, 3" 1 54133 14 Saftast Saftast Saftast 54005	10	Manual Shut-off Valve, 1/2" NPT, (Local Hardware Supply)	1	54130
13 Nipple, 1" NPT x 5" Long Brass, (Local Hardware Supply) 2 5869 Jacket Side Panels - PF-50/80 1 54173 Jacket Side Panels - PF-50/80 1 54173 Jacket Side Panels - PF-10/140 1 54192 15 Bulk Head Fitting for Condensate Connection 1 54140 16 Gasket for Bulk Head Fitting 1 54134 17 Leg Leveler 4 5429 18 Hook Bolt 2 5451 10 Convenience Outlet 1 54136 10 Houk Nut, #8-32 with Lockwasher, (Local Hardware Supply) 4 51573 10 Control Module, S2MN - PF-30 1 54282 11 Control Module, S2MN - PF-10 1 54284 12 Control Module, S2MN - PF-10 1 54285 21 Kent/Air Intel Adapter, 3" 1 54285 22 Switch, Round Toggle, 120 VAC 1 54285 23 Went/Air Intel Adapter, 3" 1 54133 24 Gasket, V	11	Screw, #10 x 1/2" Long Hex. Hd., (Local Hardware Supply)	4	99992
Jacket Side Panels - PF-50/80 1 54173 Jacket Side Panels - PF-110/140 1 54192 Bulk Head Fitting roudensate Connection 1 54140 Gasket for Bulk Head Fitting 1 54134 Ice Leveler 4 5429 Balk Hook Bolt 2 5451 Convenience Outlet 1 54136 Control Module, 852MN - PF-30 1 54282 Control Module, 852MN - PF-30 1 54283 Control Module, 852MN - PF-30 1 54283 Control Module, 852MN - PF-100 1 54284 Control Module, 852MN - PF-100 1 54285 Switch, Round Toggle, 120 VAC 1 54285 Switch, Round Toggle, 120 VAC 1 54285 Switch, Round Toggle, 120 VAC 1 54133 Seew, Witch Adapter, 3" 1 54132 Seew, Witch Adapter, 3" 1 54132 Seew, Witch Round Toggle, 120 VAC 1 54133 Seew, Witch Round Toggle, 120 VAC 1 54133 Seacew,	12	Coupling, 1" NPT Brass (Local Hardware Supply)	2	5534
Jacket Side Panels - PF-50/80 1 54173 Jacket Side Panels - PF-10/140 1 54192 Bulk Head Fitting for condensate Connection 1 54140 Gasket for Bulk Head Fitting for condensate Connection 1 54134 Leg Leveler 4 5429 Bhok Bolt 2 5451 Convenience Outlet 1 54136 Control Module, 852MN - PF-30 1 54282 Control Module, 852MN - PF-30 1 54283 Control Module, 852MN - PF-30 1 54283 Control Module, 852MN - PF-100 1 54283 Control Module, 852MN - PF-100 1 54283 Control Module, 852MN - PF-100 1 54285 Switch, Round Toggie, 120 VAC 1 6500 Switch, Round Toggie, 120 VAC 1 54133 Sorew, Rito S/S ¹ Cong Phil. Pan Head Type A Zinc, (Local Hardware Supply) 6 5507 Sorew, Rito S/S ¹ Cong Phil. Pan Head Type A Zinc, (Local Hardware Supply) 6 5507 Condensate Receiver KL with Hardware & Tubing 1 54133 <	13	Nipple, 1" NPT x 5" Long Brass, (Local Hardware Supply)	2	5869
14 jacket Side Panels – PF-110/140 1 54192 15 Bulk Head Fitting for Condensate Connection 1 54140 16 Gasket for Bulk Head Fitting 1 54134 17 Leg Leveler 4 5429 18 Hook Bolt 2 5451 19 Convenience Outlet 1 5436 20 Hex. Nut, #8-32 with Lockwasher, (Local Hardware Supply) 4 51573 Control Module, 852NN - PF-50 1 54282 Control Module, 852NN - PF-10 1 54283 Control Module, 852NN - PF-10 1 54284 Control Module, 852NN - PF-10 1 54285 Control Module, 852NN - PF-10 1 54284 Control Module, 852NN - PF-10 1 54285 Stare With As dayter, 3" 1 54135 Stare With S day Comp Bhil. Pan Head Type A Zinc, (Local Hardware Supply) 66 5507 26 Condensate Receiver Kit with Hardware & Tubing 1 54132 27 Condensate Receiver Coperidot Switch 1			1	54173
16 Gasket for Bulk Head Fitting 11 54134 17 Leg Leveler 44 5429 18 Hook Bolt 2 5451 19 Convenience Outlet 10 54136 20 Hex. Nut, #8-32 with Lockwasher, (Local Hardware Supply) 44 51573 21 Control Module, 852NN - PF-50 11 54282 22 Control Module, 852NN - PF-30 11 54283 21 Control Module, 852NN - PF-10 11 54284 Control Module, 852NN - PF-100 11 54284 Control Module, 852NN - PF-100 11 54285 22 Switch, Round Toggle, 120 VAC 11 54285 23 Vert,Air Iniet Adapter, 3" 11 54135 24 Gasket, Vent Adapter, 3" 11 54135 25 Screw, #10 x 5/8" long Phil. Pan Head Type A Zinc, (Local Hardware Supply) 66 5507 25 Condensate Receiver Kit with Hardware & Tubing 11 54132 26 Lordensate Receiver Kit with Hardware & Tubing 11	14		1	54192
16Gasket for Bulk Head Fitting1\$413417Leg Leveler4542918Hook Bolt2545119Convenience Outlet15413620Hex. Nut, #8-32 with Lockwasher, (Local Hardware Supply)45157321Control Module, 852MN - PF-5015428222Control Module, 852MN - PF-1015428322Control Module, 852MN - PF-1015428423Control Module, 852MN - PF-1015428524Gasket, Vent Adapter, 3"15413525Switch, Round Toggle, 120 VAC15413526Gasket, Vent Adapter, 3"15413527Gasket, Vent Adapter, 3"15413528Screw, #10 x 5/8" long Phil. Pan Head Type A Zinc, (Local Hardware Supply)6550726Condensate Receiver Kit with Hardware & Tubing154137276Condensate Receiver Kit with Hardware & Tubing154137276Condensate Receiver Cap/Fiot Switch154137277Condensate Receiver Cap/Fiot Switch154131278Flue Sensor, 12kOhm Tasseron TSD2081 (Accessible thru Electrical Enclosure)154141279Wiring Harness, Control (Left Terminal Block)194141274Wiring Harness, Control (Left Terminal Block)194141274Wiring Harness, Rower (Right Terminal Block)194141275Wiring Harness, Rower (Right Terminal Block)19	15	Bulk Head Fitting for Condensate Connection	1	54140
117Leg Leveler44542918Hock BoltC5413619Convenience OutletC5413620Hex. Nut, #8-32 with Lockwasher, (Local Hardware Supply)AS157320Control Module, 852MN - PF-50AS428220Control Module, 852MN - PF-10AS428320Control Module, 852MN - PF-10AS428321Control Module, 852MN - PF-10AS428322Switch, Round Toggle, 120 VACAS413323Vent/Ar Inlet Adapter, 3"S1138S413324Gaster, Vent Adapter, 3"AS413325Screw, #10 x S/8" Long Phil. Pan Head Type Azinc, (Local Hardware Supply)AS413326Condensate Receiver Ku with Hardware & TubingAS413327Condensate Receiver Cap/Float SwitchAS413328Condensate Receiver Cap/Float SwitchAS413329Condensate Receiver Cap/Float SwitchAS4134204Condensate Receiver Cap/Float SwitchAS4134215Condensate Receiver Cap/Float SwitchAS4134216Condensate Neutralizer Ku thi Hardware & TubingAS4134217Condensate Neutralizer Ku thi Hardware & TubingAS4134218Huimi Switch Tasseron TSD2081 (Accessible thru Electrical Enclosure)AS4141219Hi Limit Switch Tasseron TSD2081 (Accessible thru Electrical Enclosure)AA210Wiring Harness, Rower (Rig	16		1	54134
18 Hook Bolt 2 5451 19 Convenience Outlet 11 54136 20 Hex. Nut, #8-32 with Lockwasher, (Local Hardware Supply) 4 51573 20 Hex. Nut, #8-32 with Lockwasher, (Local Hardware Supply) 4 51573 21 Control Module, 852MN - PF-50 11 54283 20 Control Module, 852MN - PF-10 1 54283 20 Switch, Round Toggle, 120 VAC 1 6050 23 Vent/Air Inlet Adapter, 3" 1 54133 24 Gasket, Vent Adapter, 3" 1 54133 25 Screw, #10 x 5/8" Comp Phil. Pan Head Type A Zinc, (Local Hardware Supply) 6 5507 26 Condensate Receiver Kit with Hardware & Tubing 1 54133 264 Condensate Receiver Vessel 1 54137 276 Condensate Receiver Cap/Float Switch 1 54137 276 Condensate Neutralizer Vessel 1 54139 271 Condensate Neutralizer Vessel 1 54139 272 <t< td=""><td></td><td></td><td></td><td></td></t<>				
19 Convenience Outlet 1 54136 20 Hex. Nut, #3-2 with Lockwasher, (Local Hardware Supply) 4 51573 21 Control Module, 852MN - PF-50 1 54282 21 Control Module, 852MN - PF-80 1 54283 21 Control Module, 852MN - PF-80 1 54284 22 Switch, Round Toggle, 120 VAC 1 6050 23 Vent/Air Inlet Adapter, 3" 1 54133 24 Gasket, Vent Adapter, 3" 1 54133 25 Screw, #10 x 5/8" Long Phil. Pan Head Type A Zinc, (Local Hardware Supply) 6 5507 26 Condensate Receiver Kit with Hardware & Tubing 1 54132 26 Condensate Receiver Vessel 1 54132 26 Condensate Receiver Kit with Hardware & Tubing 1 54132 27 Condensate Receiver Kit with Hardware & Tubing 1 54132 27 Condensate Neutralizer Kit with Hardware & Tubing 1 54132 27 Condensate Neutralizer Kit with Hardware & Tubing 1 54132 </td <td></td> <td></td> <td>2</td> <td></td>			2	
20Hex. Nut, #8-32 with Lockwasher, (Local Hardware Supply)45157321Control Module, 852MN - PF-50154282Control Module, 852MN - PF-50154283Control Module, 852MN - PF-100154283Control Module, 852MN - PF-14015428522Switch, Round Toggle, 120 VAC1605023Vent/Air Inlet Adapter, 3"15413524Gastev, Vent Adapter, 3"15413525Screw, #10 x 5/8" Long Phil. Pan Head Type A Zinc, (Local Hardware Supply)6550726Condensate Receiver Kit with Hardware & Tubing154137256Condensate Receiver Kit with Hardware & Tubing154137266Condensate Receiver Vessel154137270Condensate Receiver Cap/Float Switch154137271Condensate Receiver Cap/Float Switch154139272Condensate Neutralizer Kit with Hardware & Tubing154139273Condensate Neutralizer Kit with Hardware & Tubing154139274Condensate Neutralizer Vessel154139275Condensate Neutralizer Kit with Hardware & Tubing154139276Indensate Neutralizer Neutralizer Vessel154139277Condensate Neutralizer Kit with Hardware & Tubing154139278File Sensor, 12kOhm Tasseron TSD008 (Accessible thru Electrical Enclosure)154119379Wiring Harness, Neuron (Lieft Terminal Block)1PF7003 <td></td> <td></td> <td></td> <td></td>				
Control Module, 852MN - PF-50 1 54282 21 Control Module, 852MN - PF-30 1 54283 Control Module, 852MN - PF-10 1 54284 Control Module, 852MN - PF-10 1 54285 22 Switch, Round Toggle, 120 VAC 1 6050 23 Vent/Air Inlet Adapter, 3" 1 54135 24 Gasket, Vent Adapter, 3" 1 54135 25 Screw, #10 x 5/8" Long Phil. Pan Head Type A Zinc, (Local Hardware Supply) 6 5507 26 Condensate Receiver KIt with Hardware & Tubing 1 54120 26b Condensate Receiver KIt with Hardware & Tubing 1 54137 26cd Large Hose Clamp 1 54138 26d Small Hose Clamp 1 54139 27 Condensate Neutralizer Kit with Hardware & Tubing 1 54139 27 Condensate Neutralizer Kit with Hardware & Tubing 1 54139 28 Filee Sensor, 12kOhm Tasseron TSD00B1 (Accessible thru Electrical Enclosure) 1 54139 28 Filue Sen				
21Control Module, 852MN - PF-80154283Control Module, 852MN - PF-10154284Control Module, 852MN - PF-14015428522Switch, Round Toggle, 120 VAC1650023Vent/Air Inlet Adapter, 3"15413524Gasket, Vent Adapter, 3"15413525Screw, H10 x 5/8" Long Phil. Pan Head Type A Zinc, (Local Hardware Supply)6550726Condensate Receiver Kit with Hardware & Tubing15412526aCondensate Receiver Cap/Float Switch15412726bCondensate Receiver Cap/Float Switch15413726cLarge Hose Clamp15413727cCondensate Neutralizer Kit with Hardware & Tubing15413727dCondensate Neutralizer Kit with Hardware & Tubing15413727dCondensate Neutralizer Kit with Hardware & Tubing15413727dCondensate Neutralizer Vessel15413127dCondensate Neutralizer Vessel15413127bCondensate Neutralizer Vessel15413127bCondensate Neutralizer Media (1 lb bag)15413127bSupply/Return Sensor, 12kOhm Tasseron TSDOBS25441830Supply/Return Sensor, 12kOhm Tasseron TSDOBS1PF700231Wiring Harness, Control (Left Terminal Block)1PF700331Wiring Harness, Control (Left Terminal Block)1PF700332Nuing Harness, Control (Left Terminal				
21Control Module, 852MN - PF-110154284Control Module, 852MN - PF-14015428522Switch, Round Toggle, 120 VAC1660523Vent/Air Inlet Adapter, 3"15413524Gasket, Vent Adapter, 3"15413325Screw, #10 x 5/8" Long Phil. Pan Head Type A Zinc, (Local Hardware Supply)6550726Condensate Receiver Kit with Hardware & Tubing15420526aCondensate Receiver Cap/Float Switch15413726cLarge Hose Clamp25413826dSmall Hose Clamp25413827Condensate Receiver Cap/Float Switch15412027aCondensate Neutralizer Kit with Hardware & Tubing15413727bCondensate Neutralizer Kit with Hardware & Tubing15413927bCondensate Neutralizer Kit with Hardware & Tubing15415928Flue Sensor, 12kOhm Tasseron TSD20B1 (Accessible thru Electrical Enclosure)15411129Hi Limit Switch Tasseron TSD20B1 (Accessible thru Electrical Enclosure)15411129Hi Limit Switch Tasseron TSD00BS254418-Wiring Harness, Control (Left Terminal Block)1PF7003-Wiring Harness, Control (Left Terminal Block)1PF7009-Wiring Harness, Control (Left Terminal Block)1PF7009-Wiring Harness, Control (Left Terminal Block)1PF7009-Nuring Harness, Control (Left Terminal Block)<				
Control Module, 852MN - PF-140 1 54285 22 Switch, Round Toggle, 120 VAC 1 6050 23 Vent/Air Inlet Adapter, 3" 1 54135 24 Gasket, Vent Adapter, 3" 1 54135 24 Gasket, Vent Adapter, 3" 1 54135 25 Screw, #10 x 5/8" Long Phil. Pan Head Type A Zinc, (Local Hardware Supply) 6 5507 26 Condensate Receiver Kit with Hardware & Tubing 1 54120 26a Condensate Receiver Kit with Hardware & Tubing 1 54137 26c Large Hose Clamp 1 54137 26c Large Hose Clamp 1 54138 26d Small Hose Clamp 1 54137 27c Condensate Neutralizer Kit with Hardware & Tubing 1 54138 27d Condensate Neutralizer Kit with Hardware & Tubing 1 54139 27a Condensate Neutralizer Kit with Hardware & Tubing 1 54139 27b Condensate Neutralizer Media (1 lb bag) 1 54111 27b <t< td=""><td>21</td><td></td><td></td><td></td></t<>	21			
22 Switch, Round Toggle, 120 VAC 1 6050 23 Vent/Air Inlet Adapter, 3" 1 54135 24 Gasket, Vent Adapter, 3" 1 54135 24 Gasket, Vent Adapter, 3" 1 54135 24 Gasket, Vent Adapter, 3" 1 54135 25 Screw, #10 x 5/8" Long Phil. Pan Head Type A Zinc, (Local Hardware Supply) 6 5507 26 Condensate Receiver Kit with Hardware & Tubing 1 54120 26a Condensate Receiver Vessel 1 54137 26c Large Hose Clamp 2 54138 26d Small Hose Clamp 1 54120 27 Condensate Neutralizer Kit with Hardware & Tubing 1 54121 27b Condensate Neutralizer Kit with Hardware & Tubing 1 54121 27b Condensate Neutralizer Kit with Hardware & Tubing 1 54121 27b Condensate Neutralizer Kit with Hardware & Tubing 1 54121 27b Condensate Neutralizer Kit with Hardware & Tubing 1 54121				
23Vent/Air Inlet Adapter, 3"15413524Gasket, Vent Adapter, 3"15413325Screw, #10 x 5/8" Long Phil. Pan Head Type A Zinc, (Local Hardware Supply)6550726Condensate Receiver Kit with Hardware & Tubing15412026aCondensate Receiver Vessel15413726cLarge Hose Clamp25413826dSmall Hose Clamp25413827Condensate Neutralizer Kit with Hardware & Tubing15413727Condensate Neutralizer Kit with Hardware & Tubing15413927Condensate Neutralizer Kit with Hardware & Tubing15412127bCondensate Neutralizer Kit with Hardware & Tubing15412127bCondensate Neutralizer Vessel15413928Flue Sensor, 12kOhm Tasseron TSD20B1 (Accessible thru Electrical Enclosure)15413929Hi Limit Switch Tasseron TSD0BS254418-Wiring Harness, Power (Right Terminal Block)1PF7002-Wiring Harness, Blower1PF7003-Wiring Harness, Blower1S0664-Outdoor Sensor, 12kOhm Tasseron TSA00B41S0664-Outdoor Sensor, 12kOhm Tasseron TSA00B41S4112-DHW Sensor, 12kOhm Tasseron TSA00B41S4112-Outdoor Sensor, 12kOhm Tasseron TSA00B41S4112-DHW Sensor, 12kOhm Tasseron TSA00B41S4112-DHW Sensor, 12kOhm Tas	22			
24 Gasket, Vent Adapter, 3" 1 54133 25 Screw, #10 x 5/8" Long Phil. Pan Head Type A Zinc, (Local Hardware Supply) 6 5507 26 Condensate Receiver Kit with Hardware & Tubing 1 54205 26a Condensate Receiver Vessel 1 54120 26b Condensate Receiver Cap/Float Switch 1 54137 26c Large Hose Clamp 2 54138 26d Small Hose Clamp 1 54120 27a Condensate Neutralizer Kit with Hardware & Tubing 1 54121 27b Condensate Neutralizer Vessel 1 54121 27b Condensate Neutralizer Kit with Hardware & Tubing 1 54121 27b Condensate Neutralizer Vessel 1 54121 27b Condensate Neutralizer Kit with Tasseron TSD20B1 (Accessible thru Electrical Enclosure) 1 54111 28 Flue Sensor, 12kOhm Tasseron TSD00BS 2 54418 - Wiring Harness, Control (Left Terminal Block) 1 PF7002 - Wiring Harness, Blower 1				
25 Screw, #10 x 5/8" Long Phil. Pan Head Type A Zinc, (Local Hardware Supply) 6 5507 26 Condensate Receiver Kit with Hardware & Tubing 1 54205 26a Condensate Receiver Vessel 1 54120 26b Condensate Receiver Cap/Float Switch 1 54137 26c Large Hose Clamp 2 54138 26d Small Hose Clamp 1 54129 27 Condensate Neutralizer Kit with Hardware & Tubing 1 54139 27 Condensate Neutralizer Vessel 1 54121 27b Condensate Neutralizer Vessel 1 54121 27b Condensate Neutralizer Media (1 lb bag) 1 54121 27b Condensate Neutralizer Media (1 lb bag) 1 54121 27b Condensate Neutralizer Media (1 lb bag) 1 54121 27b Condensate Neutralizer Media (1 lb bag) 1 54121 28 Flue Sensor, 12kOhm Tasseron TSD20B1 (Accessible thru Electrical Enclosure) 1 97002 4 Wiring Harness, Power (Right Terminal Block)				
26Condensate Receiver Kit with Hardware & Tubing15420526aCondensate Receiver Vessel15412026bCondensate Receiver Cap/Float Switch15413726cLarge Hose Clamp25413826dSmall Hose Clamp15413927Condensate Neutralizer Kit with Hardware & Tubing15412027aCondensate Neutralizer Vessel15412127bCondensate Neutralizer Vessel15412127cCondensate Neutralizer Vessel15412127bCondensate Neutralizer Vessel15415928Flue Sensor, 12kOhm Tasseron TSD20B1 (Accessible thru Electrical Enclosure)15411129Hi Limit Switch Tasseron TSD20B2 (Accessible thru Electrical Enclosure)15414930Supply/Return Sensor, 12kOhm Tasseron TSD00BS254418-Wiring Harness, Power (Right Terminal Block)1PF7002-Wiring Harness, Blower1PF7005-Wiring Harness, Ground Wire1PF7005-Wiring Harness, Ground Wire1S0664-Outdoor Sensor, 12kOhm Tasseron TSA00B4154112-DHW Sensor, 12kOhm Tasseron TSA00B4154112-DHW Sensor, 12kOhm Tasseron TSA00B4-54157				
26aCondensate Receiver Vessel15412026bCondensate Receiver Cap/Float Switch15413726cLarge Hose Clamp25413826dSmall Hose Clamp15413927Condensate Neutralizer Kit with Hardware & Tubing15412027aCondensate Neutralizer Vessel15412127bCondensate Neutralizer Vessel15415928Flue Sensor, 12kOhm Tasseron TSD20B1 (Accessible thru Electrical Enclosure)15411129Hi Limit Switch Tasseron TSD20B1 (Accessible thru Electrical Enclosure)15441930Supply/Return Sensor, 12kOhm Tasseron TSD00BS254418-Wiring Harness, Power (Right Terminal Block)1PF7002-Wiring Harness, Ground Wire1PF7003-Wiring Harness, Ground Wire1PF7003-Relief Valve150664-Outdoor Sensor, 12kOhm Tasseron TSA008415450-DHW Sensor, 12kOhm Tasseron TSA0084-5450				
26bCondensate Receiver Cap/Float Switch15413726cLarge Hose Clamp25413826dSmall Hose Clamp15413927Condensate Neutralizer Kit with Hardware & Tubing15420427aCondensate Neutralizer Vessel15412127bCondensate Neutralizer Media (1 lb bag)15415928Flue Sensor, 12kOhm Tasseron TSD20B1 (Accessible thru Electrical Enclosure)15411129Hi Limit Switch Tasseron TSD295015441930Supply/Return Sensor, 12kOhm Tasseron TSD00BS254418-Wiring Harness, Power (Right Terminal Block)1PF7002-Wiring Harness, Ground Wire1PF7003-Wiring Harness, Ground Wire1PF7009-Push-on Terminal Block (for Field Wiring Connections)25450-Relief Valve150664-Outdoor Sensor, 12kOhm Tasseron TSA00B4154112-DHW Sensor, 12kOhm Tasseron TSK10BH (Optional)54157				
26cLarge Hose Clamp25413826dSmall Hose Clamp15413927Condensate Neutralizer Kit with Hardware & Tubing15420427aCondensate Neutralizer Vessel15412127bCondensate Neutralizer Media (1 lb bag)15415928Flue Sensor, 12kOhm Tasseron TSD20B1 (Accessible thru Electrical Enclosure)15411129Hi Limit Switch Tasseron TSD20B1 (Accessible thru Electrical Enclosure)15441930Supply/Return Sensor, 12kOhm Tasseron TSD00BS254418-Wiring Harness, Power (Right Terminal Block)1PF7002-Wiring Harness, Control (Left Terminal Block)1PF7003-Wiring Harness, Ground Wire1PF7009-Push-on Terminal Block (for Field Wiring Connections)25450-Relief Valve150664-Outdoor Sensor, 12kOhm Tasseron TSA00B4154112-DHW Sensor, 12kOhm Tasseron TSA00B4-54157				
26dSmall Hose Clamp15413927Condensate Neutralizer Kit with Hardware & Tubing15420427aCondensate Neutralizer Vessel15412127bCondensate Neutralizer Media (1 lb bag)15415928Flue Sensor, 12kOhm Tasseron TSD20B1 (Accessible thru Electrical Enclosure)15411129Hi Limit Switch Tasseron TSD20B1 (Accessible thru Electrical Enclosure)15411930Supply/Return Sensor, 12kOhm Tasseron TSD00BS254418-Wiring Harness, Power (Right Terminal Block)1PF7002-Wiring Harness, Control (Left Terminal Block)1PF7003-Wiring Harness, Blower1PF7005-Wiring Harness, Ground Wire1PF7009-Push-on Terminal Block (for Field Wiring Connections)25450-Relief Valve150664-Outdoor Sensor, 12kOhm Tasseron TSA00B4154112-DHW Sensor, 12kOhm Tasseron TSK10BH (Optional)-54157				
27Condensate Neutralizer Kit with Hardware & Tubing15420427aCondensate Neutralizer Vessel15412127bCondensate Neutralizer Media (1 lb bag)15415928Flue Sensor, 12kOhm Tasseron TSD20B1 (Accessible thru Electrical Enclosure)15411129Hi Limit Switch Tasseron TSD595015441930Supply/Return Sensor, 12kOhm Tasseron TSD00BS254418-Wiring Harness, Power (Right Terminal Block)1PF7002-Wiring Harness, Control (Left Terminal Block)1PF7003-Wiring Harness, Ground Wire1PF7003-Wiring Harness, Ground Wire1PF7009-Relief Valve150664-Outdoor Sensor, 12kOhm Tasseron TSA00B4154112-DHW Sensor, 12kOhm Tasseron TSA00BH (Optional)-54157				
27aCondensate Neutralizer Vessel15412127bCondensate Neutralizer Media (1 lb bag)15415928Flue Sensor, 12kOhm Tasseron TSD20B1 (Accessible thru Electrical Enclosure)15411129Hi Limit Switch Tasseron TSD20B1 (Accessible thru Electrical Enclosure)15441930Supply/Return Sensor, 12kOhm Tasseron TSD00BS254418-Wiring Harness, Power (Right Terminal Block)1PF7002-Wiring Harness, Control (Left Terminal Block)1PF7033-Wiring Harness, Blower1PF7005-Viring Harness, Ground Wire1PF7009-Push-on Terminal Block (for Field Wiring Connections)25450-Relief Valve150664-Outdoor Sensor, 12kOhm Tasseron TSA00B4154112-DHW Sensor, 12kOhm Tasseron TSK10BH (Optional)-54157				
27bCondensate Neurtralizer Media (1 lb bag)15415928Flue Sensor, 12kOhm Tasseron TSD20B1 (Accessible thru Electrical Enclosure)15411129Hi Limit Switch Tasseron TSD295015441930Supply/Return Sensor, 12kOhm Tasseron TSD00BS254418-Wiring Harness, Power (Right Terminal Block)1PF7002-Wiring Harness, Control (Left Terminal Block)1PF7003-Wiring Harness, Blower1PF7005-Wiring Harness, Ground Wire1PF7009-Push-on Terminal Block (for Field Wiring Connections)25450-Relief Valve150664-Outdoor Sensor, 12kOhm Tasseron TSA00B4154112-DHW Sensor, 12kOhm Tasseron TSK10BH (Optional)-54157		-		
28Flue Sensor, 12kOhm Tasseron TSD20B1 (Accessible thru Electrical Enclosure)15411129Hi Limit Switch Tasseron TSD595015441930Supply/Return Sensor, 12kOhm Tasseron TSD00BS254418-Wiring Harness, Power (Right Terminal Block)1PF7002-Wiring Harness, Control (Left Terminal Block)1PF7003-Wiring Harness, Blower1PF7005-Wiring Harness, Ground Wire1PF7009-Push-on Terminal Block (for Field Wiring Connections)25450-Relief Valve150664-Outdoor Sensor, 12kOhm Tasseron TSA00B4154112-DHW Sensor, 12kOhm Tasseron TSK10BH (Optional)-54157				
29Hi Limit Switch Tasseron TSDS95015441930Supply/Return Sensor, 12k0hm Tasseron TSD00BS254418-Wiring Harness, Power (Right Terminal Block)1PF7002-Wiring Harness, Control (Left Terminal Block)1PF7003-Wiring Harness, Blower1PF7005-Wiring Harness, Ground Wire1PF7009-Push-on Terminal Block (for Field Wiring Connections)25450-Relief Valve150664-Outdoor Sensor, 12kOhm Tasseron TSA00B4154112-DHW Sensor, 12kOhm Tasseron TSK10BH (Optional)-54157				
30Supply/Return Sensor, 12k0hm Tasseron TSD00BS254418-Wiring Harness, Power (Right Terminal Block)1PF7002-Wiring Harness, Control (Left Terminal Block)1PF7003-Wiring Harness, Blower1PF7005-Wiring Harness, Ground Wire1PF7009-Push-on Terminal Block (for Field Wiring Connections)25450-Relief Valve150664-Outdoor Sensor, 12k0hm Tasseron TSA00B4154112-DHW Sensor, 12k0hm Tasseron TSK10BH (Optional)-54157				
- Wiring Harness, Power (Right Terminal Block) 1 PF7002 - Wiring Harness, Control (Left Terminal Block) 1 PF7003 - Wiring Harness, Blower 1 PF7005 - Wiring Harness, Ground Wire 1 PF7009 - Push-on Terminal Block (for Field Wiring Connections) 2 5450 - Relief Valve 1 50664 - Outdoor Sensor, 12kOhm Tasseron TSA00B4 1 54112 - DHW Sensor, 12kOhm Tasseron TSK10BH (Optional) - 54157				
- Wiring Harness, Control (Left Terminal Block) 1 PF7003 - Wiring Harness, Blower 1 PF7005 - Wiring Harness, Ground Wire 1 PF7009 - Push-on Terminal Block (for Field Wiring Connections) 2 5450 - Relief Valve 1 50664 - Outdoor Sensor, 12kOhm Tasseron TSA00B4 1 54112 - DHW Sensor, 12kOhm Tasseron TSK10BH (Optional) - 54157				
- Wiring Harness, Blower 1 PF7005 - Wiring Harness, Ground Wire 1 PF7009 - Push-on Terminal Block (for Field Wiring Connections) 2 5450 - Relief Valve 1 50664 - Outdoor Sensor, 12kOhm Tasseron TSA00B4 1 54112 - DHW Sensor, 12kOhm Tasseron TSK10BH (Optional) 54157				
-Wiring Harness, Ground Wire1PF7009-Push-on Terminal Block (for Field Wiring Connections)25450-Relief Valve150664-Outdoor Sensor, 12kOhm Tasseron TSA00B4154112-DHW Sensor, 12kOhm Tasseron TSK10BH (Optional)54157				
- Push-on Terminal Block (for Field Wiring Connections) 2 5450 - Relief Valve 1 50664 - Outdoor Sensor, 12kOhm Tasseron TSA00B4 1 54112 - DHW Sensor, 12kOhm Tasseron TSK10BH (Optional) - 54157				
- Relief Valve 1 50664 - Outdoor Sensor, 12kOhm Tasseron TSA00B4 1 54112 - DHW Sensor, 12kOhm Tasseron TSK10BH (Optional) - 54157				
- Outdoor Sensor, 12kOhm Tasseron TSA00B4 1 54112 - DHW Sensor, 12kOhm Tasseron TSK10BH (Optional) - 54157				
- DHW Sensor, 12kOhm Tasseron TSK10BH (Optional) - 54157				
		System Sensor, 12kOhm Tasseron TSA00BC (Optional)		54157





 Table 13.2:
 Heat Exchanger/Burner Assembly Repair Parts – PF-50, PF-80, PF-110 & PF-140

	Description	Quantity Required	Stock Code
1	Kit Igniter & Cable w / Gasket & Hardware	1	54246
1a	Igniter Only	1	54224
1b	Igniter Cable	1	54298
1c	Igniter Gasket	1	54123
2	Flame Sensor w / Gasket & Hardware	1	54247
2a	Flame Sensor only	1	54295
2b	Flame Sensor Gasket	1	54124
3	Screw, M4 x 8mm	4	6507
4	Screw, M5.5 x 14mm	5	6506
5	Channel, Air Inlet	1	54182
6	Gasket, Channel to Burner	1	54897
	Burner – PF-50 (Boilers built pre-August 2011)	1	54174
	Burner – PF-50/80	1	54901
7	Burner – PF-110	1	54902
	Burner – PF-140	1	54903
8	Nut, M6, 10MM Hex	6	51614
9	Combustion Chamber Cover Rate, includes items #45-#47, obs	1	54183
10	Gasket, Rubber	1	54187
11	Insulation, Combustion Chamber Cover Plate	1	54255
12	M4 X 16 MM SS Screw Target Wall	1	6511
13	Washer, M4	1	6510
14	Insulation, Target Wall	1	54185
	Heat Exchanger – PF-50/80	1	5411
15	Heat Exchanger – PF-110	1	5412
15	Heat Exchanger – PF-140	1	5412
16	Gasket, Blower to Channel	1	54122
10	Blower – PF-50/80	1	54189
17	Blower – PF-110	1	54190
1/	Blower – PF-140	1	54190
18	M5 X 12MM Screw	4	5415
18		1	5415
20	Blower Adapter Rate M4 x 10mm Screw	3	5421
	Swirl Plate – PF-50/80, Black	1	54143
21		1	54145
21	Swirl Plate – PF-110, White Swirl Plate – PF-140, Red	1	54145
		1	
22	Gas Valve – PF-50180, w / Mtg. Flange, Swirl Rate & Screws	1	54179 54180
22	Gas Valve – PF-110, w / Mtg. Flange, Swirl Rate & Screws	1	54180
22	Gas Valve – PF-140, w / Mtg. Flange, Swirl Rate & Screws		
23	Rectifier Cap Screw, M4 x 30mm, (Local Hardware Supply)	1	54125
24	PF-50/80/110 – Screw, M4 x 20mm	4	5518
Vont 7	PF-140 – Screw, M4 x 25mm	4	5519
	Perminations	1	E4106
-	3" Stainless Steel Screen		54196
	4" Stainless Steel Screen	1	54213
	3" PVC Tee	1	54151
	4" PVC Tee	1	54218
_	3" PVC Coupling	1	54152
-	4" PVC Coupling	1	54219





Table 13.3: General Repair Parts - PF-200, PF-210, PF-300 & PF-399

	Description	Quantity Required	Stock Code
1	Panel, Jacket Front Door, with Ball Studs	1	54256
2	Lens for Jacket Front Door	1	54167
3	Display Module 852RC (PF-50/399)	1	54702
4	Gasket for Display Bracket	1	54513
5	Bracket for Display Module	1	PF2007-1
6	Hex Nut, #6-32 with Lock washer (Local Hdwr Supply)	2	51553
7	Screw, #6-32 x 1/2" LG Phillips Head, (Local Hdwr Supply)	2	5449
8	Flexible Gas Line – 3/4" – PF-200/210	1	54497
	Flexible Gas Line – 3/4" – PF-300/399	1	54262
9	Manual Shut-off Valve, 3/4" NPT, Full Port	1	51805
10	Screw, #10 x 1/2" LG Hex. Hd., (Local Hdwr Supply)	4	99992
11	Jacket, Lower Front Panel	1	PF6051
12	Bulk Head Fitting for Condensate Hose	1	54140
13	Gasket for Bulk Head Fitting	1	54134
14	Leg Leveler	4	5429
15	Coupling, 1" NPT Brass, (Local Hdwr Supply) – PF-210	2	5534
	Coupling, 1-1/2" NPT Brass, (Local Hdwr Supply) – PF-399	2	5551
16	Nipple, 1" NPT x 14" LG Brass, (Local Hdwr Supply) – PF-210	2	5557
	Nipple, 1-1/2" NPT x 14" LG Brass, (Local Hdwr Supply) – PF-399 Elbow, 1" NPT Brass, (Local Hdwr Supply) – PF-210	2	5550
17	Elbow, 1-1/2" NPT Brass, (Local Hdwr Supply) – PF-210 Elbow, 1-1/2" NPT Brass, (Local Hdwr Supply) – PF-399	1	5558 5553
	Tee, 1" NPT Brass, (Local Hdwr Supply) – PF-210	1	5537
18	Tee, $1-1/2''$ NPT Brass, (Local Hdwr Supply) – PF-319	1	5554
	Nipple, 1" NPT x 3" Brass, (Local Hdwr Supply) – PF-210	2	5559
19	Nipple, 1-1/2" NPT x 3" Brass, (Local Hdwr Supply) – PF-399	2	5555
	Bushing, 1" x $3/4$ " NPT Brass, (Local Hdwr Supply) – PF-200/210	1	5539
20	Bushing, 1-1/2" x 3/4" NPT Brass, (Local Hdwr Supply) – PF-300/399	1	5556
21	Shut-off Valve, 3/4" NPT Brass, (Local Hdwr Supply)	1	50764
22	Convenience Outlet	1	54136
23	Hex. Nut, #8-32 with Lockwasher, (Local Hdwr Supply)	4	51573
	Control Module, 852MN – PF-200	1	54685
24	Control Module, 852MN – PF-210	1	54287
24	Control Module, 852MN – PF-300	1	54683
	Control Module, 852MN – PF-399	1	54287
25	3.15A. 250V 5x20mm Slow-Blow Glass Fuse, Radio Shack-270-1067	1	5650
26	Rocker Switch (20A, 120 VAC, (Local Hdwr Supply)	1	6050
27	Pump Isolation Relay Module Kit Includes harness	1	54610
28	10-Amp 125V 5x20mm Slow Blow Fuse, Radio Shack-270-152	4	_
29	Vent/Air Inlet Adapter - PF-200/210	1	54293
	Vent/Air Inlet Adapter - PF-300/399	1	54294
30	Vent Adapter Gasket - PF-200/210	1	54133
	Vent Adapter Gasket - PF-300/399	1	54217
31	Screw #10 x 3/4" Long Phillips Pan Head	6	5611
32	Heat Exchanger Outlet Collar 3" PF-200/210	1	5531
22	Heat Exchanger Outlet Collar 4" PF-300/399	1	5532
33 34	Condensate Neutralizer Assembly Condensate Receiver Assembly	1	54204 54259
34	Blocked Vent Switch Kit - Include Items #36 & #37	1	54259
36	1/4" ID PVC Tubing x 12" Long	1	5697
30	90° Barbed Elbow - Polypropylene Adapter Fitting	1	5698
38	Gasket - Cover Plate	1	54141
39	Cover Plate for Thermal Temperature Switch	1	PF2021
40	High Temperature Limit Switch - Tasseron TSDS950 - 95C	1	54419
41	Supply/Return Sensor - 12 KΩ Tasseron TSD00BS	1	54418
42	Flue Sensor Grommet - EPDM	1	54291
43	Flue Sensor - 12 KΩ Tasseron TSD20B0	1	54209
44	Thermal Temp Limit Switch - 605 F	1	54475
45	Temperature Limiter - TK32-14	1	50045





Table 13.4: Heat Exchanger/Burner Assembly Repair Parts – PF-200, PF-210, PF-300 & PF-399

	Description	Quantity Required	Stock Code
1	Kit Igniter & Cable w/ Hardware, PF50/80/110/140	1	54246
1a	Igniter Only	1	54224
1b	Igniter Cable	1	54298
1c	Igniter Gasket	1	54123
2	Flame Sensor, with Gasket, Rauschert	1	54247
2a	Flame Sensor Only	1	54295
2b	Flame Sensor Gasket	1	54124
3	Screw, M4 X 8mm, (Local Hdwr Supply)	4	6507
4	Screw, M5.5 x 14mm	5	6506
_	Premix Channel – PF-200/210	1	54249
5	Premix Channel – PF-300/399	1	54250
6	Gasket, Channel to Burner	1	54186
-	Burner – PF-200/210	1	54904
7	Burner – PF-300/399	1	54264
8	Nut, M6, 10MM Hex, (Local Hdwr Supply)	6	61614
	210 Combustion Chamber Cover Plate Kit, Current, Current, includes items #8-#12	1	54206
9	399 Combustion Chamber Cover Plate Kit, Current, Current, includes items #8-#12	1	54207
9a	Combustion Chamber Cover PF	1	54183
10	Thermal Temp Limit - Manual Reset, 435F – Burner Plate	1	50045
11	Gasket, Rubber	1	54187
12	Insulation, Combustion Chamber Cover Plate	1	54255
13	M4 X 8 MM SS Screw Target Wall, (Local Hdwr Supply)	1	6511
14	Washer, M4, (Local Hdwr Supply)	1	6510
15	Insulation, Target Wall	1	54185
10	Heat Exchanger – PF-200/210	1	5529
16	Heat Exchanger – PF-300/399	1	5530
17	Gasket, Blower to Channel	1	54122
10	Blower Kit, PF-200/210	1	54258
18	Blower Kit, PF-300/399	1	54257
19	M5 X 12MM Screw, (Local Hdwr Supply)	4	5415
20	Blower Adapter Plate – PF-200/210 - ø43 mm	1	5421
20	Blower Adapter Plate – PF-300/399 - ø50 mm	1	5610
21	M4 x 10mm Screw - Phillips Flat Head	3	5422
22	Swirl Plate – PF-210, Grey	1	54251
	Swirl Plate – PF-399, Black	1	54252
23	Gas Valve – PF-210, includes item #22	1	54253
	Gas Valve – PF-399, includes item #22	1	54254
24	PF-210, Screw M4 x 25 mm T20 TORX	3	5519
24	PF-399, Screw M4 x 30 mm T20 TORX	3	5621

REPAIR PARTS



Figure 13.5: Concentric Horizontal Vent Termination



Figure 13.6: Concentric Vertical Vent Termination

Figure 13.7: Polypropylene Adapter

Table 13.5:	Optional Exhaust Vent Termination Kits
-------------	---

		Appli		
	Description	PF-50 thru PF-210	PF-300 & PF-399	Stock Code
-	3" Concentric Sidewall Termination Kit (PolyPro 3PPS-HK)	•		54498
-	4" Concentric Sidewall Termination Kit (PolyPro 4PPS-HK)		•	54499
-	3" Concentric Vertical Termination Kit (PolyPro 3PPS-VK)	•		54500
_	4" Concentric Vertical Termination Kit (PolyPro 4PPS-VK)		•	54501

Table 13.6: Optional Polypropylene Exhaust System Adapters

		Appli		
	Description	PF-50 thru PF-210	PF-300 & PF-399	Stock Code
_	3" Polypropylene Vent/Inlet Adapter (Innoflue ISAGL0303)	•		54632
_	4" Polypropylene Vent/Inlet Adapter (Innoflue ISAGL0404)		•	54633
-	3" Polypropylene Vent/Inlet Adapter (PolyPro 3PPS-AD)	•		54630
_	4" Polypropylene Vent/Inlet Adapter (PolyPro 4PPS-AD)		•	54631

APPENDIX A. STATUS SCREENS

PureFire Condensing Boiler - Status Display

PEERLESS PUREFIRE initializing Version [xxxx]	Peerless PureFire Initialization Screen: This screen is displayed when power is first supplied to the boiler. The software version, indicated by xxxx, indicates the version of the program for the interface module. This information should be noted if contacting PB Heat for technical support.			
16:36 STANDBY 160°F	call for heat, the display on the user interface module will show that the boiler is in "STANDBY" mode. In			
Central Heating Demand				

16:36 CENTRAL HEATING Trial For Ignition	Central Heating (CH) Trial for Ignition: When a contact closure between terminal #1 & #2 occurs, the control begins a trial for ignition. The display shows that the boiler demand is for central heating and indicates that a trial for ignition has been initiated. The Ignition cycle shown in Table 8.5 is identical for central heating and domestic hot water demand.
16:36 CENTRAL HEATING 100%Input 160°F	Central Heating (CH) Demand: When the burner is on, the display continues to show the demand type. On the lower left, the percentage of modulation is shown. This screen also shows the time, in 24 hour format, and the actual supply temperature as read by the supply sensor.

Domestic Hot Water Demand

16:36 DOMESTIC HOT WATER Trial For Ignition	Domestic Hot Water (DHW) Trial for Ignition: Depending on the DHW mode, either a contact closure between terminals #5 and #6 or a drop in DHW temperature triggers a call for domestic hot water. Similarly to the CH demand, the display shows that the heat demand is for domestic hot water and that a trial for ignition has been initiated. The ignition cycle is shown in Table 8.5.
16:36 DOMESTIC HOT WATER 100%Input 160°F	Domestic Hot Water (DHW) Demand: When the burner is on, the display continues to shows the DHW demand. On the lower left, the percentage of modulation is shown. This screen also shows the time, in 24 hour format, and the actual supply temperature as read by the supply sensor.

Supply at Setpoint

16:36 SUPPLY AT SETPOINT Fan Post Purge	Supply at Setpoint - Fan Post Purge: If the boiler supply temperature exceeds the desired target (either a setpoint or a target calculated by the heating curve) the display will indicate "SUPPLY AT SETPOINT" and show that the
16:36 SUPPLY AT SETPOINT Circulator ON	boiler has entered the post purge period. After the postpurge, the display will indicate that the boiler circulator (CH PUMP) is operating. The boiler circulator will continue to operate until the demand is satisfied.

Special Demand Functions

-	
16:36 CENTRAL HEATING Freeze Protection 1%Input 160°F	<u>Freeze Protection</u> : If the supply or return temperature drops below the freeze protection setpoint the general pump and/or the CH pump are activated depending on pump mode. If the temperature continues to drop by more than $9^{\circ}F$ ($5^{\circ}C$) the burner fires at minimum power and continues until the return temperature increases by $18^{\circ}F$ ($10^{\circ}C$).
16:36 DOMESTIC HOT WATER Store Warm Hold 1%Input 160°F	Store Warm Hold: When using a DHW tank sensor, the PureFire boiler control can detect if the DHW heat demand is required only to overcome the heat loss and not a result of a hot water draw. In this instance, the burner will fire at low power (1%) and continue until the tank setpoint is satisfied.
Ignition/Flame I	Failure Handling
16:36 NO IGNITION	Ignition Failure: If control does not sense a flame at the end of the ignition period, the display will show "No

16:36 NO IGNITION Fan Post Purge	Ignition Failure: If control does not sense a flame at the end of the ignition period, the display will show "No Ignition" and the control will advance to the "Post Purge" period. The control will then repeat the Ignition Cycle. If there are three successive ignition failures, the control will lock out.
16:36 FLAME FAILURE Fan Post Purge	Flame Failure: If the control senses a flame at the beginning of the "Burner On" period and then later loses the signal, a Flame Failure will result. This failure causes the control to advance to the "Post Purge" period. The control will then repeat the Ignition Cycle. If there are three successive flame failures the control will lock out.
16:36 CENTRAL HEATING Ignition Retry 16:36 DOMESTIC HOT WATER Ignition Retry	Ignition Retry: If the control recycles due to Ignition or Flame Failure, "Ignition Retry" will be shown below the text indicating the source of the heat demand.

Error Handling

r	0
16:36 BLOCKING ERROR Fan Post Purge 16:36 BLOCKING ERROR #	Blocking Error: "Blocking Error" is displayed whenever a condition is reached that prevents the boiler from operating but will not result in a control lockout. Once the condition is corrected, the control will reset automatically. A list of blocking errors is included in Table 10.1.
16:36	Lockout Error: "Lockout Error" is displayed
LOCKOUT ERROR Fan Post Purge	whenever a condition is reached that results in a control lockout. After the condition is corrected, the control requires the reset button to be pushed in
16:36 LOCKOUT ERROR #	order to resume operation. A list of lockout errors is included in Table 10.2.
Service N	lotification
SERVICE 16:36 STANDBY 160°F	Service Indicator: Predetermined service intervals can be programmed into the control to prompt end users to call for routine service. This interval can be set to "TIME", "HRS" or "CYCLES" in the Installer Menu.
Cascade (Mu	Iltiple Boilers)
16:36 CASCADE STANDBY 0 Boilers ON 160°F	Status Display Screen (Master Cascade Boiler): The Master Boiler in a multiple boiler Cascade System will display the status information for the system as default. "CASCADE STANDBY" appears on the screen instead of "STANDBY" and the number of boilers currently operating will show on the bottom line. The System Supply Temperature is shown in the lower right corner of the display. Pressing the ∩ or ♥ key shows information for the individual boiler.
16:36 STANDBY 160°F	Status Display Screen (Dependent Cascade Boiler): Dependent boilers in a multiple boiler Cascade System will display only the status information for the individual boiler. This information for the Master Boiler can be displayed by pressing the \mathbf{O} or \mathbf{O} key.

Cascade (Multiple Boilers) continued

CALL 6 Boi	0 R H E A T e r s 0 N 1 4 0 ° F DHW demand. The number of boilers currently running	al ı
DOMES	1 6 : 3 6 shown at the bottom of the screen in addition to the cu	-
1 Boi	er ON 140°F	
CALL 75%I	O RH E A TP U T1 4 0 ° FCall For Heat (Dependent Cascade Boiler): boilers will show only "CALL FOR HEAT" if a demand given from the Master boiler. The input percentage of modulation and the supply temperature for the individu boiler are shown at the bottom of the screen.	is
CALL LOCKO 1 Boi	ORHEATTALARMBI01erON140°FJJJJSFJJJImage: A construction of the second s	em OUT
LOCKO	T A L A R M 1 6 : 3 6 Lockout Alarm: "Lockout Alarm" is displayed on any boiler that has reached a condition that results in a control lockout. Pressing the reset key on the individual boiler will reset the Lockout error. A list of lockout errors is included in Table 10.2.	

APPENDIX B. USER MENU

User Menu

MENU →Status Settings Messages	The user menu is accessed by pressing the "Menu" key. Use the up/down arrow keys to identify the desired option. Then press the "Select" key to choose that option.
Sta	tus
STATUS Current Supply Setpoint 160°F▼	STATUS System 160°F Vent 130°F Outdoor 160°F ▼
STATUS ▲ Supply 160°F Return 130°F DHW 160°F	STATUS General Circ. Off CH Circulator Off DHW Circulator Off
Sett	ings
SETTINGS Central Heating Setpoint OD RESET 129°F ▼	Range:50 °Fto185 °FDefault:160 °F10 °Cto85 °C71.1 °CDisplays OD Reset if the CH setpoint is controlled by a heating curve
SETTINGS ▲ DHW Boiler Setpoint 180°F ▼	Range:122 °Fto185 °FDefault:180 °F50 °Cto85 °C82.2 °CControls boiler supply setpoint for DHW call for heat.This screen is only visible in DHW mode 1 & 2.
SETTINGS ▲ DHW Tank Setpoint 140°F ▼	Range:50 °Fto158 °FDefault:120 °F10 °Cto70 °C48.9 °CControls DHW tank setpoint.This screen is only visiblein DHW mode 1.
SETTINGS Time & Date Monday 10 May 2008 16:02▼	
SETTINGS ▲ Temperature Units Fahrenheit °F ▼	Range: °F or °C Default: °F
Mess	ages
MESSAGES 01▲ lockout XXX XXXMIN error description error description ▼	This option displays the last Block Message and the last Lock Message.

APPENDIX C. INSTALLER MENU

V

																	Ins
1	Ν	S	Т	Α	L	L	Е	R		Μ	Ε	Ν	U				
\rightarrow	S	t	а	t	u												
	В	0				r							n	g			
	С	Η		S	е	t	t	i	n	g	s						
1	Ν	S	Т	Α	L	L	Е	R		Μ	Ε	Ν	U				
	D	Н	W		S		t	t		n	g	s					
	S		r	v		С			Ν	0	t		f				
≯	S	у	S	t	е	m		Т	е	S	t						$\mathbf{\nabla}$
1	Ν	S	Т	Α	L	L	Е	R		Μ	Ε	Ν	U				
	S	у		t		m		Т			t	s					
	С	а	s	С	а	d			S		t	t		n	g	s	
⇒	D	е	f	а	u		t										

Installer Menu

To access the Installer Menu, press and hold the "Menu" and "Select" keys simultaneously for 10 seconds. The first screen shown to the left of this text will appear. Press the up/down arrow keys to identify the desired menu option. The $\mathbf{\nabla}$ or $\mathbf{\Delta}$ symbol on the right of the screen indicates that more menu choices can be accessed by continuing to press the down or up arrow respectively. Pressing the "Select" key chooses the option.

Status

Screen #1 shows the current supply setpoint temperature. This value will change for a DHW demand or a CH demand. In addition, when outdoor reset modes are selected, this value is calculated based on the outdoor sensor reading.

Screens #2 & #3 display fan speed information. Current fan speed will vary during operation, while Low Power, Ignition, and High Power fan speeds are preset at the factory for a particular model size. Table 12.2 in Section 12 of this manual shows the fan speed presets for each model size.

Screen #4 shows the Flame Signal and the total number of Flame Failures that have occurred on the unit. Note that the refresh rate of the Flame Signal may be several seconds.

Screens #5 & #6 show the flame signal values during the last 2 seconds of the previous ignition sequence. These values are logged in 1/2 second intervals to allow service personnel to troubleshoot ignition issues.

Screen #7 displays the total number of successful and unsuccessful ignition attempts that have occurred on the boiler.

The total boiler run time for central heating (CH) and domestic hot water (DHW) are recorded on screen #8.

	_				-				$\mathbf{\nabla}$				$\mathbf{\nabla}$			_				$\mathbf{\nabla}$				▼				V	
1	F		2	M	M M	3	3	М	M	4		Α	0	5		A	A	6	Α	A	7		0	1	8		R	R	
				Р	P	-		Р	Р			u				u	u		u	u			0				Н	Н	
	0	0		Р	R R			R	R			6				5	8		2	1		t	2				0	0	
	6	0		•	0 0	-		0	0								,				,	р	1				5 0	0	
	у 1				7	-		5	0			9				2 3	3		6	8		m				m	2 7	7	
					7	-		2	8								_					е							
	р				1			3	4								_					t				Т			
	р					_											_					t	Ì						
	u				r												_					Α	u			n			
	S			d	е	C	d	n	r				s				_						f			u			
	t			e	t w	~~	е	0	e				е			1 2			3	4		n	s			R			
	t n			e	n o	_		i	w				r				_					0	S	d					
	n i	-		р	e P		р	t	0			а	u				•							е		r			
S	e	0	S	S	r	-	s s	i	P	s		n	Т	S		S	s	S		s	S	t	С	I.	S				
U	r	р 	U		r w		U	n		U	m	g	i	U	m	а	a	U	m a	a	U	i	С	i	U			W	
Т	r t		Т	n 	u o		T n	g	i	т	а		а	Т	а		e	T a	e e	e	т	n	u	а	Т		Н	Η	
Α	u e		Α	a C	L		A a	а 	H	A		S	F	Α	l	Μ	M	A I	M	М	A	g	Š	F	Α	0	С	D	
т	C S	_	T F	F		-	T F			т	F			Т	F		-	T F	r.		т	Ľ.			Т	В			
S		_	S			_	S			s				S			_	S			s				S				

Stat	us continued
STATUS #E26 9▲ 2Day Ago BLOCKED CONDENSATE DRAIN ▼	Screens #9 & #10 provide information about blocking errors (errors that do not require a control reset) and locking errors (errors that require a control reset). Each of these screens shows the last error records
STATUS #E26 0 3Hrstoprev.Block BLOCKEDCONDENSATE DRAIN ▼	along with amount of time that has passed since the error occurred. To review the error history press the select key. Section 8 provides more detail about reviewing the error history.
STATUS #A0210▲ 16Hrs Ago	
FLAMEFAILURES▼STATUS#E260	
38Mintoprev.Block FLAME FAILURES ▼	
	lor Sottings
BOILER SETTINGS 1	ler Settings Range: 0 to 3 Default: 0
Pump Mode MODE:0	Reference section 8.C.1 for an explanation of the pump mode function.
CH or CH&DHW PUMP ▼	
BOILER SETTINGS 2▲ Installation Location:	Range:USAorCANDefault:USAProvides location code information to the control for setting the vent limittemperature.Reference section 8.C.2 for further explanation
U S A ▼	
BOILER SETTINGS 3▲ Vent Material:	Range: PVC, CPVC, POLYPROPYLENE Default: PVC Provides vent material information to the control for setting the vent limit temperature. Reference section 8.C.2 for further explanation PVC
PVC BOILER SETTINGS 4▲	Range: 45 °F to 68 °F Default: 50 °F
Freeze Protection starts at: 50°F▼	7 °C to 00 r Default. 50 r 7 °C to 20 °C 10 °C Reference section 8.C.3 for an explanation of the Freeze Protection Function.
BOILER SETTINGS 5▲ Blower Post Purge time 30sec▼	Range:30secto120secDefault:30secAllows installer to increase postpurge time.Reference section 8.C.3 for an explanation of the Blower Post Purge Time Function.
BOILER SETTINGS 6▲ Additional Safety Safety Functionsons LowWaterCO ▼	Range: LowWaterCO or Default: LowWaterCO FlowSwitch Reference Section 8.C.4 for an explanation of the Additional Safety Functions.
BOILER SETTINGS 7	Range: 0-255 or Default: 255
Modbus address 255▼	Reference PFA-1 board IOM supplement for further information.
	al Heating) Settings
CH SETTINGS 1▲ CH Mode:1	Range: 0 to 7 Default: 7 Reference section 8.D.1 for an explanation of the CH Mode Function.
Indoor Thermostat ▼ CH SETTINGS 2▲	Range: 0 min to 60 min Default: 1 min
CH Pump Post Purge Time 1min▼	Reference section 8.D.4 for an explanation of the CH Pump Post Purge Function.
CH SETTINGS 3 🔺	Range: 0 min to 60 min Default: 1 min
General Circulator Post Purge Time 1min▼	Reference section 8.D.4 for an explanation of the GEN Pump Post Purge Function.
CH SETTINGS 4 🔺	Range: On or Off Default: On

Ramp Delay Step Modulation Off▼ Range:OnOrOffDefault:OnSee section 8.D.4 for an explanation of the Ramp Delay Step ModulationFunction.



CH (Central Heating) Settings continued

Servi	ce Notification
SERVICE 1 ▲ Reset Notification Timer/Counters Press Select:Reset ▼ SERVICE 2 ▲ SERVICE 3 ▲	This screen allows the installer to reset the notification timers and counters. As the screen indicates, pressing the "Select" key will reset these values. After the "Select" key is pressed, the screen displays, "Done" in place of "Reset." Range: Off, HRS, CYCLES, DATE Default: Off This screen allows the installer to choose the method of Service Notification or to disable Service Notification. Reference section 8.F for more information. Range: 0 hrs to 8000 hrs Default: 4000 hrs Settable in 100 hr increments
Notification After: XHRS♥ SERVICE 4▲ Notification After: XCYC♥ SERVICE 5▲ Notification on: DD MMM YYYY OFF♥	"SERVICE" will appear in the upper left of the main status screen after the number of hours displayed is exceeded. Range: 0 cyc to 50,000 cyc Default: 20,000 cyc Settable in 1000 cyc increments "SERVICE" will appear in the upper left of the main status screen after the number of cycles displayed is exceeded. 20,000 cyc This screen allows the installer to set the date that the "SERVICE" notification will appear. Using the up/down arrow keys, the Day, Month, and Year can be selected. The date will appear as folows: 01 JAN 2008
S	ystem Test
SYSTEM TEST →Off Low Power Ignition Power ▼ SYSTEM TEST ▲ Low Power Ignition Power →Maximum Power	The System Test mode allows the user to force the control to operate at Low Power, Igntion Power, or Maximum Power for service and troubleshooting purposes. Reference section 8.G for more information on this function.
	ando Sottingo
CASCADE Address Selection Boiler Address: 0▼ CASCADE ▲ Start Delay Time:	cade SettingsRange:0to16Default:0This screen allows the installer to choose the hierarchy of the boiler. The default value (0) indicates no cascade function is applied, (1) = Master and (2-16) = SlaveRange:1minto15minDefault:2minThis screen allows the installer to choose the delay time before the next boiler in the sequence is called for. The
2 min▼ CASCADE Stop Delay Time: 2 min▼ CASCADE	default for this value is 2 minutes.Range:1minto15minDefault:2minThis screen allows the installer to choose the delay time before the last boiler in the sequence is turned off. The default for this value is 2 minutes.The sequence is 2 °FPefault:9 °FRange:1°Fto23 °FDefault:9 °F
Start Boiler Diff: <u>9°F▼</u> CASCADE ▲ Stop Boiler Diff: 18°F▼	This screen allows the installer to choose the temperature differential that starts another boiler in the sequence after the selected delay time.
CASCADE ▲ Calculated Setpoint Max offset up: 36°F▼	Range: 0 °F to 36 °F Default: 18 °F This is an offset temperature applied to the setpoint of Dependent boilers that the control uses to adjust system response. Higher values increase system response.

Cascade Settings continued				
CASCADE Calculated Setpoint Max offset down:	 Range: 0 °F to 36 °F Default: 9 °F This is an offset temperature applied to the setpoint of Dependent boilers that the control uses to adjust system response. Higher values increase system response. 			
CASCADE Next boiler Start rate:	▲ Range: 40 % to 95 % Default: 50 % This screen allows the installer to choose the input level at which the boilers that are running should be before the next boiler in the sequence will start.			
CASCADE Next boiler Stop rate:	▲ Range: 5 % to 40 % Default: 9 % This screen allows the installer to choose the input level at which the boilers that are running should be before the last boiler in the sequence will stop.			
CASCADE Rotation Interval 2 [Range: 0 Days to 30 Days Default: 5 Days This screen allows the installer to choose the rotation cycle of the lead boiler. When this time limit is reached, the boiler with the lowest run hours will be chosen as lead. Choosing 0 disables rotation. 			

APPENDIX D. COMBUSTION TEST RECORD

Peerless® PureFire® Combustion Test Record

Contact:					
Company Name:					
Address:					
Phone Number:					
Fax Number:					
Email Address:					
Jobsite Data					
Job Name:					
Jobsite Address:					
Boiler Data					
Boiler Model:		Boiler Serial No.:			
Manufacture Date:		Startup Date:			
Gas Pressure					
Static Inlet Gas Pressure	Gas F1	Inlet Gas Pressure			
(in. w.c.) [With Boiler Off]:		Drop After Boiler Startup			
High Fire Outlet Gas		(in. w.c.): Low Fire Outlet Gas			
Pressure (in. w.c.):		Pressure (in. w.c.):			
Combustion Readings					
Flame Signal		Flame Signal			
High Fire (µA):	<u> </u>	Low Fire (µA):			
CO ² High Fire (%):		CO ² Low Fire (%):			
CO High Fire (ppm):		CO Low Fire (ppm):			
Fan Speed High Fire:		Fan Speed Low Fire:			
Excess Air		Excess Air			
High Fire (%):	I	Low Fire (%):			
Exhaust Temperature		Exhaust Temperature			
High Fire (°F):		Low Fire (°F):			
System Information					
Water Pressure:	<u> </u>	Condensate Line Size:			
Vent Length		Vent Diameter:			
(Total Equivalent Feet):					

PEERLESS[®] PureFire[®] Rev 2

Gas Boilers

PF-50 PF-80 PF-110 PF-140 PF-200 PF-210 PF-300 PF-399

Installation, Operation & Maintenance Manual

TO THE INSTALLER:

This manual is the property of the owner and must be affixed near the boiler for future reference.

TO THE OWNER:

This boiler should be inspected annually by a Qualified Service Agency.





CONTROLS





PB HEAT, LLC 131 S. CHURCH STREET • BALLY, PA 19503