

# PEERLESS<sup>®</sup> *PUREFIRE<sup>®</sup>*

## Gas Boilers PFC-460



## Installation, Operation & Maintenance Manual



PeerlessBoilers.com

# TABLE OF CONTENTS

<b>USING THIS MANUAL</b>	<b>1</b>	C. ZONE CIRCULATOR WIRING.....33
A. INSTALLATION SEQUENCE.....1		D. INTERNAL WIRING .....33
B. SPECIAL ATTENTION BOXES.....1		
<b>1. PREINSTALLATION</b>	<b>2</b>	<b>8. BOILER CONTROL: OPERATION</b>
A. GENERAL.....2		<b>35</b>
B. CODES & REGULATIONS.....2		A. CONTROL OVERVIEW.....35
C. ACCESSIBILITY CLEARANCES.....3		B. IGNITION SEQUENCE.....37
D. COMBUSTION & VENTILATION AIR.....3		C. USER MENU.....39
E. PLANNING THE LAYOUTS.....6		D. INSTALLER MENU.....41
		E. DEFAULTS.....52
<b>2. BOILER SET-UP</b>	<b>7</b>	F. MULTIPLE BOILERS.....52
A. GENERAL.....7		
B. WALL MOUNTING.....7		<b>9. START-UP PROCEDURE</b>
C. FLOOR STANDING INSTALLATION.....7		<b>57</b>
		A. GENERAL.....57
<b>3. VENTING &amp; AIR INLET PIPING</b>	<b>8</b>	B. CHECK WATER PIPING.....57
A. GENERAL.....8		C. CHECK GAS PIPING.....57
B. APPROVED MATERIALS.....8		D. CHECK OPERATION.....57
C. EXHAUST VENT/AIR INTAKE PIPE LOCATION.....8		E. LIGHTING & OPERATING PROCEDURES.....59
D. EXHAUST VENT/AIR INTAKE PIPE SIZING.....13		
E. EXHAUST VENT/AIR INTAKE INSTALLATION.....13		<b>10. TROUBLESHOOTING</b>
F. EXHAUST TAPPING FOR VENT SAMPLE.....14		<b>60</b>
G. BOILER REMOVAL FROM COMMON VENTING SYSTEM.....14		A. HARDWARE ERROR - NO COMM MAIN BOARD.....60
		B. BLOCKING ERRORS.....60
<b>4. WATER PIPING AND CONTROLS</b>	<b>16</b>	C. LOCKING ERRORS.....60
A. GENERAL.....16		D. ERROR MESSAGES IN A CASCADE SYSTEM.....60
B. WATER QUALITY.....16		E. WARNING ERRORS.....64
C. OPERATING PARAMETERS.....17		F. DELAYED IGNITION (HARD LIGHT-OFF).....66
D. SYSTEM COMPONENTS.....17		G. BOILER FAILS TO RESPOND TO A CH CALL.....66
E. SYSTEM PIPING.....20		
F. FREEZE PROTECTION.....20		<b>11. MAINTENANCE</b>
G. SPECIAL APPLICATIONS.....26		<b>67</b>
		A. GENERAL (WITH BOILER IN USE).....68
<b>5. FUEL PIPING</b>	<b>27</b>	B. WEEKLY (WITH BOILER IN USE).....68
A. GENERAL.....27		C. ANNUALLY (BEFORE START OF HEATING SEASON).....68
B. FUEL LINE SIZING.....27		D. CONDENSATE CLEANING INSTRUCTIONS.....68
C. GAS SUPPLY PIPING – INSTALLATION.....27		E. INSPECTION AND CLEANING OF COMBUSTION CHAMBER COILS.....69
D. GAS SUPPLY PIPING – OPERATION.....28		
E. MAIN GAS VALVE – OPERATION.....29		<b>12. BOILER DIMENSIONS &amp; RATINGS</b>
		<b>70</b>
<b>6. CONDENSATE DRAIN PIPING</b>	<b>30</b>	<b>13. REPAIR PARTS</b>
A. GENERAL.....30		<b>72</b>
B. CONDENSATE SYSTEM.....30		<b>APPENDIX A. STATUS SCREENS</b>
C. CONDENSATE DRAIN PIPE MATERIAL.....31		<b>77</b>
D. CONDENSATE DRAIN PIPE SIZING.....31		<b>APPENDIX B. USER MENU</b>
E. CONDENSATE DRAIN PIPE INSTALLATION.....31		<b>81</b>
		<b>APPENDIX C. INSTALLER MENU</b>
<b>7. ELECTRICAL CONNECTIONS</b>	<b>32</b>	<b>82</b>
A. GENERAL.....32		<b>APPENDIX D. COMBUSTION TEST RECORD</b>
B. CUSTOMER CONNECTIONS.....32		<b>87</b>

# USING THIS MANUAL

## A. INSTALLATION SEQUENCE

Follow the installation instructions provided in this manual in the order shown. The order of these instructions has been set in order to provide the installer with a logical sequence of steps that will minimize potential interferences and maximize safety during boiler installation.

## B. SPECIAL ATTENTION BOXES

Throughout this manual special attention boxes are provided to supplement the instructions and make special notice of potential hazards. The definition of each of these categories, in the judgement of PB Heat, LLC are as follows:

### **DANGER**

Indicates a hazardous situation, which, if not avoided, will result in death or serious injury and major property damage.

### **WARNING**

Indicates a hazardous situation, which, if not avoided, could result in death or serious injury and major property damage.

### **CAUTION**

Indicates a hazardous situation, which, if not avoided, could result in minor or moderate injury, and minor property damage.

### **NOTICE**

Indicates special attention is needed, not related to personal injury or property damage.

# 1. PREINSTALLATION

## A. GENERAL

1. *PUREFIRE*® boilers are supplied completely assembled as packaged boilers. The package should be inspected for damage upon receipt and any damage to the unit should be reported to the shipping company and wholesaler. This boiler should be stored in a clean, dry area.
2. Carefully read these instructions and be sure to understand the function of all connections prior to beginning installation. Contact your PB Heat, LLC Representative for help in answering questions.
3. This boiler must be installed by a qualified contractor. The boiler warranty may be voided if the boiler is not installed correctly.
4. A hot water boiler installed above radiation or as required by the Authority having jurisdiction, must be provided with a low water fuel cut-off device either as part of the boiler or at the time of installation.

## B. CODES & REGULATIONS

1. Installation and repairs are to be performed in strict accordance with the requirements of state and local regulating agencies and codes dealing with boiler and gas appliance installation.
2. In the absence of local requirements the following should be followed:
  - a. ASME Boiler and Pressure Vessel Code, Section IV - "Heating Boilers"
  - b. ASME Boiler and Pressure Vessel Code, Section VI - "Recommended Rules for the Care and Operation of Heating Boilers"

### WARNING

**Liquefied Petroleum (LP) Gas or Propane is heavier than air and, in the event of a leak, may collect in low areas such as basements or floor drains. The gas may then ignite resulting in a fire or explosion.**

- c. ANSI Z223.1/NFPA 54 - "National Fuel Gas Code"
  - d. ANSI/NFPA 70 - "National Electrical Code"
  - e. ANSI/NFPA 211 - "Chimneys, Fireplaces, Vents and Solid Fuel Burning Appliances"
3. Where required by the authority having jurisdiction, the installation must conform to the Standard for Controls and Safety Devices for Automatically Fired Boilers, ANSI/ASME CSD-1.

#### **\*\*Please read if installing in Massachusetts\*\***

Massachusetts requires manufacturers of Side Wall Vented boilers to provide the following information from the Massachusetts code:

- A hard wired carbon monoxide detector with an alarm and battery back-up must be installed

on the floor level where the gas equipment is to be installed AND on each additional level of the dwelling, building or structure served by the side wall horizontal vented gas fueled equipment.

- In the event that the side wall horizontally vented gas fueled equipment is installed in a crawl space or an attic, the hard wired carbon monoxide detector with alarm and battery back-up may be installed on the next adjacent floor level.
- Detector(s) must be installed by qualified licensed professionals.
- APPROVED CARBON MONOXIDE DETECTORS: Each carbon monoxide detector shall comply with NFPA 720 and be ANSI/UL 2034 listed and IAS certified.
- SIGNAGE: A metal or plastic identification plate shall be permanently mounted to the exterior of the building at a minimum height of eight (8) feet above grade directly in line with the exhaust vent terminal for the horizontally vented gas fueled heating appliance or equipment. The sign shall read, in print size no less than one-half (1/2) inch in size, **"GAS VENT DIRECTLY BELOW. KEEP CLEAR OF ALL OBSTRUCTIONS"**.
- EXEMPTIONS to the requirements listed above:
  - The above requirements do not apply if the exhaust vent termination is seven (7) feet or more above finished grade in the area of the venting, including but not limited to decks and porches.
  - The above requirements do not apply to a boiler installed in a room or structure separate from the dwelling, building or structure used in whole or in part for residential purposes.
- This boiler installation manual shall remain with the boiler at the completion of the installation.

See the latest edition of Massachusetts Code 248 CMR for complete verbiage and also for additional (non-vent related) requirements (248 CMR is available online).

If your installation is NOT in Massachusetts, please see your authority of jurisdiction for requirements that may be in effect in your area. In the absence of such requirements, follow the *National Fuel Gas Code*, ANSI Z223.1/NFPA 54 and/or CAN/CSA B149.1, *Natural Gas and Propane Installation Code*.

## NOTICE

**The installer must verify that at least one carbon monoxide alarm has been installed within a residential living space or home following the alarm manufacturer's instructions and applicable local codes before putting the appliance into operation.**

**L'installateur est tenu de vérifier qu'au moins une alarme de détection de monoxyde de carbone soit installée dans un espace résidentiel ou dans un domicile conformément aux directives du fabricant de l'alarme et aux codes locaux applicables avant de mettre l'appareil en service.**



### C. ACCESSIBILITY CLEARANCES

1. The *PUREFIRE*® boiler is certified for closet installations with zero clearance to combustible construction. In addition, it is design certified for use on combustible floors. Do not install on carpeting.

### DANGER

**DO NOT INSTALL ON CARPETING.**

2. Figure 1.1 shows the minimum recommended clearances to allow reasonable access to the boiler. However, local codes or special conditions may require greater clearances.

### D. COMBUSTION AND VENTILATION AIR

1. The *PUREFIRE*® boiler is designed for operation with combustion air piped directly to the boiler from outside the building (sealed combustion). Combustion air may be supplied from within the building only if adequate combustion air and ventilation air is provided in accordance with the National Fuel Gas Code or applicable sections of the local building code. Subsections 3 through 10 as follows are based on the National Fuel Gas Code requirements.
2. If the combustion air is piped directly to the boiler from outside the building, no additional combustion or ventilation air is required. Otherwise, follow the *National Fuel Gas Code* recommendations summarized in subsections 3 through 10.

3. **Required Combustion Air Volume:** The total required volume of indoor air is to be the sum of the required volumes for all appliances located within the space. Rooms communicating directly with the space in which the appliances are installed and through combustion air openings sized as indicated in Subsection 3 are considered part of the required volume. The required volume of indoor air is to be determined by one of two methods.
  - a. **Standard Method:** The minimum required volume of indoor air (room volume) shall be 50 cubic feet per 1000 BTU/Hr (4.8 m<sup>3</sup>/kW). This method is to be used if the air infiltration rate is unknown or if the rate of air infiltration is known to be greater than 0.6 air changes per hour. As an option, this method may be used if the air infiltration rate is known to be between 0.6 and 0.4 air changes per hour. If the air infiltration rate is known to be below 0.4 then the *Known Air Infiltration Rate Method* must be used. If the building in which this appliance is to be installed is unusually tight, PB Heat, LLC recommends that the air infiltration rate be determined.
  - b. **Known Air Infiltration Rate Method:**

$$\text{Required Volume}_{fan} = \frac{15 \text{ ft}^3}{\text{ACH}} \left( \frac{I_{fan}}{1000^{\text{Btu/hr}}} \right)$$

where:

$I_{fan}$  = Input of the fan assisted appliances in Btu/hr

ACH = air change per hour (percent of the volume of the space exchanged per hour, expressed as a decimal)

Note: These calculations are not to be used for infiltration rates greater than 0.60 ACH.






Figure 1.1: Minimum Accessibility Clearances – PFC-460


4. **Indoor Air Opening Size and Location:** Openings connecting indoor spaces shall be sized and located as follows:

- a. **Combining Spaces on the Same Floor:** Provide two permanent openings communicating with additional spaces that have a minimum free area of 1 in<sup>2</sup> per 1000 Btu/hr (22 cm<sup>2</sup> per 1000 W) of the total input rating of all gas fired equipment but not less than 100 in<sup>2</sup> (645 cm<sup>2</sup>). One opening is to begin within 12 inches (305 mm) from the top of the space and the other is to begin within 12 inches (305 mm) from the floor. The minimum dimension of either of these openings shall be 3 inches (76 mm). See Figure 1.2 for an illustration of this arrangement.



**Figure 1.2: Air Openings – All Air from Indoors on the Same Floor**


- b. **Combining Spaces on Different Floors:** Provide one or more permanent openings communicating with additional spaces that have a total minimum free area of 2 in<sup>2</sup> per 1000 Btu/hr (44 cm<sup>2</sup> per 1000 W) of total input rating of all equipment. See Figure 1.3 for an illustration of this arrangement.




**Figure 1.3: Air Openings – All Air from Indoors on Different Floors**

5. **Outdoor Combustion Air:** Outdoor combustion air is to be provided through one or two permanent openings. The minimum dimension of these air openings is 3 inches (76 mm).

- a. **Two Permanent Opening Method:** Provide two permanent openings. One opening is to begin within 12 inches (305 mm) of the top of the space and the other is to begin within 12 inches (305 mm) of the floor. The openings are to communicate directly or by ducts with the outdoors or with spaces that freely communicate with the outdoors. The size of the openings shall be determined as follows:
  - i. Where communicating directly or through vertical ducts with the outdoors each opening shall have a minimum free area of 1 in<sup>2</sup> per 4000 Btu/hr (22 cm<sup>2</sup> per 4000 W) of total input rating for all equipment in the space. See Figure 1.4 for openings directly communicating with the outdoors or Figure 1.5 for openings connected by ducts to the outdoors.




**Figure 1.4: Air Openings – All Air Directly from Outdoors**




**Figure 1.5: Air Openings – All Air from Outdoors through Vertical Ducts**

- ii. Where communicating with the outdoors through horizontal ducts, each opening shall have a minimum free area of 1 in<sup>2</sup> per 2000 Btu/hr (22 cm<sup>2</sup> per 2000 W) of total rated input for all appliances in the space. See Figure 1.6.



**Figure 1.6: Air Openings – All Air from Outdoors through Horizontal Ducts**

- b. *One Permanent Opening Method:* Provide one permanent opening beginning within 12 inches (305 mm) of the top of the space. The opening shall communicate directly with the outdoors, communicate through a vertical or horizontal duct, or communicate with a space that freely communicates with the outdoors. The opening shall have a minimum free area of 1 in<sup>2</sup> per 3000 Btu/hr of total rated input for all appliances in the space and not less than the sum of the cross-sectional areas of all vent connectors in the space. The gas-fired equipment shall have clearances of at least 1 inch (25 mm) from the sides and back and 6 inches (150 mm) from the front of the appliance. See Figure 1.7 for this arrangement.



**Figure 1.7: Air Openings – All Air from Outdoors through One Opening**

6. *Combination Indoor and Outdoor Combustion Air:* If the required volume of indoor air exceeds the available indoor air volume, outdoor air openings or ducts may be used to supplement the available indoor air provided:
- The size and location of the indoor openings comply with Subsection 3.
  - The outdoor openings are to be located in accordance with Subsection 4.
  - The size of the outdoor openings are to be sized as follows:

$$A_{req} = A_{full} \times \left( 1 - \frac{V_{avail}}{V_{req}} \right)$$

where:

$A_{req}$  = minimum area of outdoor openings.  
 $A_{full}$  = full size of outdoor openings calculated in accordance with Subsection 4.  
 $V_{avail}$  = available indoor air volume  
 $V_{req}$  = required indoor air volume

7. *Engineered Installations:* Engineered combustion air installations shall provide an adequate supply of combustion, ventilation, and dilution air and shall be approved by the authority having jurisdiction.
8. *Mechanical Combustion Air Supply:*
- In installations where all combustion air is provided by a mechanical air supply system, the combustion air shall be supplied from the outdoors at the minimum rate of 0.35 ft<sup>3</sup>/min per 1000 Btu/hr (0.034 m<sup>3</sup>/min per 1000 W) of the total rated input of all appliances in the space.
  - In installations where exhaust fans are installed, additional air shall be provided to replace the exhaust air.
  - Each of the appliances served shall be interlocked to the mechanical air supply to prevent main burner operation when the mechanical air supply system is not in operation.
  - In buildings where the combustion air is provided by the mechanical ventilation system, the system shall provide the specified combustion air rate in addition to the required ventilation air.
9. *Louvers & Grills:*
- The required size of openings for combustion, ventilation, and dilution air shall be based on the net free area of each opening.
    - Where the free area through a louver or grille is known, it shall be used in calculating the opening size required to provide the free area specified.
    - Where the free area through a louver or grille is not known, it shall be assumed that wooden louvers will have 25% free area and metal louvers and grilles will have 75% free area.
    - Non-motorized dampers shall be fixed in the open position.

- b. Motorized dampers shall be interlocked with the equipment so that they are proven in the full open position prior to ignition and during operation of the main burner.
    - i. The interlock shall prevent the main burner from igniting if the damper fails to open during burner startup.
    - ii. The interlock shall shut down the burner if the damper closes during burner operation.
10. *Combustion Air Ducts:*
- a. Ducts shall be constructed of galvanized steel or an equivalent corrosion- resistant material.
  - b. Ducts shall terminate in an unobstructed space, allowing free movement of combustion air to the appliances.
  - c. Ducts shall serve a single space.
  - d. Ducts shall not serve both upper and lower combustion air openings where both such openings are used. The separation between ducts serving upper and lower combustion air openings shall be maintained to the source of combustion air.
  - e. Ducts shall not be screened where terminating in an attic space.
  - f. Horizontal upper combustion air ducts shall not slope downward toward the source of the combustion air.
  - g. Combustion air intake openings located on the exterior of buildings shall have the lowest side of the combustion air intake opening at least 12 inches (305 mm) above grade.
11. Refer to Section 3 of this manual, Venting & Air Inlet Piping, for specific instructions for piping the exhaust and combustion air.

## E. PLANNING THE LAYOUTS

1. Prepare sketches and notes showing the layout of the boiler installation to minimize the possibility of interferences with new or existing equipment, piping, venting and wiring.
2. The following sections of this manual should be reviewed for consideration of limitations with respect to:
  - a. Venting and Air Inlet Piping: Section 3
  - b. Water Piping: Section 4
  - c. Fuel Piping: Section 5
  - d. Condensate Removal: Section 6
  - e. Electrical Connections: Section 7
  - f. Boiler Control: Section 8
  - g. Boiler Dimensions and Ratings: Section 12

### **WARNING**

**This boiler is certified as an indoor appliance. Do not install this boiler outdoors or locate where it will be exposed to freezing temperatures.**

### **WARNING**

**Do not install this boiler where gasoline or other flammable liquids or vapors are stored or are in use.**

### **WARNING**

**Do not install this boiler in the attic.**

## 2. BOILER SET-UP

### A. GENERAL

1. *PUREFIRE*<sup>®</sup> boilers are intended for installation in an area with a floor drain or in a suitable drain pan. Do not install any boiler where leaks or relief valve discharge will cause property damage.
2. The *PUREFIRE*<sup>®</sup> boiler is not intended to support external piping. All venting and other piping should be supported independently of the boiler.
3. Install the boiler level to prevent condensate from backing up inside the boiler.



### CAUTION

**This boiler must be installed level to prevent condensate from backing up inside the boiler.**

4. *PUREFIRE*<sup>®</sup> boilers can be wall mounted or floor standing. The following instructions provide guidance for both configurations.

### B. WALL MOUNTING

The PFC-460 boiler can be wall mounted by using the optional stand (91400).

1. Use the leveling feet provide with the boiler to assure proper level.
2. Be sure to leave adequate provisions for condensate piping and/or a pump (if required).

### C. FLOOR STANDING INSTALLATION

1. For floor standing installations, use the leveling feet to assure that the boiler is completely level. This will prevent condensate from backing up in the boiler.
2. Be sure to leave adequate space for condensate piping or a pump if required.

### 3. VENTING & AIR INLET PIPING

#### A. GENERAL

1. Install the *PUREFIRE*® boiler venting system in accordance with these instructions and with the National Fuel Gas Code, ANSI Z223.1/NFPA 54, CAN/CGA B149, and/or applicable provisions of local building codes.
2. The *PUREFIRE*® boiler is a direct vent appliance and is ETL Listed as a Category IV appliance with Intertek Testing Laboratories, Inc.
3. Sources of combustion air contaminated with chlorine, ammonia or alkali agents must be avoided. Do not install this boiler near a swimming pool, hot tubs or laundry. Do not store chemicals near the boiler.

#### WARNING

The venting system for this product is to be installed in strict accordance with these venting instructions. Failure to install the vent system properly may result in severe personal injury, death or major property damage.

#### WARNING

This vent system operates under positive pressure. Vent connectors serving appliances vented by natural draft shall not be connected into any portion of this venting system. Failure to comply may result in serious injury, death or major property damage.

#### B. APPROVED MATERIALS

1. Table 3.1 lists approved materials for vent pipe (and adhesives where applicable). Use only these materials for exhaust vent piping.
2. PVC pipe and fittings are not to be used for venting in confined spaces such as closet installations. Use only CPVC or polypropylene (InnoFlue or PolyPro) vent pipe under these conditions.

#### WARNING

Only the materials listed below are approved for use with the *PUREFIRE*® boiler. Use only these components in accordance with these instructions. Failure to use the correct material may result in serious injury, death, or major property damage.

3. Cellular core piping is approved for inlet air piping only.

Table 3.1: Approved Materials for Exhaust Vent Pipe

Description	Material	Conforming to Standard
Vent Piping & Fittings	PVC (Sch 40 or 80)*	ANSI/ASTM D1785
	CPVC (Sch 40 or 80)	ANSI/ASTM F441
	PVC-DWV*	ANSI/ASTM D2665
	FasNSeal®	UL1738 & ULC-S636
	PolyPro®	ULC-S636
	InnoFlue®	ULC-S636
Pipe Cement (PVC & CPVC Only)	Z-DENS®	ULC S636
	PVC/CPVC Cement	ANSI/ASTM D2564

\* PVC pipe/fittings are not to be used for venting within confined spaces.

Notice: Installations in Canada require compliance with ULC S636 - Standard for Type BH Gas Venting Systems.

#### WARNING

Use of cellular core PVC (ASTM F891), cellular core CPVC, or Radel® (polyphenolsulphone) for exhaust vent is prohibited. Use of these materials as exhaust vent may result in severe personal injury, death, or major property damage.

#### C. EXHAUST VENT/AIR INTAKE PIPE LOCATION


1. Install vent piping before installing water, fuel, or condensate piping. Working from largest to smallest diameter reduces the complexity of piping interferences.
2. Vent and air intake piping is to be installed so that there is sufficient access for routine inspection as required in Section 11, of this manual.
3. The vent piping for this boiler is approved for zero clearance to combustible construction. However, a fire stop must be used where the vent pipe penetrates walls or ceilings.
4. The Peerless® *PUREFIRE*® boiler, like all high efficiency, gas-fired appliances, is likely to produce a vapor plume due to condensation. Surfaces near the vent termination will likely become coated with condensation.
5. The maximum combined vent and air inlet vent length for the Peerless® *PUREFIRE*® boiler is about 200 equivalent feet (60 m). Be sure that the boiler is located such that the maximum vent length is not exceeded.

#### NOTICE

If the maximum equivalent vent length is exceeded, the maximum burner input rate may be reduced.

6. Air Intake Pipe Location – Sidewall Venting:

- Provide 1 foot (30 cm) clearance from the bottom of the air intake pipe to the level of maximum snow accumulation. Snow removal may be necessary to maintain clearances.
- Do not locate air intake pipe in a parking area where machinery may damage the pipe.
- Maintain a minimum of 8" horizontal distance between exhaust vent and the air intake. Increasing this distance minimizes the potential for contamination of the inlet air with exhaust.
- For multiple boiler installations, the minimum horizontal distance between the inlet of one boiler to the exhaust of an adjacent boiler is 8" center-to-center. In addition, the minimum vertical distance between the exhaust and air inlet is 6". See Figure 3.1 for an illustration.



**Figure 3.1: Vent Pipe Spacing for Multiple PUREFIRE® Boilers**

- The exhaust outlet of the vent pipe should not be angled any more than 5° from horizontal.
- Precautions should be taken to prevent recirculation of flue gases to the air inlet pipe of the boiler or other adjacent appliances.


7. Sidewall Venting Configuration:

- See Figure 3.2 for an illustration of clearances for location of exit terminals of direct-vent venting systems.
  - This boiler vent system shall terminate at least 3 feet (0.9 m) above any forced air inlet located within 10 ft (3 m). Note: This does not apply to the combustion air intake of a direct-vent appliance.
  - Provide a minimum of 1 foot (30 cm) distance from any door, operable window, or gravity intake into any building.
  - Provide a minimum of 1 foot (30 cm) clearance from the bottom of the exit terminal above the expected snow accumulation level. Snow removal may be required to maintain clearance.
  - Provide a minimum of 4 feet (1.22 m) horizontal clearance from electrical meters, gas meters, gas regulators, and relief equipment. In no case shall the exit terminal be above or below the aforementioned equipment unless the 4 foot horizontal distance is maintained.
  - Do not locate the exhaust exit terminal over public walkways where condensate could drip and create a hazard or nuisance.
  - When adjacent to public walkways, locate the exit terminal at least 7 feet above grade.
  - Do not locate the exhaust termination directly under roof overhangs to prevent icicles from forming or recirculation of exhaust gases from occurring.

**CAUTION**


Condensing flue gases can freeze on exterior building surfaces which may cause discoloration and degradation of the surfaces.

- Provide 3 feet clearance from the inside corner of adjacent walls.




**Figure 3.2: Exit Terminal Location for Mechanical Draft and Direct-Vent Venting Systems**


- b. Figures 3.3 through 3.6 show approved sidewall venting configurations using the standard fittings supplied.
- c. Figure 3.4 is only approved for locations in which the outdoor temperature is above -5°F (-21°C) in accordance with ASHRAE 90A-1980 recommendations.
- d. Figure 3.7 shows a sidewall vent configuration using an optional 4" concentric termination kit (544



**Figure 3.3: Standard Exhaust & Air Inlet Pipe Terminations**



**Figure 3.4: Offset Exhaust and Air Inlet Terminations**



**Figure 3.5: Exhaust and Air Inlet on Opposite Walls**






Figure 3.6: Sidewall Exhaust with Indoor Air




Figure 3.7: Optional Concentric Vent Kit Installation

## 8. Vertical Venting Configuration:

- Figure 3.8 shows the approved venting configuration for vertical venting using the standard fittings supplied.






Figure 3.8: Standard Vertical Vent Installation


- Locate the air intake pipe inlet 12" above the expected snow accumulation on the roof surface or 24" above the roof surface, whichever is greater.
- Locate the end of the exhaust vent pipe a minimum of 12" above the inlet to the air intake pipe.
- Figure 3.9 shows an approved vertical vent configuration using the optional concentric vent termination kit.
- Figure 3.10 shows an option for routing the exhaust and air inlet piping through an unused chimney.
- Figure 3.11 shows this option using inlet air from a sidewall position.
- Figure 3.12 shows an option for routing the exhaust through an unused chimney with the combustion air supplied from inside the building. Be sure to note the requirements for combustion air as listed under Section 1.D. "Combustion and Ventilation Air". These requirements are in accordance with the National Fuel Gas Code.




**Figure 3.9: Concentric Vertical Vent Installation**



**Figure 3.11: Venting Through a Chimney Using Sidewall Outside Air**



**Figure 3.10: Venting Through a Chimney Using Outside Air**



**Figure 3.12: Venting with a Chimney Using Inside Air**

## D. EXHAUST VENT/AIR INTAKE PIPE SIZING

- Table 3.2 shows the Exhaust Vent/Air Intake Size for *PUREFIRE*® PFC-460 boilers.

**Table 3.2: Exhaust Vent/Air Intake Sizing**

Boiler Model	Exhaust Vent/Air Intake Size
PFC-460	4" (100 mm)

- Polypropylene vent systems can be installed using optional InnoFlue® or PolyPro® vent adapters. Table 3.3 shows the appropriate PB Heat, LLC stock codes.

**Table 3.3: Polypropylene Vent Adapter Stock Codes**

Boiler Model	Centrotherm InnoFlue®	DuraVent PolyPro®
PFC-460	54633	54631*

\* Use *DuraVent* adapter connector, Part# PPS-PAC, with PB Heat stock codes 54630 and 54631.

Contact your PB Heat, LLC Representative for more information on this option.

- Combined systems using separate polypropylene exhaust & air inlet pipes which transitions to concentric can also be installed. Contact your Centrotherm or DuraVent representative for more information.
- The total combined length of exhaust vent and air intake piping is 200 equivalent feet (60 m).
  - The equivalent length of elbows, tees and other fittings are listed in Table 3.4.

**Table 3.4: Equivalent Length of Fittings**

Fitting Description	Equivalent Length
Elbow, 90° Short Radius	5 feet
Elbow, 90° Long Radius	4 feet
Elbow, 45° Short Radius	3 feet
Coupling	0 feet
Air Intake Tee	0 feet
Stainless Steel Vent Kit	1 foot
Concentric Vent Kit	3 feet

**Table 3.5: Sample Equivalent Length Calculation**

	Exhaust	Air Inlet	Total
Straight Length of Pipe	50'	50'	100'
90° Elbows, SR	2 x 5' = 10'	1 x 5' = 5'	15'
45° Elbows, SR		2 x 3' = 6'	6'
Conc. Vent Termination	1 x 3' = 3'		3'
	Total		124'

## NOTICE

**Exhaust Vent/Air Intake length in excess of 200 equivalent feet may result in reduced input due to excessive pressure drop.**

- The equivalent length can be calculated as follows.

This is well below the 200 feet maximum equivalent length. If the total is above 200 equivalent feet, alternate boiler locations or exhaust penetration location should be considered.

## E. EXHAUST VENT/AIR INTAKE INSTALLATION

### WARNING

**Covering non-metallic exhaust venting material is prohibited and may result in severe personal injury, death, or major property damage.**

- Figures 12.1 & 12.2 show the exhaust connection on top of the boiler, near the rear in the center.
  - The exhaust and air intake connections for PFC-460 boilers are 4" Male CPVC Pipe.
  - These connections are to be joined with suitable PVC/CPVC adhesives in accordance with manufacturers' instructions.
- The Air Intake connection is to the right of the exhaust.
- Both connections are clearly marked.

### WARNING

**This appliance uses a positive pressure venting system. All joints must be sealed completely to prevent leakage of flue products into living spaces. Failure to do this may result in severe personal injury, death or major property damage.**

- Remove all burrs and debris from the joints and fittings.
- Horizontal lengths of exhaust vent must be installed with a slope of not less than 1/4" per foot (21 mm per meter) toward the boiler to allow condensate to drain from the vent pipe. If the vent pipe must be piped around an obstacle that causes a low point in the piping, a drain with an appropriate trap must be installed.
- All piping must be fully supported. Use pipe hangers at a minimum of 4 foot (1.22 meter) intervals to prevent sagging of the pipe.
- Exhaust and air inlet piping is to be supported separately and should not apply force to the boiler.
- Penetration openings around the vent pipe and air intake piping are to be fully sealed to prevent exhaust gases from entering building structures.
- PVC & CPVC Piping:
  - Use only solid PVC or CPVC Schedule 40 or 80 pipe for exhaust venting. Cellular core PVC or CPVC is not approved for exhaust vent.
  - All joints in vent pipe, fittings, attachment to the boiler stub, and all vent termination joints must be properly cleaned, primed and cemented. Use only cement and primer approved for use with PVC or CPVC pipe that conforms to ANSI/ASTM D2564.
  - A straight coupling is provided with the boiler to be used as an outside vent termination. One of the two screens is to be installed to prevent birds or rodents from entering.
  - An air intake tee is provided with the boiler to be used as an outside air intake termination. A screen is to be installed to prevent birds or rodents from entering.

- e. Table 3.6 lists optional concentric air intake/exhaust terminations that are available separately from your PB Heat, LLC distributor for use with *PUREFIRE*® boilers. A 4" CPVC/PVC coupling is required for the PFC-460 boiler when using a concentric vent termination.

**Table 3.6: Concentric Vent Termination Kits**

Boiler Model	Description	Stock Code
PFC-460	Sidewall Vent Termination Kit – PolyPro 4PPS-HK	54499
	Vertical Vent Termination Kit – PolyPro 4PPS-VK	54501

- f. Refer to Figures 3.3 through 3.7 for sidewall venting options using PVC or CPVC pipe.
- g. Refer to Figures 3.8 through 3.12 for vertical venting options using PVC or CPVC pipe.

## F. EXHAUST TAPPING FOR VENT SAMPLE

To properly install the *PUREFIRE*® boiler, carbon dioxide (CO<sub>2</sub>) and carbon monoxide (CO) levels in the exhaust vent must be determined from a sample of combustion products. To do this in PVC or CPVC pipe, a hole must be drilled in the exhaust vent pipe:

- a. Drill a 21/64" diameter hole in the pipe in a position that the combustion analyzer probe can be inserted between 6" and 12" from the boiler connection.
- b. Tap the hole with a 1/8" NPT pipe tap.
- c. Use a 1/8" NPT PVC or Teflon Pipe Plug to seal the hole.

InnoFlue® and PolyPro® vent systems offer test port fittings for obtaining a sample of combustion products. See your Centrotherm or DuraVent Representative for recommendations.

See Section 9.D.7 for instructions on taking combustion readings.

## G. BOILER REMOVAL FROM COMMON VENTING SYSTEM

At the time of removal of an existing boiler, follow these steps with each appliance remaining connected to the common venting system placed in operation, while the other appliances remaining connected to the common venting system are not in operation:

*Retrait de la chaudière d'un système d'évacuation commun. Au moment de retirer une chaudière existante, il est important de suivre les étapes suivantes pour chaque appareil raccordé au système d'évacuation commun qui sont en service, alors que les autres appareils demeurant raccordés au système d'évacuation commun ne sont pas en service :*

1. Seal any unused openings in the common venting system.  
*Sceller toute ouverture du système d'évacuation commun non utilisée.*

2. Visually inspect the venting system for proper size and horizontal pitch and determine there is no blockage or restriction, leakage, corrosion and other deficiencies which could cause an unsafe condition.

*Effectuer un contrôle visuel du système d'évacuation pour vérifier la taille et la pente horizontale et s'assurer qu'il n'existe aucun blocage ou obstruction, fuite, corrosion ni tout autre problème pouvant menacer la sécurité.*

3. Insofar as is practical, close all building doors and windows and all doors between the space in which the appliances remaining connected to the common venting system are located and other spaces of the building.

*Dans la mesure du possible, fermer toutes les portes et fenêtres de l'immeuble ainsi que toutes les portes entre l'espace dans lequel les appareils qui demeurent raccordés au système d'évacuation commun se trouvent et le reste de l'immeuble.*

4. Turn on any clothes dryers and any appliance not connected to common venting system. Turn on any exhaust fans, such as range hoods and bathroom exhausts, so they will operate at maximum speed. Do not operate a summer exhaust fan.

*Mettre en marche les sècheuses et tout autre appareil non raccordé au système d'évacuation commun. Mettre en marche tous les ventilateurs aspirant, tels que les hottes de cuisinière et les ventilateurs de salle de bain, en les faisant fonctionner à vitesse maximum.*

5. Close fireplace dampers.

*Ne pas faire fonctionner les ventilateurs aspirant d'été. Fermer les registres de foyers.*

6. Place in operation the appliance being inspected. Follow the lighting instructions. Adjust thermostat so appliance will operate continuously.

*Mettre en service l'appareil à inspecter. Suivre les instructions concernant l'allumage. Régler le thermostat afin que l'appareil fonctionne sans arrêt.*

7. Test for spillage at the draft hood relief opening after 5 minutes of main burner operation. Use the flame of a match or candle, or smoke from a cigarette, cigar, or pipe.

*Vérifier toute fuite à l'orifice de décharge du coupe-tirage après que le brûleur ait fonctionné pendant 5 minutes. Utiliser la flamme d'une allumette ou d'une chandelle ou encore la fumée d'une cigarette, d'un cigare ou d'une pipe.*

8. After it has been determined that each appliance remaining connected to the common venting system properly vents when tested as outlined above, return doors, windows, exhaust fans, fireplace dampers and any other gas-burning appliance to their previous conditions of use.

*Après avoir établi que les résidus de combustion de chaque appareil qui demeure raccordé au système commun sont adéquatement évacués lorsque soumis au test décrit ci-dessus, remettre en place les portes, fenêtres, portes intérieures, ventilateurs aspirants, registres de foyer et appareils fonctionnant au gaz.*

9. Any improper operation of the common venting system should be corrected so that the installation conforms with the National Fuel Gas Code, ANSI Z223.1/NFPA 54 or CAN/CGA B149 Installation Codes.

*Tout fonctionnement inadéquat du système d'évacuation commun doit être corrigé de manière à respecter les normes du National Fuel Gas Code, ANSI Z223.1/NFPA 54 et/ou des Codes d'installation CAN/ACG B149.*

10. When resizing any portion of the common venting system, the common venting system should be resized to approach minimum size as determined using the appropriate tables located in the chapter "Sizing of Category I Venting Systems," of the National Fuel Gas Code, ANSI Z223.1/NFPA 54 or CAN/CGA B149 Installation codes.

*Lorsqu'il est nécessaire de modifier les dimensions de toute portion du système d'évacuation commun, ces dernières doivent être modifiées de manière à respecter les dimensions minimums indiquées dans les tableaux du chapitre « Sizing of Category I Venting Systems » du National Fuel Gas Code, ANSI Z223.1/NFPA 54 ou des Codes d'installation CAN/ACG B149.*

## 4. WATER PIPING & CONTROLS

### A. GENERAL

1. Size water supply and return piping in accordance with system requirements rather than the boiler connections.
2. If the *PUREFIRE*® boiler is used to replace an existing boiler, make sure the system piping is thoroughly cleaned and free from debris before installing this boiler. Sentinel Performance Solutions (<http://www.sentinel-solutions.net/us/>) offers a full line of cleaners (X300), sludge remover (X400), antifreeze (X500) and corrosion inhibitors (X100/X500) for hydronic applications.
3. In hydronic systems where sediment may exist, install a strainer in the boiler return piping to prevent large particles and pipe scale from entering the boiler heat exchanger. Use a large mesh screen in the strainer.
4. Install this boiler so that the gas ignition system components are protected from water (dripping, spraying, etc.) during operation and service (circulator replacement, condensate trap cleaning, sensor replacement, etc.).

### B. WATER QUALITY

*PUREFIRE*® boilers are intended for use in a closed-loop hydronic system. Make-up fresh water for the system will include oxygen, calcium and other substances which may cause corrosion, calcium scale buildup or other attacks on the hydronic system and boiler components.

The following steps should be taken to maximize the longevity of the boiler and system:

1. Water hardness must be between 3 Grains/Gal (gpg) and 9 Grains/Gal (gpg). Use of a water treatment system may be required on make-up water in areas with hard water.
2. The systems water pH level should fall between 6 pH and 8 pH. The slightly alkaline water will work to prevent corrosion and neutralize any acidic buildup over time minimizing potential sources of corrosive attacks on the heat exchanger.
3. The system should be flushed and cleaned thoroughly with fresh water and a rinsing agent prior to boiler installation. Any new system must be cleaned to remove any flux or welding residue. Any existing system must be cleaned to remove scale and particulate matter prior to boiler connection to the system. Thoroughly flush any cleaning agent from the system with clean water prior to connecting the boiler. See Table 4.1 for recommended cleaning agents.
4. High oxygen levels in the system water will allow scale buildup to occur. Steps must be taken to minimize oxygen levels in the system. The following items are recommended during installation:
  - a. Provide Air Elimination Means: An automatic air vent should be installed at the highest point in the system and at any points air could potentially be trapped. When replacing an existing boiler, ensure any automatic air vents installed in the system are functioning correctly and installed in a proper location. A hydronic separator is another option to provide a low velocity zone for trapped air bubbles to separate and be eliminated from the system while providing primary/secondary operation.
  - b. It is recommended that a water meter be installed on the system fresh water intake to monitor the system for any leaks by monitoring make-up water usage. Untreated fresh water sources will introduce oxygen, minerals and contaminants into system.
  - c. Correct any system leaks prior to placing the boiler in operation.

### WARNING

Failure to properly analyze and treat system water when installing a high efficiency boiler can cause heat exchanger failure due to water passageway fouling. Black oxide sludge (magnetite –  $\text{Fe}_3\text{O}_4$ ), red oxide sludge (iron oxide –  $\text{Fe}_2\text{O}_3$ ), and calcium scale (limescale) will settle over the hottest portion of the heat exchanger coils. This buildup will reduce thermal transfer in the areas where the buildup is greatest resulting in an increased fouling rate. The high temperatures in these locations will compromise the natural corrosion resistance of the stainless steel material leading to accelerated failure of the heat exchanger.

Failure to address the causes of the fouling in the system can void heat exchanger warranty, and risk property damage, personal injury or death.

System must be cleaned before the boiler is connected!

- Flush the system with fresh water
- Use a cleaning agent appropriate for the system material and debris to be removed
- Thoroughly flush cleaning agent residue from the system with fresh water

The following actions must be taken after the boiler is connected to the system:

- Treat system water with a corrosion and scale inhibitor to prevent oxidization and scale buildup. Follow the inhibitor manufacturer's instructions when treating the system water



**Table 4.1: Recommended Water Treatment Products for use in Stainless Steel Condensing Boiler Applications**

	Supplier			
	Fernox	Sentinel	Sotin	ADEY
Universal Cleaner	Restorer F3 or F5	X300	-	-
Sludge Remover	Cleaner F3 or F5	X400	Sotin 212	-
Inhibitors	Protector F1/ Alphi 11	X100, X500	Sotin 212	MC1+
Antifreeze	Alphi 11	X500	-	-

### ⚠ WARNING

Do not use petroleum based cleaners when cleaning the boiler system. Damage to the gaskets found in typical system components can occur resulting in significant property damage.

## C. OPERATING PARAMETERS

1. The *PUREFIRE*® boiler is designed to operate in a closed loop hydronic system under forced circulation. This requires the system to be completely filled with water and requires a minimum water flow through the boiler to operate effectively.
2. The minimum system pressure is 14.5 psig (100 kPa).
3. Table 4.2 lists the minimum flow rates for each *PUREFIRE*® model. If a glycol solution is to be used, contact your PB Heat, LLC representative for minimum flow rates.

**Table 4.2: Minimum Flow Rate**

<i>PUREFIRE</i> ® Model	Minimum Flow Rate	
	Water GPM (LPM)	50% Glycol Solution GPM (LPM)
PFC-460	13.2 (50.0)	16.5 (62.5)

Section 4.E provides detailed information about using glycol for freeze protection.

Table 4.3 provides the water volume of the heat exchanger including the supply and return pipes that are attached at the factory.

**Table 4.3: Heat Exchanger Water Capacity**

<i>PUREFIRE</i> ® Model	Total Water Capacity Gallons (Liters)
PFC-460	2.60 (9.84)

## D. SYSTEM COMPONENTS

Figure 4.1 shows the symbol key for piping diagrams in this section. The following are brief descriptions of system components.

1. *Pressure/Temperature Gauge*: A combination pressure/temperature gauge is provided with each *PUREFIRE*® boiler to be mounted in the piping from the boiler supply to the system as shown in Figure 4.2. Most local codes require this gauge.
2. *Air Elimination*: Closed loop hydronic systems require air elimination devices. As the system water is heated, dissolved oxygen and other gases will separate from the liquid. An air elimination device (such as a TACO Vortech® Air Separator) is required to remove the

dissolved gases preventing corrosion in the piping system and eliminating noise.

3. *Expansion Tank*: An expansion tank (such as a Bell & Gossett Series HFT) is required to provide room for expansion of the heating medium (water or glycol solution). Consult the expansion tank manufacturer's instructions for specific information regarding installation. The expansion tank is to be sized for the required system volume and capacity. In addition, be sure that the expansion tank is sized based on the proper heating medium. Glycol solutions may expand more than water for a similar temperature rise.

### ⚠ CAUTION

Use only inhibited propylene glycol solutions which are specifically formulated for hydronic systems. Unlike automotive antifreeze, solutions for hydronic applications contain corrosion inhibitors that will protect system components from premature failure due to corrosion.


### ⚠ WARNING

Use only inhibited propylene glycol solutions which are specifically formulated for hydronic systems. Ethylene glycol is toxic and may cause an environmental hazard if a leak or spill occurs.

4. *Y-Type Strainer or Filter Ball® Valve*: PB Heat recommends the use of a strainer device in the system to prevent dirt or sediment from clogging the heat exchanger. A 20 mesh stainless steel screen is adequate to protect the heat exchanger. The strainer should be cleaned often in the first several months of operation. The Filter Ball® Valve from Jomar International incorporates a strainer into a ball valve which allows the technician to isolate the water circuit while cleaning the strainer.
5. *Flow Control Valve*: Flow control valves such as the TACO Flo-Chek or Bell & Gossett Flo-Control™ are used to prevent gravity circulation by incorporating a check valve with a weighted disc.
6. *Pressure Reducing Valve*: A pressure reducing valve, such as the Bell & Gossett B-38 or a TACO #329, is used in a hydronic system to automatically feed water to the system whenever pressure in the system drops below the pressure setting of the valve. These valves should not be used on glycol systems unless close supervision of the glycol solution is practiced.
7. *Back Flow Preventer*: A back flow preventer (check valve) is required by some jurisdictions to prevent water in the hydronic system from backing up into the city water supply. This is especially important on systems in which glycol solution is used as the heating medium.
8. *Pressure Relief Valve*: The boiler pressure relief valve is shipped separately for field installation. The valve is to be installed as shown in Figure 4.2.

### ⚠ WARNING

Do not operate this appliance without installing the pressure relief valve supplied with the boiler or one with sufficient relieving capacity in accordance with the ASME Rating Plate on the boiler heat exchanger.



**Figure 4.1: Piping Symbol Key**


Pipe the discharge of the relief valve to within 12" of the floor and close to a floor drain.

## CAUTION

**Pipe the discharge of the relief valve as close as possible to the floor and away from high traffic areas. Pipe the discharge to a floor drain. Failure to do so may result in personal injury and/or property damage.**

Provide piping that is the same size or larger than the relief valve outlet.

9. **Low Water Cut Off:** When installing a probe type LWCO, locate the LWCO in the boiler supply above the top jacket panel. Refer to Section 7. Electrical Connection in this manual for wiring details.
10. **Circulator:** The boiler circulator is to be sized to overcome the pressure drop of the system while providing the flow required by the boiler.
  - a. If the boiler is piped in a secondary loop of a primary/secondary heating system, the circulator will need only to overcome the resistance of the boiler and any fittings in that loop.
  - b. The circulator should be sized based on gross output of the boiler. Table 4.4 shows the Boiler Output as reported to the Hydronics Institute Section of AHRI.



**Figure 4.2: Relief Valve Installation – PFC-460**

- c. The required flow is calculated based on the design temperature difference from the return to the supply of the boiler. For a PFC-460 boiler with a design temperature difference of 20°F, the calculation is as follows:



$$\text{Required Flow} = \frac{\text{Output}}{\Delta T \times 500} = \frac{438,000}{20 \times 500} = 43.8 \text{ GPM}$$

**Table 4.4: Boiler Inputs and Outputs**

PUREFIRE® Model	Boiler Input Btu/hr (kW)	Gross Output Btu/hr (kW)
PFC-460	460,000 (134.8)	438,000 (128.8)

- d. The boiler pressure drop for various flow rates can be determined using Figure 4.3, the PUREFIRE® Boiler Circulator Sizing Graph.
- e. Table 4.5 provides the flow rate and pressure drop information that corresponds to various system temperature rise values ( $\Delta T$ ). The pressure drop shown is for the boiler only. If there is significant pressure drop in the system, this should be included when specifying circulators.

**Table 4.5: Flow Rate vs. Pressure Drop for Various Boiler Temperature Rise Values**

$\Delta T$ (°F)	GPM	FT	LPM	m
40	21.9	6.71	82.9	2.05
35	25.0	8.60	94.6	2.62
30	29.2	11.46	110.5	3.49
25	35.0	16.10	132.5	4.91
20	43.8	24.39	165.8	7.43


- f. Table 4.6 provides a list of recommended circulators for boilers on a secondary loop of a primary/secondary system which uses water as a heating medium.
- g. Special consideration must be given if a glycol based anti-freeze solution is used as a heating medium. Propylene glycol has a higher viscosity than water, therefore the system pressure drop will be higher.

## NOTICE

The circulator sizing given is for primary/secondary installations only. The system circulators must be sized based on the flow and pressure drop requirements of the system.

**Table 4.6: PFC-460 Circulator Selection Chart (General Pump – Primary Secondary)**

Circulator Manufacturer	Temp. Difference	Pump Model
Taco	20°F	1915/7.1" 1.5 HP
Grundfos		UPS32-160F Medium Speed
Bell & Gossett		N/A
Wilo		Top S 1.5 x 20 3 – 230V Max
Taco	25°F	2400-65
Grundfos		UPS26-150 SF Hi Speed
Bell & Gossett		N/A
Wilo		Top S 1.5 x 20 3 – 230V Max
Taco	30°F	2400-60
Grundfos		UPS26-150
Bell & Gossett		NRF-45 Speed 3
Wilo		Top S 1.5 x 20 1 – 115V Min
Taco	35°F	0013
Grundfos		UPS26-99 FC Hi Speed
Bell & Gossett		NRF-36 Speed 3
Wilo		Star 17 FX
Taco	40°F	0011
Grundfos		UPS26-99 FC High Speed
Bell & Gossett		NRF-45 Speed 1
Wilo		Star 17 FX



**Figure 4.3: PUREFIRE® Circulator Sizing Graph (General Pump – Primary/Secondary)**

11. *Indirect Water Heater:* An indirect water heater should be piped to a dedicated zone. The *PUREFIRE*® boiler provides electrical terminals for connecting a domestic hot water (DHW) circulator. Examples of piping for the indirect water heater are shown under subsection "D", System Piping of this section.

### E. SYSTEM PIPING

1. Figure 4.4 shows a single boiler with multiple heating zones. In this case, the DHW zone is piped in parallel to the heating zones on the primary loop.
2. For a single boiler with one heating zone and one DHW zone which utilizes an indirect water heater like the Peerless® Partner®, pipe the boiler as shown in Figure 4.5. In systems like this, the DHW circulator must be sized to provide the minimum flow rate through the boiler.
3. In Figure 4.6 an additional boiler is added and more heating zones are shown. Notice that the two boilers are piped in parallel on the secondary loop. This maximizes the efficiency of the boilers since the lowest temperature system water is returning to both boilers.
4. Figure 4.7 shows a multiple boiler system with several different types of heat distribution units. This system illustrates how different temperature zones can be supplied from the same source by blending supply and return water to the zone.
5. In Figure 4.8 zone valves are used instead of zone circulators. Notice that the system is piped using reverse return piping to help balance the flow through the zones. If the zone lengths vary balancing valves are required on each loop.
6. Due to increased flow rate and fluid viscosity, the circulator head requirement will increase. Contact the pump manufacturer to correctly size the circulator for a particular application based on the glycol concentration and heating requirements.
7. A strainer, sediment trap, or some other means for cleaning the piping system must be provided. It should be located in the return line upstream of the boiler and must be cleaned frequently during the initial operation of the system. Glycol is likely to remove mill scale from new pipe in new installations.
8. Glycol solution is expensive and leaks should be avoided. Weld or solder joints should be used where possible and threaded joints should be avoided. Make-up water should not be added to the system automatically when glycol solution is used. Adding make-up water will dilute the system and reduce the ability of the solution to protect from freezing.
9. Check local regulations to see if systems containing glycol solutions must include a back-flow preventer or require that the glycol system be isolated from the water supply.
10. Do not use galvanized pipe in glycol systems.
11. Use water that is low in mineral content and make sure that there are no petroleum products in the solution.
  - a. Less than 50 ppm of calcium
  - b. Less than 50 ppm of magnesium
  - c. Less than 100 ppm (5 grains/gallon) of total hardness
  - d. Less than 25 ppm of chloride
  - e. Less than 25 ppm of sulfate

### F. FREEZE PROTECTION

1. Glycol for hydronic applications is specially formulated for heating systems. It includes inhibitors which prevent the glycol from attacking metallic system components. Make sure that the system fluid is checked for correct glycol concentration and inhibitor level.
2. Use only inhibited polypropylene glycol solutions of up to 50% by volume. Ethylene glycol is toxic and can chemically attack gaskets and seals used in hydronic system.
3. The anti-freeze solution should be tested at least once per year and as recommended by the manufacturer of the product.
4. Anti-freeze solutions expand more than water. For example, a 50% by volume solution expands 4.8% with a 148°F temperature rise while water expands about 3% for the same temperature increase. Allowance for this expansion must be considered in sizing expansion tanks and related components.
5. The flow rate in systems utilizing glycol solutions should be higher than in a water system to compensate for decreased heating capacity of the fluid.
12. Check with the local water supplier for chemical properties of the water.
13. The following test will determine if the water is of the appropriate hardness. Collect a sample of 50% water to 50% propylene glycol. Let the solution stand for 8-12 hours shaking it occasionally. If white sediment forms, the water is too hard and should not be used to dilute the glycol.
14. Mix the solution at room temperature.
15. Do not use a chromate treatment.
16. Refer to Technical Topics #2a published by the Hydronics Institute for further glycol system considerations.





Figure 4.4: Recommended Piping – One Boiler, Primary/Secondary with Two Zones (Zone Circulator)



**Figure 4.5: Alternate Piping – One Boiler, Primary/Secondary with a Peerless® Partner® (Zone Circulators).**  
 Note: The DHW Circulator must be sized to provide minimum flow through the boiler




Figure 4.6: Two Boilers, Primary/Secondary with Four Zones (Zone Circulator)




Figure 4.7: Three Boilers, Primary/Secondary with Five Zones (Zone Circulator)






Figure 4.8: Three Boilers, Primary/Secondary with Four Zones (Zone Valves)

## G. SPECIAL APPLICATIONS

1. If the *PUREFIRE*® boiler is used in conjunction with a chilled medium system, pipe the chiller in a separate secondary loop.
  - a. Assure that the boiler circulator is disabled during chiller operation so that chilled water does not enter the boiler.
  - b. Install a flow control valve (spring check valve) to prevent gravity flow through the boiler.
- c. See Figure 4.9 for recommended system piping for chiller operation.
2. For boilers connected to heating coils in a forced air system where they may be exposed to chilled air circulation, install flow control valves or other automatic means to prevent gravity circulation of the boiler water during cooling cycles. See Figure 4.10 for an illustration.



**Figure 4.9: Boiler in conjunction with a Chilled Water System**



**Figure 4.10: Boiler Connected to a Heating Coil in a Forced Air System**



## 5. FUEL PIPING

### A. GENERAL

1. All fuel piping to the *PUREFIRE*® boiler is to be in accordance with local codes. In the absence of local regulations refer to the National Fuel Gas Code, ANSI Z223.1/NFPA 54.
2. Size and install fuel piping to provide a supply of gas sufficient to meet the maximum demand of all appliances supplied by the piping.
3. *PUREFIRE*® boilers are intended for operation with Natural Gas or Propane with sulfur content of less than 105 ppm (150 mg/m<sup>3</sup>) peak with an annual average of less than 20 ppm (30 mg/m<sup>3</sup>). Excessive sulfur content in fuel input can result in black deposits resembling coffee grounds in the combustion chamber of the boiler.

### B. FUEL LINE SIZING

1. The required flow rate of gas fuel to the boiler can be determined by the following.

$$\text{Input Rate (ft}^3/\text{hr)} = \frac{\text{Boiler Input Rate (Btu/hr)}}{\text{Gas Heating Value (Btu/ft}^3\text{)}}$$

The gas heating value can be supplied by the gas supplier.

2. As an alternative, use Table 5.1 to determine the required gas flow rate which uses typical heating values for natural gas and liquefied petroleum (LP) gas.

**Table 5.1: Required Fuel Input**

<i>PUREFIRE</i> ® Model	Required Input Rate*	
	Natural Gas ft <sup>3</sup> /hr (m <sup>3</sup> /hr)	LP Gas ft <sup>3</sup> /hr (m <sup>3</sup> /hr)
PFC-460	460 (13.0)	184 (5.2)

\* Natural gas input rate is based on 1,000 Btu/ft<sup>3</sup>, LP input rate is based on 2,500 Btu/ft<sup>3</sup>.

3. Tables 5.2 and 5.3 shows the maximum flow capacity of several pipe sizes based on 0.3" of pressure drop.
  - a. The values shown are based on a gas specific gravity of 0.60 (Typical for natural gas).
  - b. Multiply the capacities listed by the correction factors listed for gas with a specific gravity other than 0.60 to obtain the corrected capacity.
4. Size and install the fuel gas supply piping for no more than 0.5 inches of water pressure drop between the gas regulator and the boiler.

### C. GAS SUPPLY PIPING - INSTALLATION

1. Do not install any piping directly in front of the boiler or along either side. Always provide access to the front cover and side panel openings.

**Table 5.2: Pipe Capacity - Natural Gas:**

Maximum Capacity of pipe in cubic feet per hour (cubic meters per hour) with a pressure drop of 0.3" of water (75 Pa).

Pipe Length ft (m)	1" Pipe	1-1/4" Pipe	1-1/2" Pipe	2" Pipe	2-1/2" Pipe	3" Pipe
10 (3.0)	520 (14.7)	1,050 (30)	1,600 (45)	3,050 (86)	4,800 (136)	8,500 (241)
20 (6.1)	350 (9.9)	730 (21)	1,100 (31)	2,100 (59)	3,300 (93)	5,900 (167)
30 (9.1)	285 (8.1)	590 (17)	890 (25)	1,650 (47)	2,700 (76)	4,700 (133)
40 (12.2)	245 (6.9)	500 (14)	760 (22)	1,450 (41)	2,300 (65)	4,100 (116)
50 (15.2)	215 (6.1)	440 (12)	670 (19)	1,270 (36)	2,000 (57)	3,600 (102)
60 (18.3)	195 (5.5)	400 (11)	610 (17)	1,150 (33)	1,850 (52)	3,250 (92)
70 (21.3)	180 (5.1)	370 (10)	560 (16)	1,050 (30)	1,700 (48)	3,000 (85)
80 (24.4)	170 (4.8)	350 (10)	530 (15)	930 (26)	1,500 (42)	2,600 (74)
90 (27.4)	160 (4.5)	320 (9)	490 (14)	870 (25)	1,400 (40)	2,500 (71)
100 (30.5)	150 (4.2)	305 (9)	460 (13)	710 (20)	1,130 (32)	2,000 (57)

**Table 5.3: Pipe Capacity - LP Gas (1.50 Specific Gravity)**

Maximum Capacity of pipe in cubic feet per hour (cubic meters per hour) with a pressure drop of 0.3" of water (75 Pa).

Pipe Length ft (m)	1" Pipe	1-1/4" Pipe	1-1/2" Pipe	2" Pipe	2-1/2" Pipe	3" Pipe
10 (3.0)	328 (9.3)	662 (18.7)	1,008 (28.5)	1,922 (54.4)	3,024 (85.6)	5,355 (151.6)
20 (6.1)	221 (6.3)	460 (13.0)	693 (19.6)	1,323 (37.5)	2,079 (58.9)	3,717 (105.3)
30 (9.1)	180 (5.1)	372 (10.5)	561 (15.9)	1,040 (29.4)	1,701 (48.2)	2,961 (83.8)
40 (12.2)	155 (4.4)	315 (8.9)	479 (13.6)	914 (25.9)	1,449 (41.0)	2,583 (73.1)
50 (15.2)	136 (3.9)	277 (7.8)	422 (12.0)	800 (22.7)	1,260 (35.7)	2,268 (64.2)
60 (18.3)	123 (3.5)	252 (7.1)	384 (10.9)	725 (20.5)	1,166 (33.0)	2,048 (58.0)
70 (21.3)	114 (3.2)	233 (6.6)	353 (10.0)	662 (18.7)	1,071 (30.3)	1,890 (53.5)
80 (24.4)	107 (3.0)	221 (6.2)	334 (9.5)	586 (16.6)	945 (26.0)	1,638 (46.4)
90 (27.4)	101 (2.8)	202 (5.7)	309 (8.7)	548 (15.5)	882 (25.0)	1,575 (44.6)
100 (30.5)	95 (2.7)	192 (5.4)	290 (8.2)	447 (12.7)	712 (20.2)	1,260 (35.7)

2. Install a sediment trap as shown in Figure 5.1. Be sure to allow clearance from the floor or other horizontal surface for removal of the pipe cap.

### **⚠ WARNING**


**Use a pipe joint sealing compound that is resistant to liquefied petroleum gas. A non-resistant compound may lose sealing ability in the presence of this gas, resulting in a gas leak. Gas leaks may potentially cause an explosion or fire.**

3. Install a ground joint union between the sediment trap and the boiler to allow service to the appliance.
4. Install a service valve as shown in Figure 5.1 to allow the gas supply to be interrupted for service.
5. Maintain a minimum distance of 10 pipe diameters between the gas pressure regulator and the boiler.
6. Check all gas piping for leaks prior to placing the boiler in operation. Use an approved gas detector, non-corrosive lead detection fluid, or other leak detection method. If leaks are found, turn off gas flow and repair as necessary.

### **⚠ WARNING**

**When checking for leaks, do not use matches, candles, open flames or other methods that provide an ignition source. This may ignite a gas leak resulting in a fire or explosion.**

7. Figure 5.1 shows the gas shutoff valve for the *PUREFIRE*® boiler. This valve is to be used in addition to the gas service valve shown upstream of the sediment trap.



**Figure 5.1: Gas Supply Pipe and Shut-off**

## **D. GAS SUPPLY PIPING - OPERATION**

1. The gas line must be properly purged of air to allow the boiler to operate properly. Failure to do so may result in burner ignition problems.

2. Table 5.4 shows the maximum and minimum fuel gas supply pressure to be measured at the gas valve inlet pressure tap. See Figure 5.2.
  - a. Gas pressure below 3.5 inches of water column for Natural gas and 8 inches of water column for LP gas may result in ignition failures and hard ignitions.
  - b. Gas pressure above 13.5 inches of water may result in damage to the automatic gas valve.

### **⚠ CAUTION**

**Do not subject the gas valve to more than 1/2 psi (13.5" W.C.) of pressure. Doing so may damage the gas valve.**

**Table 5.4: Max. and Min. Flue Supply Pressure**

Fuel Type	Pressure Inches W.C. (Pa)	
	Minimum	Maximum
Natural Gas	3.5	13.5
LP Gas	8	13.5

3. To check the gas supply pressure to the gas valve:
  - a. Turn off the power at the service switch.
  - b. Close the gas shutoff valve.
  - c. Using a flat screwdriver, turn the screw inside the inlet tap fitting (see Figure 5.2) one turn counter clockwise.
  - d. Attach the tube from the manometer to the pressure tap fitting.
  - e. Open the gas valve and start the boiler.
  - f. Read and record the gas pressure while the boiler is firing at max input as well as with any other appliances to the same gas line at their maximum inputs.
  - g. Turn off the boiler and close the gas shutoff valve.
  - h. Remove the manometer tube from the pressure tap fitting.
  - i. Turn the internal screw clockwise to close the valve.
  - j. Turn on the gas shutoff valve and boiler service switch.
  - k. Fire the boiler and check for fuel gas odor around the gas valve. If an odor is evident check to make sure that the pressure tap fitting is closed.
4. All gas piping must be leak tested prior to placing the boiler in operation.
  - a. If the leak test pressure requirement is higher than 13.5 inches of water column, the boiler must be isolated from the gas supply piping system.
  - b. If the gas valve is exposed to pressure exceeding 13.5 inches of water column, the gas valve must be replaced.

5. Install the boiler such that the gas ignition system components are protected from water (dripping, spraying, rain, etc.) during operation and service (circulator replacement, condensate collector and neutralizer cleanout, control replacement etc.)

**E. MAIN GAS VALVE - OPERATION**


1. Figure 5.2 is an illustration of the gas valve/venturi assembly for the PFC-460 boiler.
  - a. Adjustments should not be made to the gas valve without instrumentation to measure carbon dioxide (CO<sub>2</sub>) and carbon monoxide (CO) emissions in the vent pipe.
  - b. Turning the throttle screw clockwise will decrease the gas flow (decreasing CO<sub>2</sub>) and turning it counterclockwise will increase the gas flow rate (increasing CO<sub>2</sub>). Markings adjacent to the throttle screw show + and – indicating this operation.
  - c. The recommended CO<sub>2</sub> settings are given in Table 5.5. In no case should the boiler be allowed to operate with CO emissions above 150 ppm.

**Table 5.5: Recommended CO<sub>2</sub> Settings**

	Natural Gas		Propane (LP)	
	Low Fire	High Fire	Low Fire	High Fire
Carbon Monoxide (CO)	< 75 ppm	< 150 ppm	< 75 ppm	< 150 ppm
Carbon Dioxide (CO <sub>2</sub> )	8.8% to 11.5%	8.5% to 9.7%	9.8% to 12.5%	9.5% to 10.5%
Excess Oxygen (O <sub>2</sub> )	0.7% to 5.4%	3.9% to 6.0%	1.9% to 6.0%	4.9% to 6.5%
Excess Air	3.2% to 31.2%	20.1% to 35.4%	8.9% to 35.9%	27.6% to 39.8%

- 1 Combustion measurements should be taken during steady state operation. Values during significant transitions may exceed the numbers shown.
- 2 Conversions to excess oxygen and excess air are based on natural gas consisting of 100% methane (CH<sub>4</sub>) or 100% propane (C<sub>3</sub>H<sub>8</sub>)

2. Refer to Section 3, Venting and Air Intake for information on obtaining vent samples from this boiler.

**Figure 5.2: Gas Valve/Venturi****NOTICE**

Instructions (PF8032) for converting from natural gas to LP gas and from LP gas to natural gas are included in the boiler folder.


## 6. CONDENSATE DRAIN PIPING

### A. GENERAL

1. The disposal of all condensate into public sewage systems is to be in accordance with local codes and regulations. In the absence of such codes, follow these instructions.
2. Proper piping and removal of condensation from combustion is critical to the operation of a condensing appliance. Follow these instructions carefully to assure that your *PUREFIRE*® boiler operates correctly.
3. Depending on several factors, the condensate from gas fired condensing appliances may have a pH value as low as 2.5 (similar to cola soft drinks). Some local codes require the use of neutralization equipment to treat acidic condensate.


## B. CONDENSATE SYSTEM

The **PUREFIRE®** condensate system is designed to prevent condensate from backing up into the heat exchanger, trap the condensate to prevent combustion gases from escaping and neutralize acidic condensate. Refer to Figure 6.1 for an illustration of the system components.



**Figure 6.1: Condensate Trap System**

1. *Condensate Drain Hoses:* PFC-460 boilers have a drain attached directly to the combustion chamber. To prevent debris from entering the heat exchanger, a separate drain connection can be added to the vent system at the top bulkhead drain connection as shown in Figure 6.2. If the top bulkhead drain connection is NOT used, a 3/4" PVC or CPVC cap MUST be attached to the connection using proper solvent glue to prevent flue gases from escaping from the vent system.
2. *Condensate Collector Container:* The condensate collector container is a transparent container in the base of the boiler near the back. This container collects the condensate and acts as a part of a trap to prevent combustion gases from escaping. The container is fitted with a level switch that will prevent the boiler from operating if the condensate line is clogged.



### Figure 6.2: Separate Vent Condensate Drain Installation

3. **Condensate Float Switch:** This switch will prevent the boiler from operating if the condensate outlet is clogged before the level of condensate reaches the heat exchanger.

4. **Condensate Neutralizer Container:** The condensate neutralizer container is an additional transparent container near the front of the boiler. Fill this container with the condensate neutralizer provided. The neutralizer will be consumed during normal operation and should be checked occasionally to determine if additional neutralizer is necessary. Neutralizer is available in 1 lb bags (#54159) from your PB Heat Distributor.
5. **Bulkhead fitting:** The bulkhead fitting allows the condensate tubing to pass through the jacket without providing a path for leakage from the jacket. A PVC TEE is to be attached to the outlet of this fitting to prevent siphoning of the trap.
6. **Neutralizer:** Condensate neutralizer is provided in a package with the boiler to fill the condensate neutralizer container (Item 4).
7. **Neutralizer Cap:** This cap provides access for adding and inspecting the condensate neutralizer.
8. **Condensate Drain Tube:** This pre-formed tube connects the condensate system to the bulkhead fitting for attachment to an external drain.

### C. CONDENSATE DRAIN PIPE MATERIAL

The condensate drain is to be piped using PVC, polypropylene, or other material resistant to acidic condensate. Do not use steel, brass or galvanized pipe for this purpose. The acidic condensate will attack most metals and corrode.

### D. CONDENSATE DRAIN PIPE SIZING

The bulkhead fitting for condensate connection is for 3/4" schedule 40 PVC Pipe. Be sure to use 3/4" or larger tubing from the boiler to the drain.

### E. CONDENSATE DRAIN PIPE INSTALLATION

1. Connect a 3/4" schedule 40 PVC Tee to the outlet of the bulkhead fitting as shown in Figure 6.3. Pipe from the bottom of the tee to a suitable drain.




Figure 6.3: Condensate Drain Piping

2. Be sure that the piping slopes away from the boiler with a pitch of 1/4" per foot of pipe.
3. If the boiler condensate drain is above the level of a gravity drain, a condensate pump should be used. Table 6.1 lists several available brands. Contact your PB Heat, LLC Distributor for availability.

Table 6.1: Recommended Condensate Pumps

Brand Name	Model Number
ITT Bell & Gossett	LS
Little Giant	VCMA-15UL
Beckett	CB151LSUL
Hartell	KT-15-1UL

# 7. ELECTRICAL CONNECTIONS

## A. GENERAL

This appliance is to be wired in accordance with local codes and regulations as defined by the Authority having jurisdiction. In the absence of such local codes, the *PUREFIRE*® boiler is to be wired in accordance with the latest edition of the National Electrical Code, ANSI/NFPA 70.

## B. CUSTOMER CONNECTIONS

1. Electrical knockouts are provided on the top panel of the boiler to connect supply wiring, circulator wiring and wiring to various instruments.
2. Electrical terminals are located behind the User Interface and can be accessed by loosening the two nuts shown in Figure 7.1.





Figure 7.1: Electrical Terminal Access

- a. Remove one of the nuts and leave the other fully loosened in order to leave the display interface panel connected to the appliance.
- b. The terminals can be removed by gently pulling them away from their wired blocks. This allows the installer to easily attach wires to the connector before plugging it into the block.

3. Figure 7.2 shows customer connections for PFC-460 boilers.

- a. Terminals 1-10 on the left side are for low voltage customer connections to the CH thermostat, outdoor sensor, DHW sensor or thermostat, system sensor and low water cutoff contacts. The outdoor sensor is included. The DHW sensor (54157) and the system sensor (54156) are optional components and the low water cutoff, if used, is to be supplied by others.
- b. Terminals 11 & 12 on the left side are for connecting multiple boilers together using a cascade link which is described in Section 8.
- c. Terminals 15 & 16 are used with the OPTIONAL PFA-1 Interface board (part# 54737) for 0-10 volt input signal.
- d. Terminals 17 through 26 on the right side are for line voltage customer connections to DHW, CH, and General Circulators; voltage supply, and low water cutoff (LWCO) power output.
- e. Terminals 27 through 30 are a ground bus for any line voltage ground connections.
- f. Terminals 31 & 32 are used with the OPTIONAL PFA-1 Interface board (part# 54737) for Alarm Contacts.



\*\* USE AN ISOLATION RELAY (RIB2401B OR EQUAL) TO POWER PUMPS AND/OR 3-WAY VALVES IF EXCEEDING 10 AMPS ON ANY PUMP TERMINAL.

Figure 7.2: Customer Connections – PFC-460

- Note that the service switch does not disconnect power to the convenience outlet.

### C. ZONE CIRCULATOR WIRING

Wiring for a typical circulator zone relay is shown in Figure 7.3.




Figure 7.3: Typical Zone Circulator Relay Wiring

### D. INTERNAL WIRING

Figure 7.4 shows the complete boiler wiring schematic for PFC-460 boilers. The following is a list of internal wiring components:


- User Interface:** The user interface is attached to the front of the electrical junction box and is accessible by removing the tinted lens on the front of the boiler. This interface allows users and installers to communicate with the control.
- Supply/Return Sensors:** These component, located on the left header are a pair thermistors that provide supply and return water temperature information to the control. Be sure to use only a *PUREFIRE* supply thermistors for this boiler.
- Limit Switch:** This component is a bi-metal switch that will prevent the boiler from reaching temperatures above 203°F (95°C) to prevent damage to the boiler. Be sure to use only a *PUREFIRE* supplied switch
- Flue Sensor:** This thermistor provides flue temperature information to the control. It is located in the back of the electrical junction box behind the user interface.
- Condensate Drain Float Switch:** This switch is mounted in the condensate collector below the heat exchanger in the rear of the cabinet.
- Service Switch:** The service switch interrupts the power to the *PUREFIRE* boiler to allow service to be performed.
- Convenience Outlet:** The convenience outlet is provided for a condensate pump during operation. It is not switched with the service switch to allow its use for lighting during maintenance.
- Flame Sensor:** The flame sensor uses the principal of flame rectification to sense the burner flame. This is located on the right side of the heat exchanger front plate. After ignition, the control also senses flame through the ignition electrode.
- Gas Valve:** The gas valve is connected through a special cord and connector. The connector is attached to the valve with a screw.
- Ignition Electrode:** This electrode is located on the left side of the heat exchanger front plate. A 10,000 volt charge is initiated by the control to provide a spark for lighting the burner. After the burner lights, and no spark is present, the control uses this electrode as a second source of flame detection.
- Combustion Air Fan:** The combustion air fan has two connections. There is a 120 volt power connection (3-wire) and a low voltage control connection (4-wire).
- Blocked Vent Switch:** This switch is used to detect a blockage in the exhaust vent.
- PUREFIRE Link Adapter (Green Plug):** The adapter is used by Factory Engineers to review control settings.
- Burner Plate Switch:** This switch (Part #50045) is used to detect overheating of the burner plate, primarily caused by broken insulation on the inside of the burner plate.
- Thermal Fuse:** This fuse (stock code #54466) is used to detect overheating at the rear of the heat exchanger behind the combustion chamber. If this device causes an open circuit then it requires replacement. Before replacing the switch, inspect the target wall inside the combustion chamber at the rear to be sure it is intact.
- Relay Module:** This module, located in the control cabinet, prevents overcurrent of the main boiler control by isolating the pump current. This allows a maximum current of 10 Amps on each circulator (CH, DHW and GEN) to be connected.

### NOTICE

**IF the fuse blows in the boiler control, a spare fuse (found in a holder on the control cover) can be used as a replacement. DIAGNOSE POSSIBLE CAUSES FOR BLOWN FUSE BEFORE REPLACING. Additional fuses can be ordered as need from your Peerless Boiler Distributor (Part #5650). See Figure 10.1 for location of Boiler Control fuse and spare fuse.**



## ELECTRICAL CONNECTIONS



**Figure 7.4: Internal Wiring Schematic for PFC-460.**



# 8. BOILER CONTROL: OPERATION

## A. CONTROL OVERVIEW

The *PUREFIRE*® boiler control is one of the primary safety devices for the boiler. It controls the ignition sequence, temperature limits, circulators and gas flow to the boiler. It also provides many unique features.

The control provides 8 central heating modes and 3 domestic hot water modes. To provide maximum flexibility, several special features are also included.

### 1. Central Heating (CH) Modes:

The *PUREFIRE*® boiler control allows the installer to choose from several different central heating modes. The following table shows the central heating modes. In addition, the table shows the display text associated with each CH mode and a brief description of the operation.

### 2. Domestic Hot Water (DHW) Modes:

The *PUREFIRE*® boiler control also allows the installer to choose from three different DHW modes.

**Table 8.1: Central Heating (CH) Modes**

Central Heating Mode	Description										
0 (Indoor Thermostat) <i>Default</i>	Boiler operates when CH TSTAT terminals (#1 & #2) are closed targeting a fixed setpoint regardless of heating load.										
1 (Thermostat and Outdoor Reset)	Boiler operates when CH TSTAT terminals (#1 & #2) are closed targeting a variable setpoint based on outdoor temperature.										
2 (Permanent Demand and Outdoor Reset)	Boiler operates to maintain a variable setpoint based on outdoor temperature. When CH TSTAT terminals (#1 & #2) are closed, 18°F is subtracted from the calculated setpoint.										
3 (Permanent Demand and Setpoint)	Boiler operates to maintain a fixed setpoint. When CH TSTAT terminals (#1 & #2) are closed, 18°F is subtracted from the setpoint.										
4 (Analog 0-10 VDC Input – Setpoint)	Boiler operates on setpoint from an external device (BMS) based on a 0-10 VDC analog signal to provide setpoint. <table> <tr> <th>Input Signal</th><th>Target Setpoint</th></tr> <tr> <td>0-1.5 VDC</td><td>OFF</td></tr> <tr> <td>2 VDC</td><td>60°F</td></tr> <tr> <td>6 VDC</td><td>123°F</td></tr> <tr> <td>10 VDC</td><td>189°F</td></tr> </table>	Input Signal	Target Setpoint	0-1.5 VDC	OFF	2 VDC	60°F	6 VDC	123°F	10 VDC	189°F
Input Signal	Target Setpoint										
0-1.5 VDC	OFF										
2 VDC	60°F										
6 VDC	123°F										
10 VDC	189°F										

**Table 8.2: Domestic Hot Water (DHW) Modes**

Domestic Hot Water Mode	Description
0 (No DHW)	No DHW tank is used.
1 (DHW Tank with sensor)	The domestic water tank is equipped with a temperature sensor. The <i>PUREFIRE</i> ® control modulates the boiler firing rate based on tank temperature
2 (DHW Tank with thermostat)	The domestic water tank is equipped with a thermostat. The <i>PUREFIRE</i> ® control responds to the demand from the thermostat and modulates the boiler firing rate targeting the DHW boiler setpoint. If no domestic hot water tank is connected, this feature will not function.

**Table 8.3: Pump Modes**

Pump Mode	Display Text	Brief Description
0	DHW or CH & DHW pump	The General pump is always on when the burner is on. The CH pump runs on CH demand. The DHW pump runs on DHW demand. Either the CH or DHW pump runs; they never run at the same time
1	General pump with 3-way valve	The General pump is always on when burner is on. A line voltage (120 VAC) 3-way valve is operated to supply water to the DHW tank.
2	Manifold with pump for DHW	This mode is not used for most operations. Consult factory if needed.

## 3. Special Features:

The *PUREFIRE*® control offers several special features to give the installer options in setting up the boiler. These options are shown in the following table and described in detail later in this section.

**Table 8.4: Control Features**

Feature	Description
System Response Time	Allows the installer to adjust the response time of the burner modulating control. This can be set differently for central heating (CH) or domestic hot water (DHW) demands. This is known as “I” value.
Maximum Firing Rate	Allows the installer to adjust the maximum firing rate of the burner modulating control. This can also be set differently for CH or DHW demands.
Cascade	Up to 16 boilers can operate together in stages to satisfy the CH or DHW demand.
One Hour Retry	One hour after a lockout on ignition, fan speed or flame failure, the <i>PUREFIRE</i> ® control will reinitiate boiler operation.
Adjustable Blower Postpurge	The blower postpurge may be increased to counteract the effects of high winds or unusual wind currents.
Flame Signal Log	This troubleshooting tool captures the flame signal at four increments during the two second flame proving period. This will help service people to quickly diagnose problems with flame rectification.
Freeze Protection	Activates pumps if water temperatures fall below the specified value. If the temperature continues to fall, the burner is activated.
DHW Tank Warm Hold	Prevents the boiler from ramping up to high power if the control determines that the DHW demand is only due to tank standby losses.
Additional Safety Functions	Allows the installer to choose between a low water cutoff and a flow switch for water level safety shutdown.
Vent Temperature Safety Limit	Reduces the firing rate if the exhaust vent temperature approaches the maximum limit of the vent material specified. The control will shut down the burner if the temperature continues to climb.
System Type Presets	Automatically sets the reset calculation based on the type of heat distributions (finned tube baseboard, cast iron radiators, cast iron baseboard, low or high mass radiant).
Temperature Boost	Increases the boiler supply temperature target if the control determines that the load cannot be met at the current reset temperature (Outdoor Reset Modes).
Warm Weather Shutdown	Shuts down the boiler if the outdoor temperature exceeds an installer defined limit (Outdoor Reset Modes).
Limited DHW Priority	The <i>PUREFIRE</i> ® control provides DHW priority for boiler operation. The control will switch back to CH if a demand remains present for an installer set switch time.
System Test	The <i>PUREFIRE</i> ® boiler will allow the installer to operate the boiler at low power, ignition power or high power for setup and troubleshooting.
Fault History	This mode is not used for most operations. Consult factory if needed.


## NOTICE

The **PUREFIRE®** PFC-460 utilizes a single control system. Treat the PFC-460 control as a managing control.

## B. IGNITION SEQUENCE

Figure 8.1 shows the ignition sequence for the **PUREFIRE®** boiler control. Table 8.5 describes each step in the sequence in detail. The **PUREFIRE®** boiler control provides dual sensing of the flame to maximize the reliability. The control senses the burner flame with both the flame sensor and the ignition electrode.

**Ignition Cycle**



**Figure 8.1: Ignition Cycle – Graphical Representation**

**Table 8.5: Ignition Sequence**

Period	Demand Status	Burner LCD Display
Standby	No demand is present	<div>1 6 : 3 6</div> <div>STANDBY</div> <div>1 6 0 ° F</div>
	If the power is on to the <b>PUREFIRE®</b> boiler and there is no heat demand, the burner LCD will display “Standby” and show the boiler supply temperature in the lower right corner. The time, in 24 hour format, is shown in the upper right. When a heat demand (either CH or DHW) is present, the boiler begins the ignition cycle.	
Pre Purge	A CH or DHW demand must be present to initiate ignition. Once initiated the boiler will light.	<div>1 6 : 3 6</div> <div>CENTRAL HEATING</div> <div>Trial For Ignition</div>
	When a demand is present, the <b>PUREFIRE®</b> control starts the combustion air fan. The fan speed then increases to ignition speed and the burner LCD displays the source of the call for heat along with “Trial for ignition.” This screen is displayed until the burner is lit and stable or until a fault occurs. Once the ignition sequence begins it will continue through ignition even if the demand has ended.	

**Table 8.5: Ignition Sequence (cont'd)**

Period	Demand Status	Burner LCD Display
<b>Safety On/Off</b>	A heat demand has no influence in the Safety On/Off period. The Safety On/Off step will continue even if the demand has ended.	<div>1 6 : 3 6</div> <div>CENTRAL HEATING</div> <div>Trial For Ignition</div>
	This step very quickly opens and closes the gas valve relays and determines if the control is operating correctly. The CH pump is turned off during this test.	
<b>Pre-Ignition</b>	A heat demand has no influence in the Pre-Ignition period.	<div>1 6 : 3 6</div> <div>CENTRAL HEATING</div> <div>Trial For Ignition</div>
	Once the internal check is complete, the control begins a Pre-Ignition sequence. The igniter is energized while the gas valve remains off. If a flame is detected at the end of the pre-ignition period a lockout will occur.	
<b>Ignition</b>	A heat demand has no influence in the Ignition period.	<div>1 6 : 3 6</div> <div>CENTRAL HEATING</div> <div>Ignition Retry</div>
	<div>1 6 : 3 6</div> <div>NO IGNITION</div> <div>Fan Post Purge</div> <p>The igniter remains energized for the first 4 seconds of the Ignition period. For the final 2 seconds of the Ignition period, the igniter is turned off and the control checks for a flame signal through both the ignition electrode and the flame sensor. If no flame signal is present at the end of the Ignition period, the control initiates a post-purge and then begins the ignition cycle again. If the number of ignition failures exceeds the allowable number in one call for heat, the control will post purge and lock out. If the "One Hour Retry" parameter is set to, "ON", the control will retry ignition one hour after an ignition failure. The control records 4 flame signal values during the last two seconds of this period that can be accessed from the "Installer Menu" under "Status".</p>	
<b>Burner On</b>	A heat demand must be present for the control to stay in this period.	<div>1 6 : 3 6</div> <div>CENTRAL HEATING</div> <div>1 0 0 % I n p u t      1 6 0 ° F</div>
	Once a flame signal is established, the burner will run until a demand is satisfied, the setpoint is exceeded, or a blocking/lockout error occurs. The maximum run period for the burner is 24 hours. If the boiler runs continuously for 24 hours, the control will override the demand and turn off the burner. After this a restart will occur and the burner will continue to run.	
<b>Post Purge 1</b>	After the Post Purge period begins, a heat demand will be ignored until after this period.	<div>1 6 : 3 6</div> <div>CENTRAL HEATING</div> <div>Fan Post Purge</div>
	During post purge 1, the control monitors the flame signal to be sure that the flame has extinguished. If a flame is detected after the maximum 10 second time period, a control lockout will occur.	
<b>Post Purge 2</b>	During this period a heat demand has no effect on operation.	<div>1 6 : 3 6</div> <div>SUPPLY AT SETPOINT</div> <div>Fan Post Purge</div>
	During this period, the combustion air fan runs at high speed to purge combustion gases from the heat exchanger. The default fan post purge period is 30 seconds. It is adjustable up to 120 seconds.	
<b>Pump Purge</b>	No heat demand is present.	<div>1 6 : 3 6</div> <div>CENTRAL HEATING</div> <div>Circulator ON</div>
	The operation of the circulators and the boiler depend on the pump mode and the heat demand status.	

## NOTICE

Subsections C-E of this supplement are to be used in lieu of subsections C-I in the PF8248 I,O,&M instructions.

### C. USER MENU

To access the user menu, simply press the "Menu" key on the LCD display. Use the "▲" and "▼" keys on the display to move the cursor to the desired selection. Pressing "Select" will access the submenu for the selection. The submenus are described in detail below.

```

M E N U
→ S t a t u s
  S e t t i n g s
  M e s s a g e s

```

Figure 8.2: User Menu

#### 1. LCD Status Menu

**Status Menu:** The user status menu gives the user or installer access to basic information about the boiler system. The first screen shows the Current Supply Setpoint. If the boiler is in CH Mode 0, 2 or 6, this is the temperature that the boiler targets. As the boiler approaches this target, the burners will modulate their input.

```

S T A T U S

C u r r e n t   S u p p l y
S e t p o i n t   1 6 0 ° F

```

Figure 8.3: Status – Supply Setpoint

The next screens show temperature values read by the temperature sensors in the control system. The supply and return temperatures are measured at the header on the outlet side of the heat exchanger. There is a supply and return sensor for each burner. In addition to the supply and return sensors, there is a header (system) sensor on the boiler supply (outlet) pipe.

```

S T A T U S
S u p p l y           1 6 0 ° F
R e t u r n           1 3 0 ° F
D H W                 1 2 0 ° F

S T A T U S
S y s t e m           1 5 8 ° F
V e n t               1 3 2 ° F
O u t d o o r         4 2 ° F

```

Figure 8.4: Status – Temperature

Typical Values for Water Sensors: (Supply/Return/System/DHW): 70°F (21°C) to 200°F (93°C).

A value of 14°F (-10°C) indicates an open sensor and a value of 244°F(118°C) indicates a short for these sensors.

Typical Values for the Vent Sensor are: 70°F (21°C) to 200°F (93°C).

A value of 50°F (-10°C) indicates an open sensor and a value of 244°F(118°C) indicates a short. Since boilers installed in low temperature environments such as a garage may experience vent temperatures below 50°F, the control works as follows:

- If the Vent Temperature Sensor reads less than 50°F, the boiler will continue to operate normally, unless,
- If the return temperature exceeds 80°F (27°C) or the supply temperature exceeds 120°F (49°C) the burners will operate at their minimum modulation until the call for heat ends or the vent temperature exceeds 50°F.

The outdoor sensor temperature should correspond to the current outdoor temperature. If the sensor is mounted in direct sunlight or near an appliance exhaust vent, erratic operation can result due to large changes in the apparent outdoor temperature.

A value of -40°F (-40°C) indicates an open sensor and a value of 244°F(118°C) indicates a short for this sensor.

The final screen of the status menu provides information on the status of each of the circulators.

```

S T A T U S
G e n e r a l   C i r c .   O N
C H   C i r c u l a t o r   O N
D H W   C i r c u l a t o r   O F F

```

Figure 8.5: Status – Circulators

#### 2. LCD Settings Menu

The user settings menu provides access to basic settings on the *PUREFIRE* control. After choosing the "Settings Menu" the Central Heating Setpoint menu appears. To access the other menus, press the "▼" key. Some of the menus shown below will not appear depending on the CH or DHW mode chosen.

- Central Heating Setpoint:** Depending on the CH Mode chosen (in the Installer Menu), the user may be able to adjust the boiler water temperature that is targeted by the control on a central heat demand. If the CH Mode is 1 or 2 (Outdoor Reset), this screen will show "OD RESET" along with the target temperature calculated by the control algorithm. The user is not allowed to override the calculated temperature. If CH Mode 0 or 6 is chosen, the target temperature can be changed by pressing the "Select" key and using the "▲" and "▼" keys to increase or decrease the value. The following shows the range and default values for the Central Heating Setpoint.

```

S E T T I N G S
C e n t r a l   H e a t i n g
S e t p o i n t
O D   R E S E T   1 2 8 ° F

```

Figure 8.6: Settings – CH Setpoint

Table 8.6: CH Setpoint Range & Defaults

Central Heating Setpoint	Minimum	Maximum	Default
	50°F	195°F	160°F
	10°C	91°C	71°C

## NOTICE

DHW Boiler Setpoint Setting is only available in DHW Mode 1 & 2.

- b. DHW Boiler Setpoint: This value determines the target temperature for the boiler supply to an indirect domestic hot water (DHW) storage tank. This should not be confused with the DHW Tank temperature. If the DHW Mode is set to Mode 0 (No DHW) this screen will not be visible.

```

SETTINGS ▲
DHW Boiler Setpoint
180°F ▼
    
```

Figure 8.7: Settings – DHW Boiler Setpoint

Table 8.7: DHW Boiler Setpoint Range & Defaults

DHW Boiler Setpoint	Minimum	Maximum	Default
	122°F	195°F	180°F
	50°C	91°C	82°C

## NOTICE

DHW Tank Setpoint Setting is only available in DHW Mode 1.

- c. DHW Tank Setpoint: This screen allows the user to select the target temperature for the indirect DHW storage tank. This screen is only visible if the DHW Mode is set to Mode 1 (DHW Tank with Sensor) and an optional 12 kW DHW Tank sensor is purchased (PB Stock Code 54157).

```

SETTINGS ▲
DHW Tank Setpoint
120°F ▼
    
```

Figure 8.8: Settings – DHW Tank Setpoint

## ⚠ DANGER

Water temperatures over 125°F can instantly cause severe burns or death from scalding. Children, elderly and disabled individuals are at the highest risk of scalding. See instruction manual for the indirect tank before setting the water heater temperature. Instruct users to feel the water temperature before bathing or showering. Anti-scald valves are recommended.

## ⚠ WARNING

Be sure to only use the 12 kW tank sensor indicated. Other sensors will not provide accurate tank temperatures and may cause severe personal injury due to scalding.

Table 8.8: DHW Tank Setpoint Range & Default

DHW Tank Setpoint	Minimum	Maximum	Default
	50°F	158°F	120°F
	10°C	70°C	49°C

- d. Time & Date: This screen allows the user to set the current date & time for the burner. Setting the current date and time allows the installer to set up alert messages for routine inspection and maintenance.

```

SETTINGS ▲
Time & Date
Monday
03 Jan 2011 16:36 ▼
    
```

Figure 8.9: Settings – Date & Time

- Press the “Select” key. The third line will alternately flash the day of the week and “---”.
- Use the “▲” and “▼” keys to change the day. Press the “Select” key to select the correct day.
- The date value will flash. Use the “▲” and “▼” keys to change the date. Press the “Select” Key.
- The month value will flash. Use the “▲” and “▼” keys to change the month. Press the “Select” Key.
- The year value will flash. Use the “▲” and “▼” keys to change the year. Press the “Select” Key.
- The hour value will flash. Use the “▲” and “▼” keys to change the hour. Press the “Select” Key. (Note that the hour is displayed in the 24 hour format so that 3:00 pm = 15:00.)
- The minute value will flash. Use the “▲” and “▼” keys to change the minutes. Press the “Select” Key.

The date and time will be stored in non-volatile memory so the date will not require resetting if the power is disconnected.

- e. Temperature Units: This screen allows the user to change the temperature unit display. The default units are Fahrenheit °F. To change the unit display, press the “Select” key. The current unit system will flash. Use the “▲” and “▼” keys to change the value to Celsius °C. Press the “Select” key again to choose the units.

```

SETTINGS ▲
Temperature Units
Fahrenheit °F
    
```

Figure 8.10: Settings – Temperature Units

### 3. LCD Message Menu

The messages menu allows the user to view the last blocking error or last lockout error. The display will also show the interval between the last blocking or lockout error and the error before the last. To determine the interval between the current time and the error displayed, create an error by disconnecting the supply sensor wire.

- a. **Last Lockout Error:** The last lock menu allows the user to view the reason for the last lockout. See Table 10.2 for a list of locking errors and the associated codes. Note that a value of #255 indicates that there are no lockout errors in the control history. Also, note that the errors displayed may have occurred during the factory fire test or field commissioning of the equipment.

Last Lock	A 0 1
2 Hrs ago	
Ignit. Error	▼
Last Block	E 3 1
2 Days ago	▲
INTERLOCKS OPEN	▼

Figure 8.11: Messages – Last Errors

- b. **Last Blocking Error:** The last block screen allows the user to view the reason for the last blocking error. See Table 10.1 for a list of blocking errors and the associated “E” codes. Note that a value of #255 indicates that there are no blocking errors in the control history. Also, note that the errors displayed may have occurred during the factory fire test or during field commissioning of the equipment.

## D. INSTALLER MENU

### 1. Menu Overview

The installer menu allows installing or service contractors to view and/or make adjustments to the permanent boiler settings based on the installation configuration, desired operation and local codes. The menu structure is shown in Figure 8.12.

INSTALLER MENU	
→ Status	
Burner Settings	
CH Settings	▼
INSTALLER MENU	▲
DHW Settings	
Service Notif.	
→ System Test	▼
INSTALLER MENU	▲
System Test	
Cascade Settings	
→ Defaults	

Figure 8.12: Installer Menu

To access the installer menu, press and hold the “Menu” and “Select” key on the LCD display.

### 2. Status

The status menu is designed to monitor key parameters and aids the installer or service contractor in determining if there are problems with boiler operation.

- a. **Current Supply Setpoint:** The setpoint value will change for DHW demands or CH demands depending on the setpoint chosen for these modes of operation. When outdoor reset modes are selected, this value is the calculated target for the system.

STATUS	1
Current Supply	
Setpoint	160 ° F ▼

Figure 8.13: Status – Supply Setpoint

- b. **Fan Speeds:** Screens #2 & #3 display fan speed information. The current fan speed will vary during operation between the low power and high power values. The Low Power, Ignition, and Hi Power values are preset at the factory for a specific model size. Table 12.3, in Section 12 of this manual, shows the fan speed presets for each model size. Note that these values may vary slightly due to air setting changes.

STATUS	2 ▲
Fan Speed	
Current	5400 RPM
Low Power	1920 RPM ▼

STATUS	3 ▲
Fan Speed	
Ignition	4800 RPM
Hi Power	6180 RPM ▼

Figure 8.14: Status – Fan Speeds

- c. **Flame Measurements:** Screens #4, #5 & #6 display flame signal information. The first value, Flame Signal, is the current flame rectification signal in micro amps (µA). The minimum value for this signal that will allow the burner to continue running is 2.8 µA the maximum value for this is 10 µA.

STATUS	4 ▲
Flame	
Signal	9.6 µA
Failures	0 ▼

STATUS	5 ▲
Flame	
Meas. 1	2.5 µA
Meas. 2	3.1 µA ▼

STATUS	6 ▲
Flame	
Meas. 3	2.5 µA
Meas. 4	3.1 µA ▼

Figure 8.15: Status – Flame Signal

The next value, Flame Failures, is the number of times the burner has dropped out due to flame failure. Several flame failures may have occurred during the factory firetests and installation. If there are a large number of flame failures showing on this screen, contact your Peerless® Representative.

On Screens #5 and #6, the Flame Measurement values 1-4 are logged in the last two seconds of the most recent ignition sequence in 1/2 second intervals. This helps service contractors to diagnose ignition issues.



- d. **Ignition Attempts:** Screen #7 provides information about ignition attempts. Obviously, the total ignition attempts are the sum of the successful and failed attempts. Several ignition failures may occur during factory firetest and equipment commissioning. However, if there are a large number of failed ignition attempt showing on this screen, contact your Peerless® Representative. If there is an unusually large number of total ignition attempts, there may be a problem with the boiler short cycling.

```

STATUS 7 ▲
Ignition Attempts
Successful 1220
Failed 1 ▼
    
```

**Figure 8.16: Status – Ignition**

- e. **Burner Run Time:** Screen #8 provides information about the total run time of each burner. The total burner run time is the sum of the central heating (CH) and domestic hot water (DHW) hours. The total boiler run time is the sum of both burner run times.

```

STATUS 8 ▲
Burner Run Time
CH 250 HR
DHW 700 HR ▼
    
```

**Figure 8.17: Status – Burner Run Time**

- f. **Blocking Errors:** Screen #9 provides error history about the last 16 blocking errors. Blocking errors are errors that prevent the burner from operating until the condition causing the error is corrected. Sensor errors, low water, and blocked vent are examples of this type of error. To review previous errors, press the select key. The number in the upper right changes from the status screen “9” to a blinking “0” indicating that this is the most recent error. Use the arrow keys to scroll through previous errors from 0 to 15. If the screen shows “#255” in the error number location, this indicates that there is no error stored in this location. All errors on screens higher than one showing “#255” should also indicate no error. Table 10.1 (in Section 10) provides a list of blocking errors.

```

STATUS # E 2 6 9 ▲
3 min to prev. Block
BLOCKED CONDENSATE
DRAIN ▼
    
```

**Figure 8.18: Status – Blocking Errors**

- g. **Lockout Errors:** Screen #10 provides error history about the last 15 locking errors. Locking errors are errors that require a manual reset on the control board (pushing the “Reset” key on the display) to reset the burner once the condition causing the error has been corrected. Ignition Failure, Flame Failure and High Limit Temperature are examples of this type of error. To review previous errors, press the “Select” key. The number in the upper right changes from the status screen number “10” to a blinking “0” indicating that the screen is showing the most recent lockout error. If the burner is not in lockout, this position should show “#255” in the error number location. Use the arrow keys to scroll through previous errors from 1 to 15. As with blocking errors, “#255” always indicates that no error is stored in this location. Table 10.2 provides a list of lock out errors.

```

STATUS # A 0 1 10 ▲
16 hrs to prev. Lock
Ignit error ▼
    
```

**Figure 8.19: Status – Locking Errors**

## NOTICE

The **PUREFIRE®** PFC-460 can only be operated with the Burner set to Standalone. Do not change the Burner Settings from the factory setting for PFC-460 models.

### 3. Burner Settings

The burner settings menu allows the installation or service contractor to change settings which effect the burner operation. The following are descriptions of the available settings.

- a. **Burner Mode:** The burner modes are set by default from the factory. The burner mode is set to “standalone” from the factory for the PFC-460. **Do not use any other setting for this parameter with the PFC-460.**
- b. **Boiler Address:** **PUREFIRE®** boilers can be operated in cascade with as many as 15 identical boilers by adding 2 wire communication links between the boilers. The following chart shows the role of the boiler depending on the boiler address. Multiple boiler operation is covered in-depth at the end of this section of the manual.

```

BURNER SETTINGS 1 ▲
Burner Mode:
Standalone ▼

BURNER SETTINGS 2 ▲
Address Selection
Boiler Address: 0 ▼
    
```

**Figure 8.20: Burner Settings – Burner Mode & Boiler Address**

**Table 8.9: Boiler Address**

Boiler Address Value	Description
0	Stand-Alone Boiler
1	Master Boiler in a Cascade System
2-16	Dependent Boilers in a Cascade System

- c. **Installation Location & Vent Material:** Due to differing national codes in the United States and Canada, there are different material requirements for exhaust vent pipe. Therefore, the maximum vent limit temperature is different depending on the material used.

Screens #3 and #4 allow the installer to select the installation location and vent material. Based on the information given, Table 8.10 shows the exhaust temperature that the control will allow before reducing the burner input rate. If the temperature of the exhaust gas approaches these values, the control will reduce the input rate on both burners until the temperature begins to drop. If the flue temperature continues to rise, the control will shut down both burners.





**Figure 8.21: Burner Settings – Location & Vent Material**

**Table 8.10: Vent Temperature Limits**

Vent Material	Location	
	U.S.A.	Canada
PVC	190°F (80°C)	149°F (65°C)
CPVC	230°F (110°C)	190°F (80°C)
Polypropylene (PPs)	230°F (110°C)	230°F (110°C)
Stainless Steel	230°F (110°C)	230°F (110°C)

Note: Although stainless steel can withstand a temperature higher than 230°F (110°C) the temperature limit is set to this temperature since the vent temperature should not exceed this temperature unless there is a problem with the heat exchanger.

**Table 8.11: Location & Vent Material Default**

Parameter	Default
Location	U.S.A.
Vent Material	PVC

- d. **Freeze Protection:** Freeze protection is intended to prevent freezing the central heating system.



**Figure 8.22: Burner Settings – Freeze Protection**

- First, the control activates pumps to distribute heat uniformly through the system.
  - If the boiler supply (header) temperature drops below the value selected for "Freeze Protection starts at:", the General (boiler) circulator is activated.
  - If either of the boiler return sensors reports a value below this temperature, the CH circulator is started.
- Next, if the return temperature drops more than 9° (5°C) below the "Freeze Protection starts at:" value, the controls activates the burner at its minimum rate.
  - If a central heat demand is detected while the burner is operating for Freeze Protection, the burner will run normally to satisfy the demand.

- Finally, once the return temperature increases to 9°F (5°C) above the chosen value, the burner is switched off and the pumps are deactivated.

**Table 8.12: Freeze Protection Range & Default**

Freeze Protection Starts at	Default	Minimum	Maximum
	50°F (10°C)	45°F (7°C)	56°F (13°C)

- e. **Blower Postpurge Time:** The blower postpurge time can be increased to address problems under extreme conditions (long exhaust vent runs, high winds, etc.) where the products of combustion are not fully expelled from the venting system. This feature should be used sparingly as it may lead to decreased efficiency and higher fuel bills in certain situations.



**Figure 8.23: Burner Settings – Blower Post Purge**

**Table 8.13: Blower Post Purge Range & Default**

Blower Post Purge Time	Default	Minimum	Maximum
	30 sec	30 sec	120 sec

- f. **Additional Safety Features:** The Boiler Control is equipped with terminals for either a low water cutoff or a flow switch. The low water cutoff is the factory default and a factory supplied jumper is installed. This jumper is to be removed if a low water cutoff or flow switch is installed.



**Figure 8.24: Burner Settings – Additional Safety Functions**

- Low Water Cut Off:** The installer can connect the power supply wires for a probe-type low water cutoff to terminal #19 (Hot) and #20 (Neutral) in the main terminal box. The contacts should be wired to terminals #9 and #10.
- Flow Switch:** If a flow switch is used, simply wire the contacts to terminals #9 and #10 in the main terminal box.
- Ignition Attempts:** The control is configured from the factory to not allow the burner to recycle after a failed ignition attempt. At installation, the control can be configured to allow up to 3 ignition attempts before locking out and requiring a manual reset. In addition, the control may be configured to retry for ignition, one hour after lockout without a manual reset. Check applicable codes before changing these parameters.

BURNER SETTINGS 8 ▲  
Ignition Attempts  
Allowed : 1 ▼

BURNER SETTINGS 9 ▲  
Ignition Attempts  
One Hour Retry OFF ▼

**Figure 8.25: Burner Settings – Ignition Attempts Allowed**

**Table 8.14: Ignition Attempts Ranges & Defaults**

Parameter	Default	Minimum	Maximum
Ignition Attempts Allowed	1	1	3
Ignition Attempts 1 Hr Retry	OFF	OFF	ON

- h. **Flame Failures:** The control is configured from the factory to not allow the burner to recycle after a flame failure. At installation, the control can be configured to allow up to 2 retries after a flame failure before locking out and requiring a manual control reset. In addition, the control may be configured to retry for ignition one hour after a lockout without a manual reset. Check applicable codes before changing these parameters.

BURNER SETTINGS 10 ▲  
Flame Failure  
Allowed : 1 ▼

BURNER SETTINGS 11 ▲  
Flame Failure  
One Hour Retry OFF ▼

**Figure 8.26: Burner Settings – Flame Failures Allowed**

**Table 8.15: Flame Failures Allowed Ranges & Defaults**

Parameter	Default	Minimum	Maximum
Flame Failure Retries Allowed	0	0	2
Flame Failure 1 Hr Retry	OFF	OFF	ON

- i. **Air Adjustment:** Screens #12 and #13 allow the fan speed to be increased if required. The following is an explanation of the conditions under which these adjustments should be made.

BURNER SETTINGS 12 ▲  
Air Adjustment  
Min Fan Spd : 0 RPM ▼

BURNER SETTINGS 13 ▲  
Air Adjustment  
Max Fan Spd : 0 RPM ▼

**Figure 8.27: Burner Settings – Air Adjustment**

**Table 8.16: Air Adjustment Ranges & Defaults**

Parameter	Default	Minimum	Maximum
Air Adjustment Min Fan Speed	0 rpm	0 rpm	540 rpm
Air Adjustment Max Fan Speed	0 rpm	0 rpm	540 rpm

- j. **Minimum Fan Speed:** The minimum fan speed adjustment is intended to respond to potential issues with the loss of flame due to pressure fluctuations in the venting system. These concerns may be due to wind gusts on sidewall vented boilers or other sources of exhaust vent pressure spikes. The minimum fan speed may be adjusted in 30 RPM increments up to the minimum fan speed + 540 RPM. This feature should only be used to address nuisance flame failure or flapper valve failure lockout errors.
- k. **Maximum Fan Speed:** The maximum fan speed adjustment is intended to compensate for long exhaust vent runs if the boiler fails to keep up with the required load. Since the input rate may drop off slightly under increased resistance due to long exhaust vent installations, the boiler input may be incrementally increased to compensate. This adjustment should only be made if both of the following conditions are met:

- The boiler is not keeping up with the required load.
- The input rate has been determined to be below the rated input by timing the gas supply meter.

If these conditions are not met, contact your Peerless® Representative for assistance.

- l. **Alarm Mode:** The alarm mode allows the installing contractor to set the menu to the mode appropriate for the installation. The default setting is “Stand Alone” in which the alarm contacts (Terminals #31 & #32) simply close if an alarm condition exists. The PFC-460 has no design provisions that allow it to be included in a common venting system.

## ⚠ DANGER

**The PFC-460 cannot be vented into a common vent with other boilers. There are no provisions to prevent backflow through the heat exchanger. Severe personal injury, death or major property damage will occur.**

BURNER SETTINGS 14 ▲  
Alarm Mode :  
Stand Alone

**Figure 8.28: Burner Settings – Alarm Mode**

### 4. Central Heating (CH) Settings

CH settings manage the boiler temperature and circulators for the central heating load. Although the menu items that follow are factory set, by default, to values that can operate in any installation, they can be adjusted to maximize the efficiency of this product. The boiler can be configured to operate with a fixed setpoint or using outdoor reset to vary the boiler target temperature according to the load implied by the outdoor temperature.

- a. **Setpoint Operation:** When using a setpoint strategy, the boiler targets a fixed setpoint which is set in the User Menu on the *PUREFIRE*® control. As the boiler supply (outlet) temperature approaches this target, the burner begins to modulate the fuel input, reducing the output rate of the boiler. If the boiler reaches a temperature of 9°F (5°C) above the setpoint before the heat demand ends, the burner will shut down. If the heat demand continues and the boiler temperature drops 9°F (5°C) below the setpoint, the burner will restart.
- b. **Outdoor Reset Operation:** Outdoor reset strategies are ideal for condensing boilers for two reasons:
  - Heat distribution units, such as radiators, radiant floors and copper baseboard are sized to deliver the heat required on the coldest day at a set temperature. For the remainder of the heating season, the maximum output is not required, so the distribution can be set to a cooler temperature.
  - Condensing boilers, like the *PUREFIRE*®, are designed to withstand acidic condensate and therefore can be operated at as low a temperature that is reasonable. At lower temperatures [below 120°F (49°C) return temperature], these boilers condense more and are more efficient.
- c. **CH Modes:** The CH modes allow the operator to change the way the boiler operates to satisfy central heating demands.

```

CH SETTINGS 1
CH Mode : 0
Indoor Thermostat ▼

```

Figure 8.29: CH Settings – CH Modes

Table 8.17: CH Modes

Mode	Display	Target Temperature	Action when Terminals #1 & #2 Closed
0	Indoor Thermostat	Fixed Setpoint	Call for Central Heating
1	Indoor Thermostat with OD Reset	Outdoor Reset Calculation	Call for Central Heating
2	Permanent Demand & OD Reset	Outdoor Reset Calculation	18°F (10°C) Target Setback
3	Permanent Demand	Fixed Setpoint	18°F (10°C) Target Setback
4	0-10 V Input to Modulate Setpoint	External Analog (0-10 VDC) Input of Setpoint	No Effect

- **Mode 0, Indoor Thermostat:** This is the default mode in which the boiler responds to a demand from an indoor thermostat or zone control panel at terminals #1 and #2 in the *PUREFIRE*® control panel. The control targets a fixed setpoint and as the boiler water temperature approaches the target, the control begins to reduce the fuel input. This mode doesn't require an outdoor sensor.

- **Mode 1, Indoor Thermostat with Outdoor Reset:** When operating in this mode, the control uses the outdoor temperature and installer selected data to calculate a target boiler water temperature. A detailed description of outdoor reset is presented later in this section.
- **Mode 2, Permanent Demand and Outdoor Reset:** In this mode, the boiler operates to maintain a supply (header) temperature calculated by the outdoor reset algorithm. The boiler operates independently of any room thermostats. This is useful in buildings with many zones which operate on independent thermostats to prevent the boost function (described later in this text) from increasing the target temperature due to a long sustained call for central heat resulting from overlapping individual calls.
- **Mode 3, Permanent Demand:** This mode is similar to Full Outdoor Reset except that the control targets a fixed setpoint instead of a calculated setpoint based on the outdoor temperature. Again, the boiler control operates independently of input from room thermostats. If a switch between terminals #1 and #2 is closed, the target temperature will be set back by 18°F (10°C).
- **Mode 4, 0-10V Input to Modulate Setpoint:** This allows the boiler supply target to be set by an external analog 0-10 volt signal. The input for this signal is at terminals #15 & #16. A call for heat will be generated by a signal of 1.5 VDC or higher. The setpoint for an input voltage between 1.5 and 2.0 VDC will result in a boiler setpoint of 68°F (20°C). An input voltage of 10 VDC will result in a setpoint of 195°F (91°F).
- **Setback:** If a switch is closed across terminals #1 & #2, a setback of 18°F (10°C) is applied to the calculated target temperature. This feature is useful in a building (such as an office building) that is unoccupied during certain times. A switch or timer can be used to set back the boiler target temperature during unoccupied periods.

- d. **Pump Purge Time:** The installer can define the length of time that the circulators operate after the end of call for heat. The CH and General circulator post purge time can be set independently. The following chart shows the range and default values for both of these pumps.

```

CH SETTINGS 2 ▲
CH Pump
Post Purge Time 1 min ▼
CH SETTINGS 3 ▲
General Circulator
Post Purge Time 1 min ▼

```

Figure 8.30: CH Settings – Pump Purge Time

Table 8.18: Pump Purge Time Ranges & Defaults

Circulating Pump	Minimum	Default	Maximum
Central Heating (CH)	0	1 minute	60 minutes
General	0	1 minute	60 minutes

- e. **Outdoor Reset:** Since heating loads are typically lower when the outdoor temperature rises, outdoor reset lets the installer reduce the boiler target temperature as the outdoor temperature increases. As mentioned above, this increases the efficiency of the boiler. This is especially true with condensing boilers because it helps to recover the heat from the water vapor which, in conventional boilers, carries valuable energy out with the exhaust.
- f. **System Type Presets:** For convenience, the *PUREFIRE*® boiler control provides preset values for the outdoor reset parameters based on the system type. Table 8.19 shows the values that are applied when different system preset types are selected. If the system type, "User Defined" is chosen the outdoor reset definition values may be adjusted. If changes are made to the boiler design or mild weather boiler temperatures, the system type is automatically switched to, "User Defined".

- g. **Warm Weather Shutdown:** If the boiler is set to operate in CH Mode 1 or 2, the *PUREFIRE*® control is set by default to prevent the boiler from operating to satisfy a central heat demand if the outdoor temperature is above 70°F (21°C). This value can be adjusted using the values shown below.



**Figure 8.31: CH Settings – Warm Weather Shutdown**

**Table 8.20: Warm Weather Shutdown Range & Default**


Parameter	Minimum	Default	Maximum
Warm Weather Shutdown	35°F (-18°C)	70°F (21°C)	100°F (38°C)

**Table 8.19: System Type Presets**

System Type	Temperatures	
	Boiler Design	Mild Weather Boiler
1. Finned Tube Baseboard	180	140
2. Hydro Air Unit	190	140
3. Cast Iron Radiator	160	120
4. Cast Iron Baseboard	150	110
5. Low Mass Radiant	140	70
6. High Mass Radiant	120	70
7. user Defined (Default)	180	70

If the installer prefers to use custom values for the outdoor reset parameters, the following provides guidance.

- h. **Design Point:** The design point is defined by the **outdoor design temperature** and the **boiler design temperature**.
- i. **Boiler Design Temperature:** The boiler design temperature is the temperature at which the boiler is designed to operate in order to meet the load. Copper finned tube radiators are typically rated at 180°F (82°C). The Table 8.21 shows typical boiler design temperatures for different types of head distribution units.
- j. **Outdoor Design Temperature:** The heat loss for the structure is determined by considering the coldest sustained outdoor temperature that is expected at the site location. For a detailed list of outdoor design temperatures by state, refer to the H-22 heat loss calculation guide published by AHRI.



**Figure 8.34: Outdoor Reset Operation**

CH SETTINGS	6 ▲
Reset Curve Design	
Boiler	180 °F
Outdoor	0 °F ▼

Figure 8.32: CH Settings – Reset Curve Design

Table 8.21: Reset Curve Design Ranges & Defaults

Parameter	Minimum	Default	Maximum
Boiler Design Temp.	61°F (16°C)	180°F (82°C)	195°F (91°C)
Outdoor Design Temp.	-40°F (-40°C)	0°F (-18°C)	70°F (21°C)

- k. **Mild Weather Point:** The mild weather point is defined by the mild weather outdoor temperature and the mild weather boiler temperature.

CH SETTINGS	7 ▲
R. Curve Mild Weather	
Boiler	70 °F
Outdoor	70 °F ▼

Figure 8.33: CH Settings – Reset Curve Mild Weather

- l. **Mild Weather Boiler Temperature:** This is the minimum temperature that the boiler will target to satisfy a CH demand. In radiant floor design, this temperature can be set very low. However, avoid setting the temperature too low in systems with limited radiator surface and in lower floors with open stairways that can allow heat to migrate up to higher floors.
- m. **Mild Weather Outdoor Temperature:** This temperature is the highest outdoor temperature at which the boiler is expected to run. The default value for this is 70 which equals the default warm weather shutdown value.

Table 8.22: Reset Curve Mild Weather Ranges & Defaults

Parameter	Minimum	Default	Maximum
Mild Weather Boiler Temp.	36°F (2°C)	70°F (21°C)	160°F (71°C)
Mild Weather Outdoor Temp.	36°F (2°C)	70°F (21°C)	85°F (29°C)

The example in Figure 8.32 shows an outdoor temperature of 0°F (-18°C) which corresponds to the value for Springfield, Massachusetts. The boiler temperature is shown at 160°F (71°C) to meet the load as determined by the system designers. The mild weather point is at an outdoor temperature of 70°F (21°C) and a boiler temperature of about 85°F (29°C). When the outdoor temperature is 32°F (0°C), the boiler will target 130°F (54°C).

- n. **Boiler Limits:** The boiler limits are available to limit the minimum and maximum temperature that the boiler can target. Note that these limits will override the values set in the outdoor reset design and mild weather outdoor reset parameters.

CH SETTINGS	8 ▲
Reset Curve	
Boiler Min	OFF
Boiler Max	195 °F ▼

Figure 8.34: CH Settings – Reset Curve Min/Max

- o. **Boiler Min:** The boiler will not target a temperature lower than what is chosen in this menu screen. The default for this is, “Off” since low temperatures will not affect the boiler. However, it may be useful in installations that require a minimum temperature to operate (like a fan coil unit that will not allow a fan to operate below a certain temperature).
- p. **Boiler Max:** The boiler will not target a temperature higher than that chosen in this menu. This can be useful to prevent damage due to high temperatures in temperature sensitive situations such as radiant floors.

Table 8.23: Reset Curve Min/Max Ranges & Defaults

Parameter	Minimum	Default	Maximum
Boiler Minimum	“Off” or 40°F (4°C)	OFF	180°F (82°C)
Boiler Maximum	81°F (27°C)	195°F (91°C)	195°F (91°C)

- q. **Boost:** The boost function is designed to compensate for a system that is not meeting the required load. If there is a constant call for central heat for the length of time specified, the target temperature will be increased by the temperature value selected. The boiler will never target a temperature higher than that specified by the boiler max. parameter.

CH SETTINGS	9 ▲
Boost Function	
Temp	18 °F
Time	20 min ▼

Figure 8.35: CH Settings – Temperature Boost

There are several reasons why the boost function may or may not be implemented.

- In buildings which have many zones, there may seldom be a period when none of the zones is calling for heat. In this case, the boiler will very often be operating at the temperature selected by the “boiler max.” parameter, and much of the advantage of a condensing boiler may be lost. Therefore, it may be better to use CH Mode 2, “Permanent Demand and Outdoor Reset” in these situations. In this mode, the boost function is not applied therefore the boiler will continue to run at the temperature calculated by the outdoor reset algorithm.
- Programmable thermostats can give a building owner the ability to set back the thermostat significantly during unoccupied periods. After an aggressive setback, it may take the boiler a significant amount of time to recover. However, this may lead to the boiler frequently operating at higher temperatures, where it is less efficient. Before using setback thermostats, the building owner should be made aware that aggressive setbacks of 10°F (6°C) or more may not have the desired effect.
- If the outdoor reset parameters are set for design conditions at a certain outdoor design temperature, and the outdoor temperature drops below that temperature for a significant amount of time causing cold indoor temperatures, the boost function can allow the boiler to target temperatures up to the boiler maximum to satisfy the load.



**Table 8.24: Temperature Boost Ranges & Defaults**

Parameter	Minimum	Default	Maximum
Boost Temperature	0°F (0°C)	18°F (10°C)	36°F (20°C)
Boost Time	1 minute	20 minutes	60 minutes

- r. **Anti-Cycling Time:** This function allows the installer to set the minimum amount of time that the boiler can be off on setpoint before recycling. If the supply temperature drops by a value higher than Tdiff, the boiler will ignore the minimum off time and resume operation. If excessive cycling occurs due to cycling of the thermostat or zone relay, then the operation of these items should be examined.

CH SETTINGS	1 0 ▲
Anti-Cycling	
Time	3 min
Tdiff	30 ° F ▼

**Figure 8.36: CH Settings – Anti-Cycling**

**Table 8.25: Anti-Cycling Ranges & Defaults**

Parameter	Minimum	Default	Maximum
Anti-Cycling Time	0 minutes	3 minutes	15 minutes
Anti-Cycling Tdiff	20°F (11°C)	30°F (17°C)	40°F (22°C)

- s. **System Response Time:** To modify the reaction time of the system for a CH demand, the I-value parameter can be changed. The following chart shows the range of values with descriptions of the corresponding response speed.

CH SETTINGS	1 1 ▲
System Response	
Medium	
I-Value:	60 ▼

**Figure 8.37: CH Settings – System Response**

**Table 8.26: System Response Range & Default**

I-Value	Response Time Description
15-20	Very Fast
25-40	Fast
45-80 (Default=60)	Medium
85-110	Slow
115-120	Very Slow

Increase this value to reduce cycling in systems with smaller zones. Decrease this value for a more aggressive reaction to CH loads. This parameter affects only the CH response time, a similar parameter is available in the DHW Settings menu.

- t. **Maximum Allowable CH Rate:** If the boiler is sized primarily for a DHW load that is significantly higher than the CH load, this value can be decreased to limit the input rate of the boiler for central heating. The following chart shows the effective input values for various modulation percentages. As an example, if the DHW load is 460 MBH and the CH load is 310 MBH, set the “Max Allowable CH Rate” to 60%.

CH SETTINGS	1 2 ▲
Max Allowable	
CH Rate:	100 %

**Figure 8.38: CH Settings – Maximum CH Rate**

**Table 8.27: Maximum CH Rate Range & Default**

% Modulation	Input Rate per Burner
	PFC-460 Btu/hr
50%	230
60%	276
70%	322
80%	368
90%	414
100%	460

## 5. Domestic Hot Water (DHW) Settings

DHW settings manage the boiler temperature and circulators for the domestic water heating load. The boiler can be configured to operate without a domestic hot water load, with an indirect-fired hot water tank which incorporates a conventional thermostat, or with an indirect-fired hot water tank equipped with a water tank temperature sensor (PB#54157). The configuration using the optional tank temperature sensor allows the control to maximize the efficiency of the system by limiting the input rate to recover from standby losses.

- a. **Domestic Hot Water Modes:** This menu is used to change the control response to calls for DHW.

DHW SETTINGS	1
DHW Mode:	MODE: 2
DHW Tank	
with Thermostat	▼

**Figure 8.39: DHW Settings – DHW Modes**

**Table 8.28: DHW Modes**

Mode	Display	Input to Terminals #5 & #6
0	No DHW	None Required
1	DHW Tank with Sensor	NTC Thermistor Temperature Input
2	DHW Tank with Thermostat	Dry Contacts from DHW Thermostat

- Mode 0, No DHW:** Mode 0 indicates that there is no DHW load. The DHW pump outputs will be deactivated and the control will not respond to any signals at terminals #5 & #6.
- Mode 1, DHW Tank with Sensor:** Mode 1 is used with a temperature sensor input from the DHW tank. The optional sensor (PB #54157) transmits the tank temperature to the control which allows the control to determine the most efficient boiler operation to address the heat demand.

When this mode is chosen, the DHW Boiler Temperature and the DHW Tank Temperature setpoint values are available on the User Menu. The control will modulate the burner input based on feedback from the boiler supply temperature sensor. Therefore, if the tank temperature meets its setpoint before the boiler supply is close to its setpoint, the boiler may shut down while still in high fire. If this occurs often, lowering the DHW boiler supply setpoint will help to initiate modulation sooner.

Mode 1 can also decrease operating costs by assuring that the boiler operates at its minimum firing rate to address loads due only to standby losses.

- *Mode 2, DHW Tank with Thermostat:* This is the default DHW mode and it operates with a contact closure from a typical indirect tank thermostat. In this mode, the control targets the DHW boiler setpoint in the User Menu.
- b. *DHW Switch Time:* When the *PUREFIRE* boiler control is supervising the CH and DHW circulating pumps, it operates with a limited DHW priority strategy.

D H W   S E T T I N G S				2 ▲
C H	/	D H W	S w i t c h	
T i m e				3 0 m i n ▼

Figure 8.40: CH Settings – DHW Priority Switch Time

- If there is a CH demand from the thermostat when the DHW tank calls for heat, the control will immediately switch from CH to satisfy the DHW demand.
  - The control will continue to attempt to satisfy the DHW load until the selected switch time is reached.
  - Once the switch time is reached, the boiler will switch back to the CH demand.
  - If either the CH or DHW demand is satisfied, the boiler will then focus on satisfying the remaining load.
- If there is a CH demand during a call for DHW, the boiler will continue satisfying the tank load until the switch time is reached.
  - After that it will alternate loads at the end of each switch time until one of the loads is satisfied.
  - Then again, it will focus on the remaining call for heat.

Table 8.29: DHW Priority Switch Time Range & Default

Parameter	Minimum	Default	Maximum
CH/DHW Switch Time	5 minutes	30 minutes	60 minutes

- c. *DHW Heat Dump:* Scientists at Brookhaven National Laboratories have performed experiments which suggest that diverting heat from the boiler into an indirect storage tank at the end of each cycle improves the overall efficiency of the heating system. The heat dump function is designed to take advantage of this principal.

D H W   S E T T I N G S				3 ▲
D H W	H e a t	D u m p :		O F F
M a x	T i m e :			1 m i n
M i n	D i f f :			5 ° F ▼

Figure 8.41: DHW Settings – Heat Dump

- At the end of a heating cycle, when the CH demand is satisfied, the control switches off the CH circulating pump and turns on the DHW pump for the **Max Time** period.
- If the temperature difference between the supply and return of the boiler drops lower than the **Min Diff** value, the pumps shut down.

Table 8.30: DHW Heat Dump Ranges & Defaults

Parameter	Minimum	Default	Maximum
DHW Heat Dump	OFF	OFF	ON
Maximum Time	0 minutes	1 minute	60 minutes
Minimum Difference	0°F (0°C)	5°F (3°C)	10°F (6°C)

- d. *System Response Time:* The system response time works identically for DHW demands as it does for CH demands. These values are designed to allow independent modification of the response time for CH and DHW loads. For small DHW loads, the I-Value can be increased. For large DHW loads, this value can be decreased. If the burner doesn't modulate when it satisfies a DHW load, this value should be increased.

D H W   S E T T I N G S				4 ▲
S y s t e m	R e s p o n s e			
M e d i u m	I - V a l u e :			6 0 ▼

Figure 8.42: DHW Settings – Response Time

- e. *Maximum Allowable DHW Rate:* If the boiler is sized primarily for a CH load that is significantly higher than the DHW load, this value can be decreased to limit the input rate of the boiler for domestic hot water.

D H W   S E T T I N G S				5 ▲
M a x	A l l o w a b l e			
D H W	R a t e :			1 0 0 %

Figure 8.43: DHW Settings – Maximum DHW Rate

#### 6. Service Notification

The *PUREFIRE* boiler control gives installers several options to notify building owners when boiler service should be performed. The first screen that appears, after choosing Service Notification, is Reset Notifications. Pressing select resets the hours and cycles to "0".

The default for this optional feature is, "OFF". However, if it is enabled, the installer can choose the number of hours, the number of cycles or the date when, "SERVICE" appears on the LCD menu screens.

The following chart shows the range and default values for the Service Notification feature.

If desired, the installer can select a specific date for the Service Notification. Simply press the “Select” key when viewing the “Notification on:” date screen. Use the “▼” and “▲” keys to set the value. Pressing “Select” activates the next date parameter.




Figure 8.44: Service Notification

Table 8.31: Service Notification Ranges & Defaults

Notification On	Minimum	Default	Maximum
	OFF	OFF	ON
Hours	0	4,000	8,000
Cycles	0	50,000	20,000

## 7. System Test

System Test settings allow the installer or service person to operate each burner manually at its maximum, minimum and ignition rates. The following outlines the system test operation.

### a. Burner Only:

- Eliminate all heat demands to the boiler by disconnecting the CH thermostat from terminals #1 & #2 and disconnecting the DHW sensor or thermostat from terminals #5 & #6.



Figure 8.45: System Test Menu

- Use the “▼” and “▲” keys to position the arrow at the desired power setting.
- Press select to activate System Test. The burner will ignite and then operate at the selected input rate until “Off” is selected from the System Test menu or for 1 hour. The burner may cycle off on limit if the input rate exceeds the heating load.

### b. Pump For CH/DHW:

- This function can be used to check the function of the CH and DHW circulating pump outputs.
- While in “Standby”, choose the desired pump output from the Installer Menu, System Test screen on the display.
- The pump terminals should be activated. If the pumps don’t appear to be operating, check the voltage on the pump output terminals.

### c. Multiple Boiler Systems:

- These selections may also be used in a multiple boiler, cascade system when testing a dependent burner.
- In multiple boiler systems, these pumps are to be connected to the master boiler in the cascade. Therefore, when a dependent boiler is being tested, there will not likely be sufficient heating load to run the boiler for very long.
- In this case. Choose “Pump For CH” or “Pump for DHW” from the System Test menu on the display of the managing boiler in the system before running the dependent boilers.

## 8. Sequence (Managing Burner Display Only)

### NOTICE

The following features are non-functional for the PFC-460.

Adjustments in the sequence menu affect the sequence of burner operation. The first six parameters will stop and start burners as follows:

- On a call for heat (either CH or DHW) the 1st burner will start. The 1st burner can be either the managing or dependent burner based on the **Rotation Interval** chosen.
- After the 1st burner is activated, the 2nd burner will come on if all three of the following conditions are met:
  - Supply Temperature < Target Temperature – **Start Burner Differential**
  - 1st Burner Input Rate > **Next Burner Start Rate**
  - Start Delay Time** has elapsed (Time from when both prior parameters are met)
- The 2nd burner will be deactivated if the following conditions are met:
  - Supply Temperature > Target Temperature + **Stop Burner Differential**
  - Both Burner Input Rates < **Next Burner Stop Rate**
  - Stop Delay Time** has elapsed (Time from when both prior parameters are met)
- Calculated Setpoint Max Offset Up/Down:** The target supply temperature of both burners are adjusted if the system supply temperature is above or below the targeted value. For example, if the system supply target temperature is 150°F, each burner will target this temperature. However, if they approach their individual target temperature before the system supply approaches its target, a temperature offset is applied. This offset is calculated based on the **Calculated Setpoint Max** offset up. Similarly,



Table 8.32: Sequence Menu, Ranges &amp; Defaults

Menu Screen	Ranges & Defaults		
	Minimum	Default	Maximum
S E Q U E N C E 1 S t a r t   D e l a y   T i m e : 2   m i n ▼	1 Minute	2 Minutes	15 Minutes
S E Q U E N C E 2 S t o p   D e l a y   T i m e : 2   m i n ▼	1 Minute	2 Minutes	15 Minutes
S E Q U E N C E 3 S t a r t   B u r n e r   D i f f : 9 ° F ▼	1°F (0.6°C)	9°F (5°C)	23°F (13°C)
S E Q U E N C E 4 ▲ S t o p   B u r n e r   D i f f : 1 8 ° F ▼	1°F (0.6°C)	18°F (10°C)	45°F (25°C)
S E Q U E N C E 5 ▲ C a l c u l a t e d   S e t p o i n t M a x   o f f s e t   u p : 3 6 ° F ▼	0°F (0°C)	18°F (10°C)	36°F (20°C)
S E Q U E N C E 7 ▲ C a l c u l a t e d   S e t p o i n t M a x   o f f s e t   d o w n : 9 ° F ▼	0°F (0°C)	9°F (5°C)	36°F (20°C)
S E Q U E N C E 8 ▲ N e x t   B u r n e r S t a r t   R a t e : 5 0 % ▼	40%	50%	95%
S E Q U E N C E 9 ▲ N e x t   B u r n e r S t o p   R a t e : 9 % ▼	5%	9%	40%
S E Q U E N C E 1 0 ▲ R o t a t i o n   I n t e r v a l 5 D a y s ▼	0 Days (No Rotation)	5 Days	30 Days

if the system target is above its target a calculated negative offset based on the **Calculated Setpoint Max offset down** is applied. The maximum increased setpoint temperature is 195°F (91°C).

## E. DEFAULTS

1. **Factory Defaults – Restore:** By pressing the “Select” key while in the “Factory Defaults” screen. All factory settings will be restored on the control.



Figure 8.46: Restore Factory Defaults Screen

2. **Site Defaults – Save:** To save the current settings as “Site Defaults,” press the “Select” key while in the following menu.



Figure 8.47: Save Site Defaults Screen

3. **Site Defaults – Reset:** To restore the “Site Defaults,” press the “Select” key while in the following menu.



Figure 8.48: Restore Site Defaults Screen

## F. MULTIPLE BOILERS

### NOTICE

**Before selecting cascade operation, connect the System sensor to terminals #7 & #8. Failure to do this will result in a blinking screen warning as covered in Section 10.D.**

1. **PUREFIRE®** boiler controls can operate together to control up to 16 boilers for one central heat or domestic hot water demand. Only the addition of a system sensor (54156) is required to provide this operation.
2. **Overview:**
  - a. **Master Boiler:** In a multiple boiler system, a boiler designated as the “Master” boiler controls the function of the boiler system.
    - Attached to a system sensor which monitors the system water temperature.
    - Can also be connected to an outdoor sensor (54112), included with each boiler, as well as an optional DHW sensor (54157) or a standard DHW thermostat.

- Determines which boiler operates first (lead) and when to bring on additional boilers.
- Determines the setpoint temperature of individual boilers.
- Shuts down all boilers in the system if the LWCO contacts are opened.

- b. **Dependent Boilers:** The “dependent” boilers operate at the setpoint temperature that the Master boiler specifies.

- Maintain all of their own safety parameters such as safety limit, vent temperature limit, and freeze protection.
- Control their own general circulator that is energized whenever there is a call for either Central Heat or Domestic Hot Water.
- Shuts down the individual boiler if the dependent boiler LWCO contacts are opened.

### 3. System Piping & Wiring:

- a. Multiple boilers with multiple zones with zone valves.
  - Figure 8.49 shows a typical system which uses a CH circulator, a DHW circulator and zone valves to distribute the heating load to the building.
  - A three zone valve control panel (not included) controls circulation to individual zones.

### NOTICE

**The central heating (CH) circulator and the domestic hot water (DHW) circulator must be sized in accordance with good Engineering practices based on the required flow and pressure drop of the system. Failure to do so may result in system performance problems.**

- A call from any of the heating zones initiates a contact closure from the zone relay across the CH thermostat connections (terminals #1 & 2) on the master boiler. This initiates ignition of the “lead” boiler and its general pump. In addition, the CH circulator is energized.
- A call for domestic hot water can either be initiated internally by the control when it sees a drop in indirect tank temperature or by a tank thermostat. In either case, the lead boiler is ignited and its general pump operates. The DHW circulator is also energized.

- b. Multiple boilers with multiple zones with zone circulators.
  - Figure 8.50 shows a typical system which uses a circulator zone control panel to control the central heating zones.
  - The DHW circulator can be operated by the priority zone or can be connected directly to the boiler (as shown). In either case, the priority zone cannot be used for heating.
  - Again, a call for heat from any of the heating zones causes the master boiler to initiate operation of the lead boiler and its general circulator. The CH circulators are controlled by the zone control relay panel.




Figure 8.49: Multiple Boiler (Cascade) Piping / Electrical Connections for Systems with Zone Valves




Figure 8.50: Multiple Boiler (Cascade) Piping / Electrical Connections for Systems with Zone Circulators

- A DHW call results in the operation of the lead boiler and its general pump. The DHW pump is also energized.
- Wiring for a typical circulator zone relay is shown in Figure 7.4.

## 4. Setting up Multiple Boiler Operation:


### a. Setting the Boiler Address:

- Press the “Menu” and “Select” keys simultaneously for 5 seconds to enter the Installer Menu.
- Find screen #2, Boiler Address. Use the “▼” key to scroll down to “Burner Settings” on the menu.
- Pressing “Select” will cause the Boiler Address value to blink. Use the “▼” or “▲” key to change the value.
- The master boiler will be designated as Boiler Address: 1.
- All dependent boilers must have sequential boiler address settings as shown on the following table.

**Table 8.33: Cascade Addresses and Sensor Functions**

Boiler Operation	Cascade Address	System Sensor	Outdoor Sensor	DHW Sensor
Stand-alone Boiler	0	Not Active	Active	Active
Boiler #1 Master	1	Active	Active	Active
Boiler #2 Dependent	2	Not Active	Not Active	Not Active
Boiler #3 Dependent	3	Not Active	Not Active	Not Active
↓	↓	↓	↓	↓
Boiler #16 Dependent	16	Not Active	Not Active	Not Active

- Once a boiler is designated as a dependent boiler, the display will show the individual boiler supply temperature and its status.



**Figure 8.51: Cascade Link Connection & Switch Setting**


- The master boiler will display the system temperature and the overall status of the cascade system.
- By pressing the “▼” or “▲” key the operator can view the master boiler status.

### b. Connecting the Cascade Links – PFC-460.

- Re-attach the User Interface Display.
- Connect wires from terminals #11 & #12 between all boilers in the system.

## 5. Cascade Operation:

- When a call for Central Heat (CH) or Domestic Hot Water (DHW) is present, the Master boiler chooses which boiler will lead based on the Cascade Rotation Interval.



MULTIPLE BOILER CASCADE LINK WIRING: PFC-460

**Figure 8.52: Interconnection of Cascade Link Wires**

- b. Before starting the Lead boiler, the Master control will first check to be sure that the System temperature is lower than the System Setpoint + Stop Boiler Differential.
- c. After a Trial For Ignition (TFI), the lead boiler will modulate its input rate to meet the heat demand.
- d. Any time that a boiler is started the Cascade Start Delay Time will be initiated and no boiler will be allowed to start before this time elapses. This is to allow time for the system to stabilize before bringing on an additional boiler.
- e. After the delay time has elapsed, one of the following conditions must be met before starting the next boiler:
  - The System Temperature must be lower than the Set Point minus the Cascade Start Boiler Differential temperature, or
  - The input rate of all boilers operating must be higher than the Next Boiler Start Rate.
- f. After operation of the second boiler is initiated, the Cascade Start Delay Time must elapse before bringing on additional boilers. Again, in order to initiate operation of additional boilers one of the same conditions must be met.
- g. When the boiler system approaches its Setpoint, the boilers will reduce input rates at approximately equal values. When the input rates of all of the operating boilers fall below the Next Boiler Stop Rate, the master control will shut down the last boiler that started after the Cascade Stop Delay Time has elapsed.
- h. The Calculated Setpoint Max Offset Up and Calculated Setpoint Max Offset Down are applied to individual boilers in multiple boiler cascade operation.
  - These temperature offset values are used to change the response of individual boilers to the system setpoint.
  - Increasing these values will cause the system to react more quickly, but may result in frequent cycling.
  - Decreasing these values will cause the system to react more slowly to achieve the setpoint.
  - By increasing the Calculated Setpoint Max Offset Up value, the Master boiler will offset individual boiler setpoints temperature by a larger amount in order to achieve the system setpoint.
  - By increasing the Calculated Setpoint Max Offset Down value, the boilers will decrease the boiler setpoints by a larger amount to achieve the system setpoint.

- i. The Rotation Interval is the frequency at which the Master Boiler will change the Lead boiler in the sequence.

- For example, if the Rotation Interval is set to 4 days and there are 4 boilers operating together, the following chart shows the operating sequence over the next 25 days.

**Table 8.34: Rotation Interval Sequence**

Days of Operation	Start/Stop Sequence
1-5	1-2-3-4
6-10	2-3-4-1
11-15	3-4-1-2
16-20	4-1-2-3
21-25	1-2-3-4

6. **Multiple Boilers – Boost & Warm Weather Shutdown (WWSD):**
  - a. To use the Boost function with multiple boilers, the parameters on the master boiler are used. Boost parameters set on dependent boilers have no effect on the system operation.
  - b. Similarly, the WWSD Temperature set on the master boiler will prevent any boilers from operating for a CH demand when the outdoor temperature is above this value.
7. **Multiple Boilers – Ramp Delay:**
  - a. The ramp delay feature can be set on each individual boiler.
  - b. However, it is important to note that since the dependent boilers treat DHW demands as a CH call, the ramp delay will take effect even when the DHW tank calls.
8. **Multiple Boilers – Anti-Cycling:**
  - a. The Anti-Cycling feature is active on all boilers unless it is disabled.
  - b. This will prevent dependent boilers from operating within the prescribed time limit. However, it will only prevent the boiler from cycling on its own limit. Repetitive calls from the master boiler will result in cycling.
9. **Multiple Boilers – DHW Operation:**
  - a. Since the DHW tank sensor or thermostat is connected only to the Master boiler, this is the only boiler that will receive the DHW demand.
  - b. The master control will start boilers as necessary to meet the demand.
  - c. Boilers with a boiler address of 2 or higher will automatically be switched to DHW Mode 0 (No DHW).

# 9. START-UP PROCEDURE

## A. GENERAL

1. Confirm that all water, gas and electricity are turned off.
2. Verify that the water piping, venting & air intake piping, gas piping, electrical wiring and electrical components are installed in accordance with the manufacturer's instructions. Be sure that the boiler is installed in accordance with this manual and good engineering practice.
3. Turn on electricity and gas to the boiler.
4. Fill the condensate tanks with water to within 2-3" of the top of the tanks to prevent flue gasses from escaping the vent during initial start-up.

## B. CHECK WATER PIPING

1. Fill the boiler and system with water, making certain to purge all air from the system. Open each vent in the system until all air is released and water begins to be discharged. Then close the vent.
2. The pressure reducing valve on the fill line will typically allow the system to be pressurized to 12 PSI. Consult manufacturers instructions for operation of the valve and expansion tank.
3. Check joints and fittings throughout the system and repair as required.

## C. CHECK GAS PIPING

1. Turn on gas to the boiler using the shut-off valve upstream of the sediment trap. Be sure that the gas shut-off valve supplied with the boiler is in the closed position.
2. Connect a manometer to the gas supply upstream of the supplied manual gas valve.
3. Confirm that the gas supply pressure to the boiler is between the minimum and maximum values as indicated in Section 5.
4. If a supply pressure check is required, isolate the boiler and gas valve before performing the pressure test. If the supply pressure is too high or too low, contact the fuel gas supplier.
5. Double check the fuel gas supply pressure after the boiler is running to be sure that the pressure doesn't drop off significantly under operation.

## D. CHECK OPERATION

1. Either disconnect or set CH thermostat and DHW tank thermostat to assure that no call for heat.
2. Turn on electricity and all manual gas valves to the boiler. Check to see if the LCD display is lit. The control will display, "Standby".

3. Refer to Section 8, Boiler Control, to set up the control for the desired operation.
4. Use the ignition sequence, Figure 8.1 to follow the light off and shutdown sequences and to assist in troubleshooting operation problems. If the boiler does not function properly, consult Section 10, Troubleshooting.
5. After starting the boiler, be certain that all controls are working properly and that the combustion is properly set up. Paragraphs 6 and 7 below provide instructions on how to do this.
6. Check that the boiler will shut down when the supply water temperature reaches the control setpoint.
  - a. Note the boiler setpoint by accessing the User Menu, Status Display. Press the "Menu" key on the keypad. Choose Status by pressing the "Select Key". Use the "▼" and "▲" key to scroll through the CH and DHW setpoints. Refer to Appendix B for the User Menu.
  - b. Use the System Test Mode in the Installer Menu to choose High Input Power.
  - c. Monitor the boiler temperature on the temperature gauge (supplied for field mounting) and on the Status display.
  - d. The boiler should shut down at the boiler setpoint plus 10°F (5.6°C). If it does not shut down turn off the boiler and contact your PB Heat representative.
7. Check combustion readings in the boiler vent pipe.
  - a. For PVC or CPVC exhaust vent pipe only: Drill and tap a 1/8" NPT threaded hole in the boiler vent pipe within 12" (305 mm) of the boiler vent connection. (21/64" Drill and 1/8" NPT Pipe Tap recommended) This is to be used as the combustion test port for the combustion analyzer. See Figure 9.1.



Figure 9.1: Drill and Tap Combustion Test Port

## START-UP PROCEDURE

- b. Polypropylene vent systems from Centrotherm or Duravent should include a sample port fitting connected to the exhaust outlet port of the boiler. In this case, this fitting is to be used as the test port for the combustion analyzer.
- c. Using a combustion analyzer with the capability to read carbon dioxide (CO<sub>2</sub>) and carbon monoxide (CO), place the probe into the combustion test port. See Figure 9.2.
- d. Manually set the boiler to Maximum power by entering the System Test Mode. See Appendix C, Installer Menu.



**Figure 9.2: Insert Analyzer Test Probe into Test Port**

- Verify that the fan speed indicated is within 30 rpm of the maximum power fan speed in Table 12.3.
  - Verify that the CO and CO<sub>2</sub> emissions are within the parameters specified in Table 5.4.
- e. Manually set the boiler to Low Power by entering the System Test Mode. See Appendix C, Installer Menu.

- Verify that the fan speed indicated is within 100 rpm of the Low Power fan speed listed in Table 12.3.
  - Verify that the CO and CO<sub>2</sub> emissions are within the parameters specified in Table 5.4.
- f. If the values in either of these instances falls outside the parameters listed in Table 5.4, turn off the boiler and contact your PB Heat representative. For best results, the value should be set for the middle of the range (9% for Natural Gas and 10% for LP Gas).
  - g. Be sure to set the System Test mode to Off so that the boiler will modulate correctly in accordance with the load.
  - h. After removing the analysis probe from the vent pipe, insert a PVC or Stainless Steel pipe plug into the test port. See Figure 9.3.
  - i. Record the combustion readings on the “Start-up Combustion Record” in Appendix D. It is very important to record all of the information requested on the sheet for follow up and troubleshooting.



**Figure 9.3: Insert Pipe Plug into Test Port**

## NOTICE

**To prevent moisture damage to control and blower:**

**During Boiler operation verify that there are no water leaks from any fittings on the boiler header and that all vent connections are water tight and properly assembled.**



**E. LIGHTING & OPERATING PROCEDURES**

### FOR YOUR SAFETY READ BEFORE OPERATING


**WARNING:** If you do not follow these instructions exactly, a fire or explosion may result causing property damage, personal injury, or loss of life.

- A. This appliance does not have a pilot. It is equipped with an ignition device which automatically lights the burner. Do not try to light the burner by hand.
  - B. **BEFORE OPERATING** smell all around the appliance area for gas. Be sure to smell next to the floor because some gas is heavier than air and will settle on the floor.
    - If you cannot reach your gas supplier, call the fire department.
  - C. Use only your hand to turn the gas control valve. Never use tools. If the handle will not turn by hand, don't try to repair it, call a qualified service technician. Force or attempted repair may result in a fire or explosion.
  - D. Do not use this appliance if any part has been under water. Immediately call a qualified service technician to inspect the appliance and to replace any part of the control system and any gas control which has been under water.
- WHAT TO DO IF YOU DO SMELL GAS**
- Do not try to light any appliance.
  - Do not touch any electric switch; do not use any phone in your building.
  - Immediately call your gas supplier from a neighbor's phone. Follow the gas supplier's instructions.


### OPERATING INSTRUCTIONS

1. **STOP!** Read the safety information above.
2. Set the thermostat to lowest setting.
3. Turn off all electric power to the appliance.
4. This appliance is equipped with an ignition device which automatically lights the burner. Do not try to light the burner by hand.
5. Turn gas shutoff valve(s) clockwise ⤵ to "OFF". Handle will be perpendicular to pipe, do not force.
6. Wait five (5) minutes to clear out any gas. Then smell for gas, including near the floor. If you smell gas, **STOP!** Follow "B" in the safety information above on this label. If you don't smell gas, go to the next step.
7. Turn gas shutoff valve(s) counterclockwise ⤴ to "ON". Handle will be in line with the pipe.
8. Turn on all electric power to appliance.
9. Set thermostat to desired setting.
10. If the appliance will not operate, follow the instructions "To Turn Off Gas To Appliance" and call your service technician or gas supplier.

Single Burner Models



Gas Control Knob(s)  
(shown in the  
"OFF" position)



Two Burner Models (Commercial)

### TO TURN OFF GAS TO APPLIANCE

1. Set the thermostat to lowest setting.
2. Turn off all electric power to the appliance if service is to be performed.
3. Turn the gas shutoff valve(s) clockwise ⤵ "OFF". Handle will be perpendicular to pipe, do not force.

(PF)

9512 REV1

Figure 9.4: Lighting &amp; Operating Instructions

# 10. TROUBLESHOOTING

## A. HARDWARE ERROR- NO COMM MAIN BOARD

If the display shows “NO COMM MAIN BOARD”, Contact your PB Heat representative or PB Heat Technical Support.

## B. BLOCKING ERRORS

1. When a Blocking Error occurs the controller will display a message and an “E” error code on the display module.
2. These error messages and several suggested corrective actions are included in Table 10.1.
3. Certain Blocking Errors will, if uncorrected, become Locking Errors as described in Paragraph B.

## C. LOCKING ERRORS

1. When a Locking Error occurs the controller will display a message and an “A” error code on the display module.
2. These error messages and several suggested corrective actions are included in Table 10.2.
3. Press the reset key to clear the Locking Error and resume operation. Be sure to observe the operation of the unit to prevent a recurrence of the fault.
4. The PUREFIRE® control will retry for ignition after one hour of being in a lockout condition. This will prevent lockout errors from resulting in “No Heat” calls if there is an intermittent problem.
5. The PUREFIRE® control logs the flame signal four times during the last 2 seconds of the ignition period. This is to aid in troubleshooting ignition errors. A flame signal below 2.8 micro amps at the end of this period will result in a lockout. If the flame signal is low, remove the flame sensor and igniter for inspection. Also, be sure that the lead to the flame sensor is not grounded.

### ⚠ WARNING

When servicing or replacing any components of this boiler be certain that:

- The gas is off.
- All electrical power is disconnected.

### ⚠ DANGER

When servicing or replacing components that are in direct contact with the boiler water, be certain that:

- There is no pressure in the boiler. (Pull the release on the relief valve. Do not depend on the pressure gauge reading).
- The boiler water is not hot.
- The electrical power is off.

### ⚠ WARNING

Do not use this appliance if any part has been under water. Improper or dangerous operation may result. Contact a qualified service technician immediately to inspect the boiler and to repair or replace any part of the boiler which has been under water.

### ⚠ CAUTION


If overheating occurs or the gas supply fails to shut off, do not turn off electrical power to the circulating pump. This may aggravate the problem and increase the likelihood of boiler damage. Instead, shut off the gas supply to the boiler at the gas service valve.

### ⚠ CAUTION

Label all wires prior to disconnection when servicing controls. Wiring errors may cause improper and dangerous operation. Verify proper operation after servicing.

### ⚠ CAUTION

The convenience outlet is powered even when the service switch is off.



NOTE: BOILER CONTROL HAS A REPLACEABLE FUSE. BE SURE TO CHECK FUSE IF INSPECTION FINDS A LINE VOLTAGE POWER ISSUE.

Figure 10.1

## D. ERROR MESSAGES IN A CASCADE SYSTEM

See paragraph D and the Cascade section of Appendix A for further information on how errors are displayed when using a Cascade System.

**Table 10.1: Control Board Blocking Error Codes (automatic reset):**

"E" CODE	Error Display	Internal No.	Error Description	Corrective Action
E01	SUPPLY SENSOR NOT CONNECTED	51	Supply sensor not connected.	Check harness and sensor.
E02	RETURN SENSOR NOT CONNECTED	52	Return sensor not connected.	Check harness and sensor.
E04	DHW SENSOR NOT CONNECTED	55	DHW sensor not connected.	If DHW Mode is not intended to be set to Mode 1, DHW Store with Sensor, then change it to the appropriate Mode. Check harness and sensor.
E05	STACK SENSOR OPEN	57	Flue gas sensor open.	Check vent temperature, harness, sensor.
E11	SUPPLY SENSOR SHORT	59	Supply sensor shorted.	Check harness and sensor.
E12	RETURN SENSOR SHORT	60	Return sensor shorted.	Check harness and sensor.
E13	STACK SENSOR SHORT	65	Flue gas sensor shorted.	Check harness and sensor.
E14	DHW SENSOR SHORT	63	DHW sensor shorted.	Check harness and sensor.
E19	COMMUNICATION ERROR E2PROM ERROR	0	Problems reading from or writing to e2prom.	Contact PB Heat Representative.
E20	FALSE FLAME DETECTED	35	False Flame detected.	Verify no flame in observation port. Check Sensor.
E21	HOT/NEUTRAL REVERSED	44	Phase and neutral of mains supply are reversed.	Verify polarity of incoming wiring. Check boiler ground and harness.
E22	POOR GROUND	43	No earth connected or internal hardware error.	Check boiler ground and harness.
E23	NET FREQUENCY ERROR	45	Mains frequency differs more than 2% from 60Hz.	Contact electrical provider and/or an electrician.
E24	POOR GROUND	46	Earth connection is not ok.	Check boiler ground and harness.
E25	BLOCKED VENT	38	Blocked Vent Switch is Open	This error applies to PF-200, PF-210, PF-300 and PF-399 models. Check for blocked vent pipe or blocked heat exchanger. Check switch and tubing to switch.
E26	BLOCKED CONDENSATE DRAIN	41	Condensate drain blocked.	Check condensate tanks, hoses, condensate switch, and harness.
E30	HIGH STACK TEMPERATURE	39	Flue gas sensor above max flue setpoint + diff.	If flue pipe is hot, check flue temperature and compare to values shown Table 8.5. Check for proper gas input and combustion readings, check for dirty heat exchanger. If flue pipe is not hot, check flue sensor and harness.
E31	LOW WATER	36	Water level is too low.	Check boiler water level, low water cut-off, harness. If a LWCO is not used, a jumper should be placed between terminals #9 and #10, LWCO Contact.
E32	HIGH RETURN TEMP	40	Return temperature is above 194°F (90°C).	Check for reversed supply and return piping or pump installed backwards.
E42	INTERNAL HDWRE ERROR	47	Internal hardware error.	See Note*
E45	INTERNAL HDWRE ERROR	31	Internal hardware error.	See Note*
E46	INTERNAL HDWRE ERROR	32	Internal hardware error.	See Note*
E47	INTERNAL HDWRE ERROR	33	Internal hardware error.	See Note*
E48	INTERNAL HDWRE ERROR	34	Internal hardware error.	See Note*
E51	RESET BUTTON ERROR PLEASE WAIT.	66		Wait five minutes. If error does not clear, replace control.

\* If persistent blocking errors, E42 through E48, occur, systematically disconnect all wires that were not supplied by the factory with the exception of the power supply (CH T'stat, DHW T'stat, LWCO and Pumps). If the error code goes away, determine if there may be feedback from one of the circuits. If the Error occurs with all of these disconnected, there is likely a problem with the control board.

Table 10.2: Control Board Locking Error Codes (manual reset):

"A" CODE	Error Display	Internal No.	Error Description	Corrective Action
A01	IGNITION ERROR	1	Three consecutive unsuccessful ignition attempts.	<ol style="list-style-type: none"> <li>1. Watch the igniter through the observation window.</li> <li>2. If no spark is present, check the spark electrode for the proper 3/16" gap. (DO NOT try to bend the electrodes if they have been operating for an extended period. Heat causes them to become brittle and they may break.) <ul style="list-style-type: none"> <li>• Remove any corrosion from the spark electrode with abrasive.</li> </ul> </li> <li>3. If a spark is present but no flame results, check the gas supply to the boiler. <ul style="list-style-type: none"> <li>• Check for either high or low gas pressure. (See table 5.3)</li> <li>• Try restricting the air to the burner by covering the air inlet vanes on the swirl plate. If ignition results, check the combustion products using a combustion analyzer. If the combustion is out of tolerance (see table 5.4) contact your PB Heat representative.</li> </ul> </li> <li>4. If a flame is present but the burner drops out, check the flame sensor log in the Installer Menu (Meas. 1, 2, 3, 4). <ul style="list-style-type: none"> <li>• The flame Meas. Values are the flame signal at 1/2 second intervals during the last 2 seconds of trial for ignition after the spark has stopped but before proving ignition. If Meas. 4 is below 3.1 <math>\mu</math>A, the control will not stay running.</li> <li>• If the flame signal is too low, remove the burner plate and check the distance between the sensor and the burner. If it is greater than 1/4" the flame sensor should be replaced and the new sensor should be bent to be sure it is between 1/8" and 3/16" from the burner. (DO NOT try to bend the electrode if it has been operating for an extended period. Heat will cause it to become brittle and it may break.)</li> </ul> </li> <li>5. Determine if the gas valve is opening by monitoring gas pressure. Also, listen for the solenoid valve to pull in. <ul style="list-style-type: none"> <li>• If the gas valve is not opening, check to be sure the harness connections are not faulty.</li> <li>• If the harness appears correct, replace the gas valve. (Before beginning this replacement, connect the gas valve to be sure it operates correctly before removing the old one. If it doesn't operate correctly, the existing valve may not be bad.)</li> </ul> </li> </ol>
A02	FLAME FAILURE	24	Three consecutive flame failures during one demand.	<ol style="list-style-type: none"> <li>1. If boiler sparks, lights briefly and then goes out: <ol style="list-style-type: none"> <li>a. Disconnect the flame sensor cable and then retry ignition.</li> <li>b. If the flame stays lit, allow the boiler to run for several minutes and then reattach the cable.</li> <li>c. If the problem persists, remove the flame sensor and inspect the burner through the sensor opening. If metal fibers are protruding from the burner, use a blunt probe to move the fibers away from the sensor.</li> <li>d. If the problem is still present, replace the flame sensor.</li> </ol> </li> <li>2. If the unit locks out on flame failure during normal operation: <ol style="list-style-type: none"> <li>a. Check gas pressure at the inlet to the gas valve (See figure 5.2) while the boiler is operating.</li> <li>b. Check the flame signal in the Installer Menu under Status. This will also show the total number of flame failures. If the flame signal reads less than 2.8 <math>\mu</math>A, clean the sensor and igniter. Be sure that the wiring harness is fully seated at the control.</li> <li>c. If the flame signal is consistently low, check the signal with the sensor disconnected. If the flame signal improves, replace the flame sensor.</li> </ol> </li> </ol>
A03	OVERHEAT LIMIT OPEN	18	High Temperature Limit Open (Set Temperature 205°F)	<ol style="list-style-type: none"> <li>1. Check CH, DHW, General Pump Operation</li> <li>2. Assure that there is adequate flow through the boiler by checking the status menu and assuring less than 40°F temperature rise across the boiler.</li> <li>3. Check the resistance reading through the High Limit Temperature Switch when the boiler is cool (below 160°F). If the switch shows an open circuit, replace the switch.</li> </ol>

\*\* If persistent locking errors, A04 through A18, occur, systematically disconnect all wires that were not supplied by the factory with the exception of the power supply (CH T'stat, DHW T'stat, LWCO and Pumps). If the error code goes away, determine if there may be feedback from one of the circuits. If the Error occurs with all of these disconnected, there is likely a problem with the control board.

**Table 10.2 (cont'd): Control Board Locking Error Codes (manual reset):**

"A" CODE	Error Display	Internal No.	Error Description	Corrective Action
A04	INTERNAL ERROR GAS VALVE RELAY	5	Gas Valve Relay Problems.	See Note**
A05	INTERNAL ERROR SAFETY RELAY	6	Safety Relay Problems.	See Note**
A09	INTERNAL SOFTWARE ERR RAM ERROR	9	Internal Software Error.	See Note**
A10	COMMUNICATION ERROR E2PROM ERROR	12	No Communication with E2prom.	See Note**
A12	SOFTWARE OUT OF DATE E2PROM OUT OF DATE	10	Contents of e2prom is not up-to-date.	See Note**
A13	INTERNAL ERROR	13	Internal Software Error	See Note**
A14	INTERNAL ERROR	14	Internal Software Error	See Note**
A15	INTERNAL ERROR	16	Internal Software Error	See Note**
A16	INTERNAL ERROR	22	Internal Software Error	See Note**
A18	INTERNAL ERROR	19	Internal Software Error	See Note**
A19	FALSE FLAME DETECTED AFTER SHUTDOWN	20	Flame signal detected 10 sec. after closing the gas valve.	1. Check flame sensor to be sure there is no short to ground. 2. Check igniter to be sure there is not short to ground. 3. This could also indicate that the gas valve doesn't close completely.
A20	FALSE FLAME DETECTED BEFORE IGNITION	21	Flame signal detected before gas valve opened.	4. Check flame sensor to be sure there is no short to ground. Check igniter to be sure there is not short to ground.
A23	FLOW_SW_NOT_OPEN	25	CH flow switch not working.	1. Check for electrical continuity between wires connected to terminals 9 & 10 from field supplied flow switch. 2. If there is continuity when the circulator is off, there is a system piping or circulator control problem.
A24	FLOW_SW_NOT_CLOSED	26	CH flow switch not working.	1. Check for electrical continuity between wires connected to terminals 9 & 10 from the field supplied flow switch. 2. If there is no continuity, check to be sure the circulator is working. 3. If the circulator is working correctly, check the flow switch.
A32	FAN NOT RUNNING	23	Internal Software Error.	
A33	FAN SPEED ERROR	8	Fan speed detected is more than 300 rpm different from targeted value for more than 60 seconds.	1. Does the fan run at full speed after resetting the control? • Check connections in the 4-wire connection to the blower. • If the connections are correct, there may be a problem with the harness or the main control board. 2. Does the fan run normally after resetting the control? • Under System Test in the Installer Menu on the display, choose "Low Power". If the boiler locks out when targeting low power, check the voltage to the fan. • If the voltage is within specification, replace the blower. 3. Does the fan not run after pressing reset? • Check for signs of moisture around the fan motor. Check for evidence of recirculating flue gas (corrosion inside the cabinet). • DO NOT replace the blower without determining the cause of the failure. Otherwise, the failure may reoccur.
A50	RETURN HIGHER THAN SUPPLY	11	Boiler return water temperature higher than supply for more than 5 ignition attempts.	1. Check system piping. Assure that the water is entering the return connection and exiting the supply connection. 2. Compare the supply thermistor reading to the temperature gauge, if they don't agree, replace the supply thermistor.

\*\* If persistent locking errors, A04 through A18, occur, systematically disconnect all wires that were not supplied by the factory with the exception of the power supply (CH T'stat, DHW T'stat, LWCO and Pumps). If the error code goes away, determine if there may be feedback from one of the circuits. If the Error occurs with all of these disconnected, there is likely a problem with the control board.

**E. WARNING ERRORS**

The *PUREFIRE*® boiler control will display a blinking screen under several conditions. Several of these conditions provide the error information directly on the screen. Table 10.3 shows sensor errors and corresponding corrective actions.

**1. Outdoor Sensor Error:**

- a. If the boiler control is set to a CH mode which requires an outdoor sensor (CH Mode 1 or 2) and the sensor is not connected, the screen will blink. Pressing the "Reset" key will display the following error screen.

```

1 6 : 3 6
Warning Number # W00
Outdoor Sensor Open
Warning
  
```

In this condition, the control will continue to operate, targeting the Boiler Design Temperature as a fixed value. To operate at the maximum efficiency while the sensor circuit is being repaired or replaced, use CH Mode 7, Internal Reset.

- b. If the boiler control is set to a CH mode in which an outdoor sensor is required and the sensor is shorted, the screen will blink. Pressing the "Reset" key will display the following error screen.

```

1 6 : 3 6
Warning Number # W01
Outdoor Sensor Short
Warning
  
```

- c. The boiler will not operate until this problem is corrected.
- d. If the Outdoor Sensor is open, the status screen will read -40°F and the boiler will run at the boiler design temperature as set up in the installer menu.

```

STATUS
System      1 6 0 ° F
Vent        1 3 0 ° F
Outdoor     - 4 0 ° F
  
```

**2. DHW Sensor Error:**

- a. If the boiler control is set to operate on DHW Mode 1 (DHW Sensor), and there is no sensor connected the boiler will not satisfy a DHW call for heat.
- b. The display will blink and the DHW temperature will read 14°F if there is an open circuit at the sensor terminals. Pressing the "Reset" key will display the following error screen.
- c. This will also occur if the wires are not properly connected.

```

1 6 : 3 6
Warning Number # W02
DHW Sensor Open
Warning
  
```

- d. If there is a short at the DHW sensor terminals and the DHW mode is set to Mode 1, the DHW system will not operate. The display will blink to indicate a warning error. Pressing the "Reset" key will display the following error screen.

```

1 6 : 3 6
Warning Number # W03
DHW Sensor Shorted
Warning
  
```

**3. Flue Sensor Error:**

- a. If the control senses that the flue temperature does not rise to above 50°F after ignition, and either the supply water temperature rises above 120°F or the return water temperature rises above 80°F, the control will display "Flue Sensor Hold" and run at 1% Input.

```

1 6 : 3 6
FLUE SENSOR HOLD
1 % Input      1 6 3 ° F
  
```

- b. If "Flue Sensor Hold" continues for an extended period of time, the display will blink. Pressing the "Reset" key will display the following error screen.

```

1 6 : 3 6
Warning Number # W04
Flue Sensor open
Warning
  
```

**4. Cascade – System Sensor Error:**

- a. In a multiple boiler cascade installation a system sensor must be connected to the system. If no system sensor is connected or if there is an open circuit the display will blink and the display screen will read as follows:

```

1 6 : 3 6
CASCADE STANDBY
SYSTEM SENSOR FAIL
01 Boilers On 14 ° F
  
```

- b. If there is a short circuit in the system sensor wiring, the display screen will read similarly. Notice that a short circuit results in a high system temperature reading (244°F).

```

1 6 : 3 6
CASCADE STANDBY
SYSTEM SENSOR FAIL
01 Boilers On 244 ° F
  
```

- c. Under either of these conditions, the Master boiler will set the supply setpoints of all of the boilers to match the system setpoint. It will continue to bring on and shut off boilers based on the thermostat demand (terminals #1 and #2) and the Boiler Start/Stop Delay Time.

**5. Cascade – Loss of Communication with Master Boiler:**

- a. If a dependent boiler is not communicating with the Master boiler, and it is set as address 2-16, the screen will blink with the following information displayed.






```

1 6 : 3 6
STANDBY
NO COMM CASCADE
1 2 0 ° F
  
```

- b. The boiler that is not communicating with the Master boiler will not run until the problem is corrected. Other boilers connected to the Master boiler and the Master boiler itself will operate normally.



Table 10.3: Control Board Warning Error Codes

"W" CODE	Error Display	Error Description	Corrective Action
#W00	 <p>Blinking Screen – Press "Reset" key to view this message</p>	Outdoor Sensor Open	<ol style="list-style-type: none"> <li>1) Check to see if the Outdoor Sensor is connected.</li> <li>2) Check wiring connectons to outdoor sensor.</li> <li>3) Remove wires from terminals #3 and #4 on the boiler and check the resistance between them. If the reading shows an open circuit there is an broken/disconnected wire or sensor. Reconnect or replace.</li> </ol>
#W01	 <p>Blinking Screen – Press "Reset" key to view this message</p>	Outdoor Sensor Shorted	<ol style="list-style-type: none"> <li>1) Check wiring connection to Outdoor Sensor.</li> <li>2) Remove the wires from terminals #3 and #4 on the boiler and check the resistance between them. <ul style="list-style-type: none"> <li>• If this reading is below 3000 <math>\Omega</math> check the reading at the sensor.</li> <li>• If the reading is the same at the sensor, replace the sensor.</li> <li>• If the reading is higher at the sensor, replace the wiring.</li> </ul> </li> </ol>
#W02	 <p>Blinking Screen – Press "Reset" key to view this message</p>	DHW Sensor Open	<ol style="list-style-type: none"> <li>1) Be sure the optional DHW Sensor (54157) is connected.</li> <li>2) Remove the wires from terminals #5 and #6 on the boiler and check the resistance between them. <ol style="list-style-type: none"> <li>a. If the resistance is above 10 k <math>\Omega</math>, check the resistance at the sensor.</li> <li>b. If the reading at the sensor is the same, replace the sensor.</li> <li>c. If the reading at the sensor is lower, replace the wiring.</li> </ol> </li> </ol>
#W03	 <p>Blinking Screen – Press "Reset" key to view this message</p>	DHW Sensor Shorted	<ol style="list-style-type: none"> <li>1) Check wiring connection to DHW Sensor.</li> <li>2) Remove the wires from terminals #5 and #6 on the boiler and check the resistance between them. <ol style="list-style-type: none"> <li>a. If this reading is below 1000 <math>\Omega</math>, check the reading at the sensor</li> <li>b. If the reading is the same at the sensor, replace the sensor.</li> <li>c. If the reading is higher at the sensor, replace the wiring.</li> </ol> </li> </ol>
#W04		Flue Sensor Open	<ol style="list-style-type: none"> <li>1) Check wiring connection to flue sensor.</li> <li>2) Compare sensor resistance to Figure 8.3. If resistance value is incorrect, replace sensor.</li> </ol>

**F. DELAYED IGNITION (HARD LIGHT-OFF)**

There are several factors that may cause a delayed ignition in the *PureFire*® boiler due to a pressure pulse at light-off.

**Table 10.4: Hard Light-Off Conditions:**


Condition	Condition Description	Corrective Action
LOW GAS PRESSURE	If the gas inlet pressure at the inlet port on the gas valve is below 3.5" of water for Natural Gas and 8" of water for LP at 100% of modulation, a hard light-off may occur. This may be due to slow introduction of the gas/air mixture at light-off.	Be sure that the incoming gas pressure does not drop below 3.5" of water for Natural Gas and 8" of water for LP at any point in its operation. Be sure to check while other appliances are in operation.
HIGH GAS PRESSURE	If the gas inlet pressure at the inlet port on the gas valve is above 13.5" of water when the boiler is off, a delayed ignition may occur. This is because the gas pressure may inhibit the smooth opening of the gas valve at light-off.	Be sure that the incoming gas pressure is not above 13.5" while the boiler is off or at any time during its operation.
INCORRECT AIR/FUEL RATIO	Using a suitable combustion analyzer, check the products of combustion to assure correct combustion air/fuel ratio as described in Section 9.D.7 of these instructions.	If the vent CO <sub>2</sub> or CO is out of range in accordance with table 5.4 in these instructions, please contact your PB Heat representative.
SPARK GAP IS TOO LARGE	If the spark gap between the ignition electrode and ground rod is too large, a delayed ignition may occur. This may be due to decreased spark energy of the larger spark.	If the boiler is natural gas-fired, the spark gap should be between 1/8" and 3/16". If the fuel is LP gas, the spark gap should be between 3/16" and 1/4".
SPARK GAP IS TOO SMALL	If the spark gap between the ignition electrode and ground rod is too small, a delayed ignition may occur. This may be due to a narrow ignition window from the small spark.	If the boiler is natural gas-fired, the spark gap should be between 1/8" and 3/16". If the fuel is LP gas, the spark gap should be between 3/16" and 1/4".
SPARK PLACEMENT	If the placement of the spark is the wrong distance from the burner a delayed ignition may occur. The distance of the spark from the burner surface should be approximately 3/8". If the spark gap is farther away from the burner, a significant amount of combustible mixture may be introduced into the combustion chamber before ignition. This may result in a delayed ignition.	If the spark gap is more than 3/8" from the burner, replace the ignitor and assure that the spark is 3/8" or less.
WEAK SPARK	A weak spark at the gap between the ignition electrode and ground rod on the ignitor may be attributed to several problems. 1. Deterioration of the insulated spark wire 2. Dirt on the insulated portion of the spark electrode that may provide a path for spark energy to ground	1. Check the spark wire for wear or damage. Replace if necessary. 2. Check the porcelain insulation on the spark electrode for evidence of dirt. Clean the insulator if dirt is evident.

**G. BOILER FAILS TO RESPOND TO A CH CALL**

If the display screen shows "STANDBY" and does not respond when a thermostat call has been initiated, use the following procedure to check operation.

1. Enter the "Installer Menu" by pressing the "Menu/Return" key and the "Select" key simultaneously for 5 seconds.
2. Using the "▼" key move the cursor to "SYSTEM TEST" and press "Select".
3. Use the "▼" key again to move the cursor to "Low Power".
4. Press the "Menu/Return" key twice to return to the status screen.
5. If the boiler operates, return to "SYSTEM TEST" and select "OFF". If not, contact technical support.
6. Next, remove any wires from terminals #1 & #2 (CH Thermostat). See the illustration below.

7. Place a jumper in terminals #1 & #2, shown in Figure 10.2 below, to simulate a heating call.
8. If the boiler operates, there may be voltage feedback to the thermostat terminals from the source. Check for stray voltage or isolate the contacts.

**Figure 10.2: CH Thermostat Terminals**



# 11. MAINTENANCE

## WARNING

### Product Safety Information Refractory Ceramic Fiber Product

This appliance contains materials made from refractory ceramic fibers (RCF). Airborne RCF fibers, when inhaled, have been classified by the International Agency for Research on Cancer (IARC), as a possible carcinogen to humans. After the RCF materials have been exposed to temperatures above 1800°F, they can change into crystalline silica, which has been classified by the IARC as carcinogenic to humans. If particles become airborne during service or repair, inhalation of these particles may be hazardous to your health.

#### Avoid Breathing Fiber Particulates and Dust

Suppliers of RCF recommend the following precautions be taken when handling these materials:

#### Precautionary Measures:

Provide adequate ventilation.

Wear a NIOSH/MSHA approved respirator.

Wear long sleeved, loose fitting clothing and gloves to prevent skin contact.

Wear eye goggles.

Minimize airborne dust prior to handling and removal by water misting the material and avoiding unnecessary disturbance of materials.

Wash work clothes separately from others. Rinse washer thoroughly after use.

Discard RCF materials by sealing in an airtight plastic bag.

#### First Aid Procedures:

**Inhalation:** If breathing difficulty or irritation occurs, move to a location with fresh clean air.

Seek immediate medical attention if symptoms persist.

**Skin Contact:** Wash affected area gently with a mild soap and warm water. Seek immediate medical attention if irritation persists.

**Eye Contact:** Flush eyes with water for 15 minutes while holding eyelids apart. Do not rub eyes.

Seek immediate medical attention if irritation persists.

**Ingestion:** Drink 1 to 2 glasses of water. Do not induce vomiting. Seek immediate medical attention.

## A. GENERAL (WITH BOILER IN USE)

General boiler observation can be performed by the owner. If any potential problems are found, a qualified installer or service technician/agency must be notified.

1. Remove any combustible materials, gasoline and other flammable liquids and substances that generate flammable vapors from the area where the boiler is contained.
2. Observe general boiler conditions (unusual noises, vibrations, etc.)
3. Observe operating temperature and pressure on the combination gauge located in the supply piping on the left side of the boiler. Boiler pressure should never be higher than 5 psi below the rating shown on the safety relief valve (25 psig maximum for a 30 psig rating). Boiler temperature should never be higher than 240° F.
4. Check for water leaks in boiler and system piping.
5. Smell around the appliance area for gas. If you smell gas, follow the procedure listed in the Lighting Operating Instructions to shut down appliance in Section 9, Start-Up Procedure Part B.

## B. WEEKLY (WITH BOILER IN USE)

Flush float-type low-water cut-off (if used) to remove sediment from the float bowl as stated in the manufacturer's instructions.

## C. ANNUALLY (BEFORE START OF HEATING SEASON)

### CAUTION

**The following annual inspection must be performed by a qualified service technician.**

1. Check boiler room floor drains for proper functioning.
2. Check function of the safety relief valve by performing the following test:
  - a. Check valve piping to determine that it is properly installed and supported.
  - b. Check boiler operating temperature and pressure.
  - c. Lift the try lever on the safety relief valve to the full open position and hold it for at least five seconds or until clean water is discharged.
  - d. Release the try lever and allow the valve to close. If the valve leaks, operate the lever two or three times to clear the valve seat of foreign matter. It may take some time to determine if the valve has shut completely.
  - e. If the valve continues to leak, it must be replaced before the boiler is returned to operation.
  - f. Check that operating pressure and temperature have returned to normal.
  - g. Check again to confirm that valve has closed completely and is not leaking.

3. Test low-water cut-off (if used) as described by the manufacturer.
4. Test limit as described in Section 9, Part D, "Check Operation".
5. Test function of ignition system safety shut-off features as described in Section 9, Part D, "Check Operation".

### DANGER

**When servicing or replacing components, be absolutely certain that the following conditions are met:**

- Water, gas and electricity are off.
- The boiler is at room temperature.
- There is no pressure in the boiler.

### CAUTION

**The convenience outlet is powered even when the service switch is off.**

6. Remove the top/front jacket panel and inspect for any foreign debris that may have entered through air intake vent.
7. Inspect burner for deterioration. Replace if necessary.
8. With boiler in operation check that condensate is dripping from condensate tubing. Check for any restriction in condensate drain line.

## D. CONDENSATE CLEANING INSTRUCTIONS

1. Removal of Condensate Tanks.
  - a. Close manual gas shutoff valve on top of boiler and turn off power to the boiler by placing the boiler service switch to the off position.
  - b. Remove the front jacket panel.
  - c. Remove the wing nut securing the front tank and disconnect the tank from the upper right drain hose. (Some condensate may spill out of this port).
  - d. Remove the cap from the tank and position a container in front of the boiler and tilt the tank to drain condensate into the container.
  - e. Tank and lower hose may be removed by disconnecting the lower hose from the rear tank.
  - f. Clean tank and hose with water and inspect the rear tank for sediment in the lower connection port. The rear tank can be removed for cleaning if required by removing the wing nut and disconnecting the two float switch wire leads. NOTE: Special care must be taken when removing the hoses from the top of the rear tank. They must be held secure and do not pull hoses downward and away from their upper connections to the heat exchanger and vent adapter.
  - g. After cleaning, replace tanks and reconnect hoses and wire leads to float switch. Fill the front tank with water and check for any leaks at connections.
  - h. Replace the front jacket panel, open the manual gas valve and place the boiler service switch to the on position.

2. Before re-starting the *PUREFIRE*® boiler follow the steps below:
  - a. Reconnect the thermostat wires.
  - b. Open the manual gas shutoff valve and reset the thermostats.
  - c. Observe the boiler function to make sure you see a condensate flow.
  - d. If you do not observe a condensate flow, repeat the above procedure.
3. If the problem is not corrected at this point, it is possible that there is a material deposit problem. Follow the Coil Cleaning Instructions (Subsection 9E) below to dissolve deposits and clean the heat exchanger.

### **WARNING**

**It is extremely important to make sure there is no blockage in the exhaust vent. Failure to do so may result in serious personal injury or death.**

## **E. INSPECTION AND CLEANING OF COMBUSTION CHAMBER COILS**

Before beginning this procedure, you must have on hand the following items:

- a nylon or brass brush (not steel)
- “Rydlyme” (recommended for best results) (available online [www.rydlyme.com](http://www.rydlyme.com)) or “CLR” (available at most hardware stores)

1. Shut the boiler down and access the heat exchanger using the following steps:
  - a. Close the manual gas shutoff valve and wait for the unit to be cool to the touch.
  - b. Disconnect the condensate piping from the outside connections (not from the *PUREFIRE*® side) so the flow can be observed.
  - c. Disconnect compression nut on gas valve inlet and disconnect the gas valve electrical connector.
  - d. Remove the six 10 mm nuts from the burner plate assembly. Disconnect wire leads to the spark igniter and flame sensor. Disconnect two Molex plugs from blower motor.
  - e. Pull the entire burner plate towards you to access the heat exchanger coils.
  - f. Significant deposits may be caused by the recirculation of exhaust gasses, poor fuel quality or contamination of the air supply. Review Section 3, Venting & Air Inlet Piping, if deposits are evident.
2. Using a spray bottle filled with the recommended product “Rydlyme” or “CLR”, spray liberally on the coils, making sure the solution penetrates and funnels down through the condensate hose. If the condensate hose is blocked, let the chemical penetrate for at least 15 minutes or until it drains.

3. Use the nylon or brass brush (do not use steel) and scrub coils to remove any buildup, then vacuum the debris from the coils.
4. Spray coils with clear water, making sure to confine the spray to the area being cleaned (try to avoid wetting the back ceramic wall of the unit). Flush the combustion chamber with fresh water. At this point, the *PUREFIRE*® should be ready to power back up.
5. Reinstall the burner plate assembly using the following steps:
  - a. Inspect the inside of the heat exchanger for dirt and debris.
  - b. Install the burner plate assembly and replace the six 10 mm nuts.
  - c. Reconnect the wire leads to the spark igniter, flame sensor and gas valve. (Be sure that the spark igniter is connected to the lead with the large insulated connection boot.) Reconnect two Molex plugs on blower motor.
  - d. Connect the compression nut on the gas valve inlet and reattach the gas valve electrical connector.
  - e. Reset thermostats. **(IMPORTANT: BE SURE THAT THE VENT CONNECTION IS NOT BLOCKED.)**

### **WARNING**

**It is extremely important to check for leaks when reconnecting the gas valve. Failure to do so may result in severe personal injury, death or major property damage.**

- f. Turn the power to the *PUREFIRE*® on. Observe the display module to assure proper operation.
- g. Initiate a call for heat\*\* and observe the condensate flow.
- h. Reconnect the condensate piping to the drain connection.

**\*\*NOTE: When firing the boiler the first few times you may experience some fluttering of the gas burner that may result in a flame lockout. This is normal and will require you to recycle the unit until this clears up. This is caused by water still present in the combustion chamber.**

6. Inspect exhaust vent and air intake vents for proper support and joint integrity. Repair as necessary. Refer to Section 5, VENTING.

### **WARNING**

**Leaks in the vent system will cause products of combustion to enter structure (vent system operates under positive pressure).**

7. Inspect exhaust vent and air intake vent terminations for obstructions or corrosion. Corrosion is an indication of exhaust gas recirculation.

# 12. BOILER DIMENSIONS & RATINGS




Figure 12.1: Dimensional Drawing – PFC-460

Table 12.1: Boiler Dimensions

SERIES PEERLESS® PUREFIRE® DIMENSIONS (INCHES)											
Boiler Model	"A"	"B"	"C"	"D"	"E"	"F"	"G"	"H"	"J"	"K"	"L"
PFC-460	27-15/16"	17-3/16"	40-1/2"	1-1/2"	4"	3/4"	2-3/4"	5-1/4"	3-1/2"	5-3/4"	7-1/16"

Table 12.2: Boiler Ratings


SERIES PEERLESS® PUREFIRE® BOILER RATINGS					
Series Peerless® PUREFIRE®					
Boiler Model	Input (MBH)		Gross Output (MBH)	Net Rating (MBH)	Thermal Efficiency (%)
	Min.	Max.			
PFC-460	92	460	438	381	95.2

Table 12.3: Combustion Air Fan Speeds

SERIES PEERLESS® PUREFIRE® COMBUSTION AIR FAN SPEEDS				
Boiler Model	Input Rate	Fan Speed		
		Low Power	Ignition	High Power
PFC-460	460 MBH	1530	4110	6060

Table 12.4: Electrical Ratings

SERIES PEERLESS® PUREFIRE® ELECTRICAL RATINGS									
Boiler Model	Supply Voltage (-15%, +10%)	Frequency (±1.2 Hz)	Blower		Gas Valve		Pumps		Max Total Service Current to Boiler
			Voltage (VAC)	Current (Amps)	Voltage (VAC)	Current (Amps)	Voltage (VAC)	Max. Current (Amps)	
PFC-460	120 VAC	60 Hz	120	2.58	120	0.21	120	20.00	22.79

Table 12.5: PUREFIRE® Main Control Specifications

SERIES PEERLESS® PUREFIRE® MAIN CONTROL SPECIFICATIONS	
Power Supply	120 VAC Nominal (102-132 VAC); 60 Hertz (40-70 Hz) Phase Neutral
Fuse (5650)	3.15 Amp, 250 VAC
Blower Voltage	120 VAC
Gas Valve Voltage	120 VAC
Thermostat Contacts	24 VAC
DHW Contacts	24 VAC
Flame Current Limits	Minimum (running): 2.8 µA Minimum (ignition): 3.1 µA Maximum: 10 µA
Temperature Sensors	All PUREFIRE® NTC thermistors are 12kΩ @ 77°F (25°C). They operate on 5 VDC. Supply Sensor: 14°F (-10°C) to 244°F (118°C) Return Sensor : 14°F (-10°C) to 244°F (118°C) Flue Sensor: 50°F (10°C) to 280°F (138°C) Outdoor Sensor: -40°F (-40°C) to 185°F (85°C)
	<b>Optional Sensors</b> DHW Sensor: 14°F (-10°C) to 244°F (118°C) System Sensor : 14°F (-10°C) to 244°F (118°C)
Standards	Europe: CE EN298 North America: ANSI Z21.20 / CSA C22.2

# 13. REPAIR PARTS

Repair parts are available from your local PB Heat, LLC distributor or from Parts To Your Door at 1 (610) 916-5380 ([www.partstoyourdoor.com](http://www.partstoyourdoor.com)).

Note: Remember to include the boiler model number and serial number when ordering parts.




Figure 13.1: General Repair Parts – PFC-460

Table 13.1: General Repair Parts – PFC-460

	Description	Quantity Required	Stock Code
1	Panel, Jacket Front Door, with Ball Studs	1	54256
2	Lens for Jacket Front Door	1	54167
3	Display Module 852RT- PFC-460/1500	1	54735
4	Gasket for Display Bracket	1	54513
5	Bracket for Display Module	1	PF2007-1
6	Hex Nut, #6-32 with Lock washer (Local Hdwr Supply)	2	51553
7	Screw, #6-32 x 1/2" LG Phillips Head, (Local Hdwr Supply)	2	5449
8	Screw, #10 x 1/2" Lg. Hex Head, (Local Hdwr Supply)	4	99992
9	Cover Plate	1	PF6088
10	Cover Plate Gasket	1	54680
11	Jacket, Lower Front Panel	1	PF6051
12	Bulk Head Fitting for Condensate Hose	1	54140
13	Gasket for Bulk Head Fitting	1	54134
14	Leg Leveler	4	5429
15	Coupling, 1-1/2" NPT Brass – PF-460 (Local Hdwr Supply)	2	5551
16	Nipple, 1-1/2" NPT x 1/4" LG Brass – PF-460 (Local Hdwr Supply)	2	5550
17	Elbow, 1-1/2" NPT Brass – PF-460 (Local Hdwr Supply)	1	5553
18	Tee, 1-1/2" NPT Brass – PF-460 (Local Hdwr Supply)	1	5554
19	Nipple, 1-1/2" NPT x 3/8" Brass – PF-460 (Local Hdwr Supply)	2	5552
20	Bushing, 1-1/2" x 3/4" NPT Brass – PF-460 (Local Hdwr Supply)	1	5556
21	Shut-off Valve, 3/4" NPT Brass, (Local Hdwr Supply)	1	50764
22	Convenience Outlet	1	54136
23	Hex. Nut, #8-32 with Lockwasher, (Local Hdwr Supply)	4	51573
24	Control Module 852MT – PFC-460	1	54730
25	3.15Amp, 250V 5x20mm Slow-Blow Glass Fuse, Radio Shack-270-1067	1	5650
26	Rocker Switch - 20Amp	1	5701
27	Pump Isolation Relay Module Kit (Includes harness)	1	54610
28	10Amp, 125V 5x20mm Slow-Blow Glass Fuse, Radio Shack-270-152	4	—
29	Vent/Air Inlet Adapter – PFC-460	1	54294
30	Vent Adapter Gasket – PFC-460	1	54217
31	Screw #10 x 3/4" Long Phillips Pan Head	6	5611
32	Heat Exchanger Outlet Collar 4" PFC-460	1	5532
33	Condensate Neutralizer Assembly	1	54204
34	Condensate Receiver Assembly	1	54259
35	Blocked Vent Switch Kit - Include Items #36 & #37	1	54260
36	1/4" ID PVC Tubing x 12" Long	1	5697
37	90° Barbed Elbow - Polypropylene Adapter Fitting	1	5698
38	Gasket - Cover Plate	1	54141
39	Cover Plate for Thermal Temperature Switch	1	PF2021
40	High Temperature Limit Switch - Tasseron TSDS950 - 95C	1	54419
41	Supply/Return Sensor - 12 K $\Omega$ Tasseron TSD00BS	1	54418
42	Flue Sensor Grommet - EPDM	1	54291
43	Flue Sensor - 12 K $\Omega$ Tasseron TSD20B0	1	54209






Figure 13.2: Heat Exchanger/Burner Assembly Repair Parts – PFC-460

**Table 13.2: Heat Exchanger/Burner Assembly Repair Parts – PFC-460**

	Description	Quantity Required	Stock Code
1	Ignitor, with Gasket	1	4246
2	Sensor, with Gasket	1	54247
5	Premix Channel – PFC-460	1	54250
6	Gasket, Channel to Burner	1	54186
7	Burner – PFC-460	1	54264
9	Combustion Chamber Cover Plate, includes items #10-#12	1	54248
10	Gasket, Glass Rope	1	54188
11	Gasket, Rubber	1	54187
12	Insulation, Combustion Chamber Cover Plate	1	54255
15	Insulation, Target Wall	1	54185
16	Heat Exchanger – PFC-460	1	5530
17	Thermal Fuse	1	54466
18	Gasket, Blower to Channel	1	54122
19	Blower- PFC-460	1	55428
21	90° Flange Connection	1	5543
22	Dungs 057 Gas Valve	1	54429
23	Straight Flange Connection	1	5855
24	Gas Manifold- PFC-460	1	54681
25	High Gas Pressure Switch- Honeywell C6097B1028	1	50701
26	Low Gas Pressure Switch- Honeywell C6097A1012	1	50700



**Figure 13.3: Concentric Horizontal Vent Termination**



**Figure 13.5: Polypropylene Adapter**



**Figure 13.4: Concentric Vertical Vent Termination**

**Table 13.3: Optional Exhaust Vent Termination Kits**

Description	Stock Code
4" Concentric Sidewall Termination Kit (PolyPro 3PPS-HK)	54499
4" Concentric Vertical Termination Kit (PolyPro 4PPS-VK)	54501

**Table 13.4: Optional Polypropylene Exhaust System Adapters**

Description	Stock Code
4" Polypropylene Vent/Inlet Adapter (Innoflue ISAGL0404)	54633
4" Polypropylene Vent/Inlet Adapter (PolyPro 4PPS-AD)	54631

# APPENDIX A. STATUS SCREENS

## PureFire Condensing Boiler - Status Display

<div> PEERLESS  PUREFIRE  - - i n i t i a l i z i n g - -  Version [ x x x x ] </div>	<div>1 6 : 3 6</div> <div>1 6 0 ° F</div>	<p><b>Peerless PureFire Initialization Screen:</b> This screen is displayed when power is first supplied to the boiler. The software version, indicated by xxxx, indicates the version of the program for the interface module. This information should be noted if contacting PB Heat for technical support.</p>
<div> STANDBY </div>		<p><b>Status Display Screen:</b> Under normal conditions with no call for heat, the display on the user interface module will show that the boiler is in “STANDBY” mode. In addition, the current time, in 24 hour format, will be displayed in the upper right corner. The boiler supply temperature is shown in the lower right corner of the display.</p>

## Central Heating Demand

<div> CENTRAL HEATING  T r i a l   F o r   I g n i t i o n </div>	<div>1 6 : 3 6</div>	<p><b>Central Heating (CH) Trial for Ignition:</b> When a contact closure between terminal #1 &amp; #2 occurs, the control begins a trial for ignition. The display shows that the boiler demand is for central heating and indicates that a trial for ignition has been initiated. The Ignition cycle shown in Table 8.5 is identical for central heating and domestic hot water demand.</p>
<div> CENTRAL HEATING  1 0 0 % I n p u t </div>	<div>1 6 : 3 6</div> <div>1 6 0 ° F</div>	<p><b>Central Heating (CH) Demand:</b> When the burner is on, the display continues to show the demand type. On the lower left, the percentage of modulation is shown. This screen also shows the time, in 24 hour format, and the actual supply temperature as read by the supply sensor.</p>

## Domestic Hot Water Demand

<div> DOMESTIC HOT WATER  T r i a l   F o r   I g n i t i o n </div>	<div>1 6 : 3 6</div>	<p><b>Domestic Hot Water (DHW) Trial for Ignition:</b> Depending on the DHW mode, either a contact closure between terminals #5 and #6 or a drop in DHW temperature triggers a call for domestic hot water. Similarly to the CH demand, the display shows that the heat demand is for domestic hot water and that a trial for ignition has been initiated. The ignition cycle is shown in Table 8.5.</p>
<div> DOMESTIC HOT WATER  1 0 0 % I n p u t </div>	<div>1 6 : 3 6</div> <div>1 6 0 ° F</div>	<p><b>Domestic Hot Water (DHW) Demand:</b> When the burner is on, the display continues to show the DHW demand. On the lower left, the percentage of modulation is shown. This screen also shows the time, in 24 hour format, and the actual supply temperature as read by the supply sensor.</p>

## Supply at Setpoint

1 6 : 3 6  
S U P P L Y   A T   S E T P O I N T  
F a n   P o s t   P u r g e

**Supply at Setpoint - Fan Post Purge:** If the boiler supply temperature exceeds the desired target (either a setpoint or a target calculated by the heating curve) the display will indicate "SUPPLY AT SETPOINT" and show that the boiler has entered the post purge period. After the postpurge, the display will indicate that the boiler circulator (CH PUMP) is operating. The boiler circulator will continue to operate until the demand is satisfied.

1 6 : 3 6  
S U P P L Y   A T   S E T P O I N T  
C i r c u l a t o r   O N

## Special Demand Functions

1 6 : 3 6  
C E N T R A L   H E A T I N G  
F r e e z e   P r o t e c t i o n  
1 % I n p u t   1 6 0 ° F

**Freeze Protection:** If the supply or return temperature drops below the freeze protection setpoint the general pump and/or the CH pump are activated depending on pump mode. If the temperature continues to drop by more than 9°F (5°C) the burner fires at minimum power and continues until the return temperature increases by 18°F (10°C).

1 6 : 3 6  
D O M E S T I C   H O T   W A T E R  
S t o r e   W a r m   H o l d  
1 % I n p u t   1 6 0 ° F

**Store Warm Hold:** When using a DHW tank sensor, the PureFire boiler control can detect if the DHW heat demand is required only to overcome the heat loss and not a result of a hot water draw. In this instance, the burner will fire at low power (1%) and continue until the tank setpoint is satisfied.

## Ignition/Flame Failure Handling

1 6 : 3 6  
N O   I G N I T I O N  
F a n   P o s t   P u r g e

**Ignition Failure:** If control does not sense a flame at the end of the ignition period, the display will show "No Ignition" and the control will advance to the "Post Purge" period. The control will then repeat the Ignition Cycle. If there are three successive ignition failures, the control will lock out.

1 6 : 3 6  
F L A M E   F A I L U R E  
F a n   P o s t   P u r g e

**Flame Failure:** If the control senses a flame at the beginning of the "Burner On" period and then later loses the signal, a Flame Failure will result. This failure causes the control to advance to the "Post Purge" period. The control will then repeat the Ignition Cycle. If there are three successive flame failures the control will lock out.

1 6 : 3 6  
C E N T R A L   H E A T I N G  
I g n i t i o n   R e t r y

**Ignition Retry:** If the control recycles due to Ignition or Flame Failure, "Ignition Retry" will be shown below the text indicating the source of the heat demand.

1 6 : 3 6  
D O M E S T I C   H O T   W A T E R  
I g n i t i o n   R e t r y

## Error Handling

BLOCKING ERROR 1 6 : 3 6  
Fan Post Purge

**Blocking Error:** "Blocking Error" is displayed whenever a condition is reached that prevents the boiler from operating but will not result in a control lockout. Once the condition is corrected, the control will reset automatically. A list of blocking errors is included in Table 10.1.

BLOCKING ERROR 1 6 : 3 6  
#

LOCKOUT ERROR 1 6 : 3 6  
Fan Post Purge

**Lockout Error:** "Lockout Error" is displayed whenever a condition is reached that results in a control lockout. After the condition is corrected, the control requires the reset button to be pushed in order to resume operation. A list of lockout errors is included in Table 10.2.

LOCKOUT ERROR 1 6 : 3 6  
#

## Service Notification



SERVICE 1 6 : 3 6  
STANDBY

**Service Indicator:** Predetermined service intervals can be programmed into the control to prompt end users to call for routine service. This interval can be set to "TIME", "HRS" or "CYCLES" in the Installer Menu.



1 6 0 ° F

## Cascade (Multiple Boilers)

CASCADE STANDBY 1 6 : 3 6  
0 Boilers ON 1 6 0 ° F

**Status Display Screen (Master Cascade Boiler):** The Master Boiler in a multiple boiler Cascade System will display the status information for the system as default. "CASCADE STANDBY" appears on the screen instead of "STANDBY" and the number of boilers currently operating will show on the bottom line. The System Supply Temperature is shown in the lower right corner of the display. Pressing the  or  key shows information for the individual boiler.

STANDBY 1 6 : 3 6  
1 6 0 ° F

**Status Display Screen (Dependent Cascade Boiler):** Dependent boilers in a multiple boiler Cascade System will display only the status information for the individual boiler. This information for the Master Boiler can be displayed by pressing the  or  key.

## Cascade (Multiple Boilers) continued

```

CALL FOR HEAT          1 6 : 3 6
6 Boilers ON 140 ° F

```

```

DOMESTIC HOT WATER     1 6 : 3 6
1 Boiler ON 140 ° F

```

```

CALL FOR HEAT          1 6 : 3 6
75 % INPUT             140 ° F

```

```

CALL FOR HEAT          1 6 : 3 6
LOCKOUT ALARM BI 01
1 Boiler ON 140 ° F

```

```

LOCKOUT ALARM          1 6 : 3 6
#

```

**Call For Heat (Master Cascade Boiler):** The Master boiler will display "CALL FOR HEAT" if there is a central heating demand and "DOMESTIC HOT WATER" for a DHW demand. The number of boilers currently running is shown at the bottom of the screen in addition to the current System temperature.

**Call For Heat (Dependent Cascade Boiler):** Dependent boilers will show only "CALL FOR HEAT" if a demand is given from the Master boiler. The input percentage of modulation and the supply temperature for the individual boiler are shown at the bottom of the screen.

**Lockout Alarm (Master Cascade Boiler):** If any of the boilers (including the Master Boiler) in a cascade system fail in a lockout condition, the screen will show "LOCKOUT ALARM BI 0X" where "X" is the address of the boiler in Lockout. Press the Down Arrow to display the "Lockout Alarm #" screen below.

**Lockout Alarm:** "Lockout Alarm" is displayed on any boiler that has reached a condition that results in a control lockout. Pressing the reset key on the individual boiler will reset the Lockout error. A list of lockout errors is included in Table 10.2.



# APPENDIX B. USER MENU

## User Menu

```

M E N U
→ S t a t u s
  S e t t i n g s
  M e s s a g e s

```

The user menu is accessed by pressing the "Menu" key. Use the up/down arrow keys to identify the desired option. Then press the "Select" key to choose that option.

## Status

```

S T A T U S

C u r r e n t   S u p p l y
S e t p o i n t       1 6 0 ° F ▼

```

```

S T A T U S                               ▲
S y s t e m           1 6 0 ° F
V e n t               1 3 0 ° F
O u t d o o r         1 6 0 ° F ▼

```

```

S T A T U S                               ▲
S u p p l y           1 6 0 ° F
R e t u r n           1 3 0 ° F
D H W                 1 6 0 ° F ▼

```

```

S T A T U S                               ▲
G e n e r a l   C i r c .   O f f
C H   C i r c u l a t o r   O f f
D H W   C i r c u l a t o r   O f f

```

## Settings

```

S E T T I N G S
C e n t r a l   H e a t i n g
S e t p o i n t
O D   R E S E T   1 2 9 ° F ▼

```

**Range:** 50 °F to 189 °F **Default:** 160 °F  
 10 °C to 90.6 °C 71.1 °C  
 Displays OD Reset if the CH setpoint is controlled by a heating curve

```

S E T T I N G S                               ▲
D H W   B o i l e r   S e t p o i n t
1 8 0 ° F ▼

```

**Range:** 122 °F to 189 °F **Default:** 180 °F  
 50 °C to 90.6 °C 82.2 °C  
 Controls boiler supply setpoint for DHW call for heat.  
 This screen is only visible in DHW mode 1 & 2.

```

S E T T I N G S                               ▲
D H W   T a n k   S e t p o i n t
1 4 0 ° F ▼

```

**Range:** 50 °F to 158 °F **Default:** 120 °F  
 10 °C to 70 °C 48.9 °C  
 Controls DHW tank setpoint. This screen is only visible in DHW mode 1.

```

S E T T I N G S                               ▲
T i m e   &   D a t e
M o n d a y
1 0   M a y   2 0 0 8   1 6 : 0 2 ▼

```

```

S E T T I N G S                               ▲
T e m p e r a t u r e   U n i t s
F a h r e n h e i t   ° F ▼

```

**Range:** °F or °C **Default:** °F

## Messages

```

M E S S A G E S                               0 1 ▲
l o c k o u t   X X X       X X X M I N
e r r o r   d e s c r i p t i o n
e r r o r   d e s c r i p t i o n ▼

```

This option displays the last Block Message and the last Lock Message.

# APPENDIX C. INSTALLER MENU

## Installer Menu

INSTALLER MENU	
→ Status	
Boiler Settings	
CH Settings	▼
INSTALLER MENU	
DHW Settings	▲
Service Notif.	
→ System Test	▼
INSTALLER MENU	
System Tests	▲
Cascade Settings	
→ Default	

To access the Installer Menu, press and hold the "Menu" and "Select" keys simultaneously for 10 seconds. The first screen shown to the left of this text will appear. Press the up/down arrow keys to identify the desired menu option. The ▼ or ▲ symbol on the right of the screen indicates that more menu choices can be accessed by continuing to press the down or up arrow respectively. Pressing the "Select" key chooses the option.

STATUS		1	
Current Supply Setpoint		160 °F	▼
STATUS		2	▲
Fan Speed			
Current		0 RPM	
Low Power		1770 RPM	▼
STATUS		3	▲
Fan Speed			
Ignition		3250 RPM	
Hi Power		4800 RPM	▼
STATUS		4	▲
Flame			
Signal		9,6 uA	
Failures		0	▼
STATUS		5	▲
Flame			
Meas. 1	2,5 uA		
Meas. 2	3,8 uA		▼
STATUS		6	▲
Flame			
Meas. 3	6,2 uA		
Meas. 4	8,1 uA		▼
STATUS		7	▲
Ignition Attempts			
Successful	1200		
Failed	1		▼
STATUS		8	▲
Boiler Run Time			
CH	250 HR		
DHW	700 HR		▼

## Status

Screen #1 shows the current supply setpoint temperature. This value will change for a DHW demand or a CH demand. In addition, when outdoor reset modes are selected, this value is calculated based on the outdoor sensor reading.

Screens #2 & #3 display fan speed information. Current fan speed will vary during operation, while Low Power, Ignition, and High Power fan speeds are preset at the factory for a particular model size. Table 12.2 in Section 12 of this manual shows the fan speed presets for each model size.

Screen #4 shows the Flame Signal and the total number of Flame Failures that have occurred on the unit. Note that the refresh rate of the Flame Signal may be several seconds.

Screens #5 & #6 show the flame signal values during the last 2 seconds of the previous ignition sequence. These values are logged in 1/2 second intervals to allow service personnel to troubleshoot ignition issues.

Screen #7 displays the total number of successful and unsuccessful ignition attempts that have occurred on the boiler.

The total boiler run time for central heating (CH) and domestic hot water (DHW) are recorded on screen #8.

## Status continued

STATUS	# E 2 6	9 ▲
2 Day Ago		
BLOCKED CONDENSATE		
DRAIN		▼
STATUS	# E 2 6	0
3 Hrs to prev. Block		
BLOCKED CONDENSATE		
DRAIN		▼
STATUS	# A 0 2	1 0 ▲
16 Hrs Ago		
FLAME FAILURES		▼
STATUS	# E 2 6	0
38 Min to prev. Block		
FLAME FAILURES		▼

Screens #9 & #10 provide information about blocking errors (errors that do not require a control reset) and locking errors (errors that require a control reset). Each of these screens shows the last error records along with amount of time that has passed since the error occurred. To review the error history press the select key. Section 8 provides more detail about reviewing the error history.

## Boiler Settings

BOILER SETTINGS	1 ▲
Pump Mode	MODE: 0
CH or CH&DHW PUMP	▼
BOILER SETTINGS	2 ▲
Installation	
Location:	USA ▼
BOILER SETTINGS	3 ▲
Vent Material:	PVC ▼
BOILER SETTINGS	4 ▲
Freeze Protection	
starts at:	50 °F ▼
BOILER SETTINGS	5 ▲
Blower	
Post Purge time	30 sec ▼
BOILER SETTINGS	6 ▲
Additional Safety	
Safety Function on	LowWaterCO ▼
BOILER SETTINGS	7 ▲
Modbus address	255 ▼

Range:	0 to 3	Default:	0
Reference section 8.C.1 for an explanation of the pump mode function.			
Range:	USA or CAN	Default:	USA
Provides location code information to the control for setting the vent limit temperature. Reference section 8.C.2 for further explanation			
Range:	PVC, CPVC, POLYPROPYLENE	Default:	PVC
Provides vent material information to the control for setting the vent limit temperature. Reference section 8.C.2 for further explanation			
Range:	45 °F to 68 °F	Default:	50 °F
	7 °C to 20 °C		10 °C
Reference section 8.C.3 for an explanation of the Freeze Protection Function.			
Range:	30 sec to 120 sec	Default:	30 sec
Allows installer to increase postpurge time. Reference section 8.C.3 for an explanation of the Blower Post Purge Time Function.			
Range:	LowWaterCO or FlowSwitch	Default:	LowWaterCO
Reference Section 8.C.4 for an explanation of the Additional Safety Functions.			
Range:	0-255	or	Default: 255
Reference PFA-1 board IOM supplement for further information.			

## CH (Central Heating) Settings

CH SETTINGS	1 ▲
CH Mode:	1
Indoor Thermostat	▼
CH SETTINGS	2 ▲
CH Pump	
Post Purge Time	1 min ▼
CH SETTINGS	3 ▲
General Circulator	
Post Purge Time	1 min ▼
CH SETTINGS	4 ▲
Ramp Delay Step	
Modulation	Off ▼

Range:	0 to 7	Default:	7
Reference section 8.D.1 for an explanation of the CH Mode Function.			
Range:	0 min to 60 min	Default:	1 min
Reference section 8.D.4 for an explanation of the CH Pump Post Purge Function.			
Range:	0 min to 60 min	Default:	1 min
Reference section 8.D.4 for an explanation of the GEN Pump Post Purge Function.			
Range:	On or Off	Default:	Off
See section 8.D.4 for an explanation of the Ramp Delay Step Modulation Function.			

## CH (Central Heating) Settings continued

**Outdoor Reset** - An explanation of the Outdoor Reset Function can be found in 8.D.3.

CH SETTINGS	5 ▲
System Type	
User Defined	▼

**Range:** Finned Tube Baseboard, Hydro Air Unit, Cast Iron Radiators, Cast Iron Baseboard, High Mass Radiant, Low Mass Radiant, User Defined (Default). The system type presets allow the installer to quickly set the design values for the above heat distribution types.

CH SETTINGS	6 ▲
Warm Weather	
Shutdown Temp	70 °F ▼

**Range:** "OFF" or 35 °F to 100 °F Default: 70 °F  
-18 °C to 38 °C 21 °C

Reference section 8.D.4 for an explanation of the Warm Weather Shutdown Function.

CH SETTINGS	7 ▲
Reset Curve Design	
Boiler	180 °F
Outdoor	10 °F ▼

**Boiler** 35 °F to 189 °F Default: 180 °F  
**Range:** 2 °C to 91 °C 82 °C

**Outdoor** -40 °F to 70 °F Default: 10 °F  
**Range:** -40 °C to 21 °C -12 °C

CH SETTINGS	8 ▲
R. Curve Mild Weath.	
Boiler	70 °F
Outdoor	70 °F ▼

**Boiler** 36 °F to 189 °F Default: 70 °F  
**Range:** 2 °C to 91 °C 21 °C

**Outdoor** -20 °F to 95 °F Default: 70 °F  
**Range:** -29 °C to 35 °C 21 °C

CH SETTINGS	9 ▲
Reset Curve	
Boiler Min	off °F
Boiler Max	70 °F ▼

**Min** 40 °F to 189 °F Default: 40 °F  
**Range:** 4 °C to 82 °C

**Max** 81 °F to 195 °F Default: 195 °F  
**Range:** 27 °C to 91 °C 91 °C

**Boost Function** - An explanation of the Boost Function can be found in section 8.D.3.

CH SETTINGS	10 ▲
Boost Function	
Temp	18 °F
Time	20 min ▼

**Temp** 0 °F to 36 °F Default: 18 °F  
**Range:** 0 °C to 20 °C 10 °C

**Time** 0 min to 60 min Default: 20 min  
**Range:**

**Anti-Cycling Function** - An explanation of the Anti-Cycling Function can be found in Section 8.D.4

CH SETTINGS	11 ▲
Anti-Cycling	
Time	10 sec ▼

**Range:** 0 sec to 900 sec Default: 10 sec

The Anti-cycling time is settable in 10 second increments. For a detailed explanation of the Anti-Cycling Function, see section 8.D.4.

CH SETTINGS	12 ▲
Max Allowable	
CH Rate :	100 %

**Range:** 50 % to 100 % Default: 100 %

Allows the installer to limit the maximum input rate for central heating (CH). Used when boiler is sized primarily for DHW heating and the CH load is small. See section 8.D.4.

## DHW (Domestic Hot Water) Settings

DHW SETTINGS	1
DHW mode	MODE : 0
No DHW	▼

**Range:** 0 to 2 Default: 0

DHW Modes are used to choose between no DHW (Mode 0) and DHW Tank with either Temp. Sensor (Mode 1) or Thermostat (Mode 2). Section 8.E.1 provides more information.

DHW SETTINGS	2 ▲
DHW Priority :	Time
CH / DHW Switch	
Time	10 min ▼

**Range:** 0 min to 60 min Default: 180 min

Settable in 5 minute increments

Reference section 8.E.2 for an explanation of the DHW Limited Priority Function.

**DHW Heat Dump Function** - An explanation of the DHW Heat Dump Function can be found in section 8.E.4.

DHW SETTINGS	3 ▲
DHW Heat Dump	Off
Max Time	30 s
Min Diff	5 °F

**Max Purge** 0 min to 60 min Default: 1 min

**Time Range:** Settable in 5 second increments

**Min Diff.** 0 °F to 10 °F Default: 5 °F

**Range:** 0 °C to 6 °C 3 °C

DHW SETTINGS	4 ▲
Max Allowable	
DHW Rate :	100 %

**Range:** 50 % to 100 % Default: 100 %

Allows the installer to limit the maximum input rate for domestic hot water (DHW). Used when boiler is sized primarily for CH heating and the DHW load is small. See section 8.E.5.

## Service Notification

SERVICE 1 ▲  
 Reset Notification  
 Timer / Counters  
 Press Select: Reset ▼

This screen allows the installer to reset the notification timers and counters. As the screen indicates, pressing the "Select" key will reset these values. After the "Select" key is pressed, the screen displays, "Done" in place of "Reset."

SERVICE 2 ▲  
 Notification on:  
 OFF ▼

**Range:** Off, HRS, CYCLES, DATE **Default:** Off  
 This screen allows the installer to choose the method of Service Notification or to disable Service Notification. Reference section 8.F for more information.

SERVICE 3 ▲  
 Notification  
 After: X HRS ▼

**Range:** 0 hrs to 8000 hrs **Default:** 4000 hrs  
 Settable in 100 hr increments  
 "SERVICE" will appear in the upper left of the main status screen after the number of hours displayed is exceeded.

SERVICE 4 ▲  
 Notification  
 After: X CYC ▼

**Range:** 0 cyc to 50,000 cyc **Default:** 20,000 cyc  
 Settable in 1000 cyc increments  
 "SERVICE" will appear in the upper left of the main status screen after the number of cycles displayed is exceeded.

SERVICE 5 ▲  
 Notification on:  
 DD MMM YYYY OFF ▼

This screen allows the installer to set the date that the "SERVICE" notification will appear. Using the up/down arrow keys, the Day, Month, and Year can be selected. The date will appear as follows: 01 JAN 2008

## System Test

SYSTEM TEST  
 → Off  
 Low Power  
 Ignition Power ▼

The System Test mode allows the user to force the control to operate at Low Power, Ignition Power, or Maximum Power for service and troubleshooting purposes. Reference section 8.G for more information on this function.

SYSTEM TEST ▲  
 Low Power  
 Ignition Power  
 → Maximum Power

## Cascade Settings

CASCADE  
 Address Selection  
 Boiler Address: 0 ▼

**Range:** 0 to 16 **Default:** 0  
 This screen allows the installer to choose the hierarchy of the boiler. The default value (0) indicates no cascade function is applied, (1) = Master and (2-16) = Slave

CASCADE ▲  
 Start Delay Time:  
 2 min ▼

**Range:** 1 min to 15 min **Default:** 2 min  
 This screen allows the installer to choose the delay time before the next boiler in the sequence is called for. The default for this value is 2 minutes.

CASCADE ▲  
 Stop Delay Time:  
 2 min ▼

**Range:** 1 min to 15 min **Default:** 2 min  
 This screen allows the installer to choose the delay time before the last boiler in the sequence is turned off. The default for this value is 2 minutes.

CASCADE ▲  
 Start Boiler Diff:  
 9 °F ▼

**Range:** 1 °F to 23 °F **Default:** 9 °F  
 This screen allows the installer to choose the temperature differential that starts another boiler in the sequence after the selected delay time.

CASCADE ▲  
 Stop Boiler Diff:  
 18 °F ▼

**Range:** 1 °F to 45 °F **Default:** 18 °F  
 This screen allows the installer to choose the temperature difference below which the last boiler in the sequence will stop after the selected delay time.

CASCADE ▲  
 Calculated Setpoint  
 Max offset up:  
 36 °F ▼

**Range:** 0 °F to 36 °F **Default:** 18 °F  
 This is an offset temperature applied to the setpoint of Dependent boilers that the control uses to adjust system response. Higher values increase system response.

## Cascade Settings continued

CASCADE ▲  
 Calculated Setpoint  
 Max offset down:  
 9 ° F ▼

**Range:** 0 °F to 36 °F **Default:** 9 °F

This is an offset temperature applied to the setpoint of Dependent boilers that the control uses to adjust system response. Higher values increase system response.

CASCADE ▲  
 Next boiler  
 Start rate:  
 50 % ▼

**Range:** 40 % to 95 % **Default:** 50 %

This screen allows the installer to choose the input level at which the boilers that are running should be before the next boiler in the sequence will start.

CASCADE ▲  
 Next boiler  
 Stop rate:  
 9 % ▼

**Range:** 5 % to 40 % **Default:** 9 %

This screen allows the installer to choose the input level at which the boilers that are running should be before the last boiler in the sequence will stop.

CASCADE ▲  
 Rotation Interval  
 2 Days

**Range:** 0 Days to 30 Days **Default:** 5 Days

This screen allows the installer to choose the rotation cycle of the lead boiler. When this time limit is reached, the boiler with the lowest run hours will be chosen as lead. Choosing 0 disables rotation.

# APPENDIX D. COMBUSTION TEST RECORD

## Peerless® PUREFIRE® Combustion Test Record

Contact:			
Company Name:			
Address:			
Phone Number:			
Fax Number:			
Email Address:			
<b>Jobsite Data</b>			
Job Name:			
Jobsite Address:			
<b>Boiler Data</b>			
Boiler Model:		Boiler Serial No.:	
Manufacture Date:		Startup Date:	
<b>Gas Pressure</b>			
Static Inlet Gas Pressure (in. w.c.) [With Boiler Off]:		Inlet Gas Pressure Drop After Boiler Startup (in. w.c.):	
High Fire Outlet Gas Pressure (in. w.c.):		Low Fire Outlet Gas Pressure (in. w.c.):	
<b>Combustion Readings</b>			
Flame Signal High Fire (μA):		Flame Signal Low Fire (μA):	
CO <sub>2</sub> High Fire (%):		CO <sub>2</sub> Low Fire (%):	
CO High Fire (ppm):		CO Low Fire (ppm):	
Fan Speed High Fire:		Fan Speed Low Fire:	
Excess Air High Fire (%):		Excess Air Low Fire (%):	
Exhaust Temperature High Fire (°F):		Exhaust Temperature Low Fire (°F):	
<b>System Information</b>			
Water Pressure:		Condensate Line Size:	
Vent Length (Total Equivalent Feet):		Vent Diameter:	



# PEERLESS<sup>®</sup> PUREFIRE<sup>®</sup>

## Gas Boilers

PFC-460

## Installation, Operation & Maintenance Manual

### TO THE INSTALLER:

*This manual is the property of the owner and must be affixed near the boiler for future reference.*

### TO THE OWNER:

*This boiler should be inspected annually by a Qualified Service Agency.*



PeerlessBoilers.com

**PB HEAT, LLC**

131 S. CHURCH STREET • BALLY, PA 19503