

PRO SERIES BURNER SPECIFICATIONS

Beckett Burner Specifications

Boiler Model Number	Burner Model Number	Burner Head	Static Plate	Nozzle Size	Pump Pressure	Start-up Settings	
						Air Shutter	Air Band
PRO-03-060	AFG-L2	L2	3-3/8"	0.50 60° AS Del	140	4	0
PRO-04-080	AFG-L1	L1	2-3/4"	0.65 60° A Del	140	8	0
PRO-04-100	AFG-L1	L1	2-3/4"	0.85 60° A Del ¹	140	10	4
PRO-05-100	AFG-L1	L1	N/A	0.75 45° B Del	190	7	1
PRO-05-125	AFG-L1	L1	N/A	0.90 60° B Del ¹	190	10	3.5

Factory Installed Nozzles are indicated in **Boldface**.

1 – Shipped Loose with Burner Carton